

Tabletop Robot TT

Operation Manual 8th Edition



IAI America, Inc.



INTELLIGENT ACTUATOR

Please Read Before Use

Thank you for purchasing our product.

This Operation Manual explains the handling methods, structure and maintenance of this product, among others, providing the information you need to know to use the product safely.

Before using the product, be sure to read this manual and fully understand the contents explained herein to ensure safe use of the product.

The CD or DVD that comes with the product contains operation manuals for IAI products.

When using the product, refer to the necessary portions of the applicable operation manual by printing them out or displaying them on a PC.


After reading the Operation Manual, keep it in a convenient place so that whoever is handling this product can reference it quickly when necessary.

[Important]

- This Operation Manual is original.
- The product cannot be operated in any way unless expressly specified in this Operation Manual. IAI shall assume no responsibility for the outcome of any operation not specified herein.
- Information contained in this Operation Manual is subject to change without notice for the purpose of product improvement.
- If you have any question or comment regarding the content of this manual, please contact the IAI sales office near you.
- Using or copying all or part of this Operation Manual without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.


1. Notes on operation

To prevent pinching of fingers, do not bring your fingers near the following areas where a warning label is attached while the actuator is moving.



2. Installation of safety cage

It is strongly recommended that the robot be enclosed by a safety cage to ensure safety of the operator. When the robot is enclosed by a safety cage, the robot will satisfy the Machine Directives regardless of how it is used by the operator.



3. The maximum sound pressure level of this robot is 76.4 dB.

4. After grease has been applied to the guide and ball screw during maintenance and inspection, be sure to install the covers.



INTELLIGENT ACTUATOR

CE Marking

If a compliance with the CE Marking is required, please follow Overseas Standards Compliance Manual (ME0287) that is provided separately.



Before Use



Caution

■ Caution

- [1] Be sure to read this operation manual to ensure the proper use of this product.
- [2] Unauthorized use or reproduction of a part or all of this operation manual is prohibited.
- [3] Always handle or operate the product in manners specified in this operation manual, by assuming that whatever is not specified herein is not feasible. The warranty does not cover any defect arising from a handling or operation not specified in this operation manual.
- [4] The information contained in this operation manual is subject to change without notice for the purpose of modification and improvement.
 - * If you have purchased PC software:
Always back up the parameters after installing the product or changing the parameter settings.
- [5] The specifications in this manual may not apply to a custom product.



Caution

■ Action to Be Taken in Case of Emergency

If this product is found to be in a dangerous condition, immediately turn off all power switches of the main unit and connected equipment or immediately disconnect all power cables from the outlets. ("Dangerous condition" refers to a situation where the product is generating abnormal heat or smoke or has ignited and a fire or danger to human health is anticipated.)

■ Contact Us

This robot has been designed and manufactured with the utmost attention and care. Should you find any defect, however, or have any question regarding the handling of the robot, please contact IAI at the address and numbers specified at the end of this manual.



Table of Contents

Safety Guide	1
Chapter 1 Installation.....	9
1.1 Introduction	9
1.2 Models	10
1.3 Safety Precautions.....	11
1.4 Warranty.....	12
1.4.1 Warranty Period.....	12
1.4.2 Scope of Warranty.....	12
1.4.3 Honoring the Warranty.....	12
1.4.4 Limited Liability.....	12
1.4.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications....	13
1.4.6 Other Items Excluded from Warranty.....	13
2. Specifications	14
2.1 Basic Specifications	14
2.2 Name and Function of Each Part.....	15
2.2.1 Robot Body	15
2.2.2 Front Panel.....	18
2.2.3 Codes Displayed on the Panel Window	21
2.2.4 Rear Panel	23
2.2.5 I/O Connector Pin Assignments	25
2.3 Interfaces of the Tabletop Robot.....	26
2.3.1 Standard Interface (Main Application Version 0.18 or Earlier)	26
2.3.2 Standard Interface (Main Application Version 0.19 or Later)	28
2.4 External I/O Specifications.....	32
2.4.1 NPN Specification	32
2.4.2 PNP Specification.....	34
2.5 External Dimensions.....	36
3. Installation Environment, Noise Measures and Other.....	44
3.1 Installation Environment	44
3.2 Installation.....	45
3.2.1 Brackets (Optional)	45
3.2.2 Installing the Load, Etc.....	45
3.2.3 Using the T-grooves	46
3.3 Power Source	46
3.4 Noise Measures and Grounding	47
3.4.1 Grounding	47
3.4.2 Noise sources and noise elimination	47
4. System Setup	49
4.1 Connecting the Tabletop Robot with Peripheral Equipment.....	49
4.2 I/O Connection Diagram (External DIOs)	50
4.2.1 NPN specification.....	50
4.2.2 PNP specification	51



Chapter 2	Operation	52
1.	Operation.....	52
1.1	How to Start a Program	52
1.2	Starting a Program by Auto-Start via Parameter Setting.....	53
1.3	Starting via the Digital Program Selector Switch and Function Switch	54
2.	Controller Data	55
2.1	Data Structure.....	55
2.2	Saving Data	56
Chapter 3	X-SEL Language Data	58
1.	Values and Symbols Used in SEL Language	58
2.	Position Part.....	71
3.	Command Part	72
Chapter 4	Commands	74
1.	List of SEL Language Command Codes by Function	74
1.1	List of Commands by Function	74
1.2	List of Commands in Alphabetical Order	79
2.	Explanation of Commands	84
3.	Key Characteristics of Actuator Control Commands and Points to Note	224
3.1	Continuous Movement Commands	224
3.2	PATH/PSPL Commands	226
3.3	CIR/ARC Commands.....	226
3.4	CIR2/ARC2/ARCD/ARCC Commands	226
4.	Palletizing Function	227
4.1	How to Use	227
4.2	Palletizing Setting	227
4.3	Palletizing Calculation.....	233
4.4	Palletizing Movement.....	234
4.5	Program Examples	236
5.	Pseudo-Ladder Task.....	244
5.1	Basic Frame.....	244
5.2	Ladder Statement Field.....	245
5.3	Points to Note	245
5.4	Program Example	246



Chapter 5 Maintenance and Inspection	247
1. Inspection Items and Inspection Intervals.....	247
2. Visual Inspection of the Exterior	247
3. Visual Inspection and Cleaning	247
3.1 Cleaning.....	247
3.2 Interior Inspection	248
3.3 Internal Cleaning.....	248
4. Greasing the Guides.....	248
4.1 Applicable Grease	248
4.2 How to Apply Grease	248
5. Greasing the Ball Screw	249
5.1 Applicable Grease	249
5.2 How to Apply Grease	249
6. Timing Belt.....	249
6.1 Inspecting the Belt	249
6.2 Applicable Belt.....	249
6.3 Belt Replacement Procedure	250
Appendix	251
⊙ How to Create a Program	251
1. Position Table	251
2. Program Format	252
3. Positioning to Five Positions.....	253
4. How to Use TAG and GOTO	254
5. Moving Back and Forth between Two Points.....	255
6. Path Operation	256
7. Output Control during Path Movement	257
8. Circular/Arc Operation	258
9. Home-return Completion Output	259
10. Moving an Axis Selectively based on Input and Outputting a Completion Signal ..	260
11. Changing the Moving Speed	261
12. Changing the Speed during Movement	262
13. Local/Global Classification of Variables and Flags	263
14. How to Use Subroutines.....	264
15. Pausing the Operation.....	265
16. Aborting the Operation 1 (CANC).....	266



17. Aborting the Operation 2 (STOP)	267
18. Moving to a Specified Position Number	268
19. Conditional Jump.....	269
20. Waiting for Multiple Inputs	270
21. How to Use Offset	271
22. Executing an Operation n Times	272
23. Constant-pitch Feed Operation.....	273
24. Jogging.....	274
25. Switching Programs.....	275
26. Aborting a Program	276
⊙ How to Use Internal DIOs	277
1. Internal DIs and Dedicated Functions.....	277
2. Showing User SEL Program Data on the 7-segment LED Display	278
⊙ List of Parameters	281
1. I/O Parameters	282
2. Parameters Common to All Axes	296
3. Axis-Specific Parameters.....	299
4. Driver Card Parameters.....	303
5. Encoder Parameters.....	307
6. I/O-Slot Card Parameters	308
7. Other Parameters	309
8. Manual Operation Types	314
9. Use Examples of Key Parameters.....	315
⊙ Error Level Control.....	317
⊙ Error List (Main application).....	319
⊙ Error List (Main core)	343
⊙ Troubleshooting of X-SEL Controller	348
Trouble Report Sheet.....	351
Change History	352



Safety Guide

“Safety Guide” has been written to use the machine safely and so prevent personal injury or property damage beforehand. Make sure to read it before the operation of this product.

Safety Precautions for Our Products

The common safety precautions for the use of any of our robots in each operation.

No.	Operation Description	Description
1	Model Selection	<ul style="list-style-type: none">• This product has not been planned and designed for the application where high level of safety is required, so the guarantee of the protection of human life is impossible. Accordingly, do not use it in any of the following applications.<ol style="list-style-type: none">1) Medical equipment used to maintain, control or otherwise affect human life or physical health.2) Mechanisms and machinery designed for the purpose of moving or transporting people (For vehicle, railway facility or air navigation facility)3) Important safety parts of machinery (Safety device, etc.)• Do not use the product outside the specifications. Failure to do so may considerably shorten the life of the product.• Do not use it in any of the following environments.<ol style="list-style-type: none">1) Location where there is any inflammable gas, inflammable object or explosive2) Place with potential exposure to radiation3) Location with the ambient temperature or relative humidity exceeding the specification range4) Location where radiant heat is added from direct sunlight or other large heat source5) Location where condensation occurs due to abrupt temperature changes6) Location where there is any corrosive gas (sulfuric acid or hydrochloric acid)7) Location exposed to significant amount of dust, salt or iron powder8) Location subject to direct vibration or impact• For an actuator used in vertical orientation, select a model which is equipped with a brake. If selecting a model with no brake, the moving part may drop when the power is turned OFF and may cause an accident such as an injury or damage on the work piece.



No.	Operation Description	Description
2	Transportation	<ul style="list-style-type: none">• When carrying a heavy object, do the work with two or more persons or utilize equipment such as crane.• When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers.• When in transportation, consider well about the positions to hold, weight and weight balance and pay special attention to the carried object so it would not get hit or dropped.• Transport it using an appropriate transportation measure. The actuators available for transportation with a crane have eyebolts attached or there are tapped holes to attach bolts. Follow the instructions in the operation manual for each model.• Do not step or sit on the package.• Do not put any heavy thing that can deform the package, on it.• When using a crane capable of 1t or more of weight, have an operator who has qualifications for crane operation and sling work.• When using a crane or equivalent equipments, make sure not to hang a load that weighs more than the equipment's capability limit.• Use a hook that is suitable for the load. Consider the safety factor of the hook in such factors as shear strength.• Do not get on the load that is hung on a crane.• Do not leave a load hung up with a crane.• Do not stand under the load that is hung up with a crane.
3	Storage and Preservation	<ul style="list-style-type: none">• The storage and preservation environment conforms to the installation environment. However, especially give consideration to the prevention of condensation.• Store the products with a consideration not to fall them over or drop due to an act of God such as earthquake.
4	Installation and Start	<p>(1) Installation of Robot Main Body and Controller, etc.</p> <ul style="list-style-type: none">• Make sure to securely hold and fix the product (including the work part). A fall, drop or abnormal motion of the product may cause a damage or injury. Also, be equipped for a fall-over or drop due to an act of God such as earthquake.• Do not get on or put anything on the product. Failure to do so may cause an accidental fall, injury or damage to the product due to a drop of anything, malfunction of the product, performance degradation, or shortening of its life.• When using the product in any of the places specified below, provide a sufficient shield.<ol style="list-style-type: none">1) Location where electric noise is generated2) Location where high electrical or magnetic field is present3) Location with the mains or power lines passing nearby4) Location where the product may come in contact with water, oil or chemical droplets



No.	Operation Description	Description
4	Installation and Start	<p>(2) Cable Wiring</p> <ul style="list-style-type: none">● Use our company's genuine cables for connecting between the actuator and controller, and for the teaching tool.● Do not scratch on the cable. Do not bend it forcibly. Do not pull it. Do not coil it around. Do not insert it. Do not put any heavy thing on it. Failure to do so may cause a fire, electric shock or malfunction due to leakage or continuity error.● Perform the wiring for the product, after turning OFF the power to the unit, so that there is no wiring error.● When the direct current power (+24V) is connected, take the great care of the directions of positive and negative poles. If the connection direction is not correct, it might cause a fire, product breakdown or malfunction.● Connect the cable connector securely so that there is no disconnection or looseness. Failure to do so may cause a fire, electric shock or malfunction of the product.● Never cut and/or reconnect the cables supplied with the product for the purpose of extending or shortening the cable length. Failure to do so may cause the product to malfunction or cause fire. <p>(3) Grounding</p> <ul style="list-style-type: none">● The grounding operation should be performed to prevent an electric shock or electrostatic charge, enhance the noise-resistance ability and control the unnecessary electromagnetic radiation.● For the ground terminal on the AC power cable of the controller and the grounding plate in the control panel, make sure to use a twisted pair cable with wire thickness 0.5mm^2 (AWG20 or equivalent) or more for grounding work. For security grounding, it is necessary to select an appropriate wire thickness suitable for the load. Perform wiring that satisfies the specifications (electrical equipment technical standards).● Perform Class D Grounding (former Class 3 Grounding with ground resistance 100Ω or below).



No.	Operation Description	Description
4	Installation and Start	<p>(4) Safety Measures</p> <ul style="list-style-type: none"> • When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. • When the product is under operation or in the ready mode, take the safety measures (such as the installation of safety and protection fence) so that nobody can enter the area within the robot's movable range. When the robot under operation is touched, it may result in death or serious injury. • Make sure to install the emergency stop circuit so that the unit can be stopped immediately in an emergency during the unit operation. • Take the safety measure not to start up the unit only with the power turning ON. Failure to do so may start up the machine suddenly and cause an injury or damage to the product. • Take the safety measure not to start up the machine only with the emergency stop cancellation or recovery after the power failure. Failure to do so may result in an electric shock or injury due to unexpected power input. • When the installation or adjustment operation is to be performed, give clear warnings such as "Under Operation; Do not turn ON the power!" etc. Sudden power input may cause an electric shock or injury. • Take the measure so that the work part is not dropped in power failure or emergency stop. • Wear protection gloves, goggle or safety shoes, as necessary, to secure safety. • Do not insert a finger or object in the openings in the product. Failure to do so may cause an injury, electric shock, damage to the product or fire. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.
5	Teaching	<ul style="list-style-type: none"> • When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. • Perform the teaching operation from outside the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. • When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. • When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. • Place a sign "Under Operation" at the position easy to see. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>



No.	Operation Description	Description
6	Trial Operation	<ul style="list-style-type: none">• When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers.• After the teaching or programming operation, perform the check operation one step by one step and then shift to the automatic operation.• When the check operation is to be performed inside the safety protection fence, perform the check operation using the previously specified work procedure like the teaching operation.• Make sure to perform the programmed operation check at the safety speed. Failure to do so may result in an accident due to unexpected motion caused by a program error, etc.• Do not touch the terminal block or any of the various setting switches in the power ON mode. Failure to do so may result in an electric shock or malfunction.
7	Automatic Operation	<ul style="list-style-type: none">• Check before starting the automatic operation or rebooting after operation stop that there is nobody in the safety protection fence.• Before starting automatic operation, make sure that all peripheral equipment is in an automatic-operation-ready state and there is no alarm indication.• Make sure to operate automatic operation start from outside of the safety protection fence.• In the case that there is any abnormal heating, smoke, offensive smell, or abnormal noise in the product, immediately stop the machine and turn OFF the power switch. Failure to do so may result in a fire or damage to the product.• When a power failure occurs, turn OFF the power switch. Failure to do so may cause an injury or damage to the product, due to a sudden motion of the product in the recovery operation from the power failure.







No.	Operation Description	Description
8	Maintenance and Inspection	<ul style="list-style-type: none"> • When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. • Perform the work out of the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. • When the work is to be performed inside the safety protection fence, basically turn OFF the power switch. • When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. • When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. • Place a sign "Under Operation" at the position easy to see. • For the grease for the guide or ball screw, use appropriate grease according to the Operation Manual for each model. • Do not perform the dielectric strength test. Failure to do so may result in a damage to the product. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. • The slider or rod may get misaligned OFF the stop position if the servo is turned OFF. Be careful not to get injured or damaged due to an unnecessary operation. • Pay attention not to lose the cover or untightened screws, and make sure to put the product back to the original condition after maintenance and inspection works. <p>Use in incomplete condition may cause damage to the product or an injury.</p> <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>
9	Modification and Dismantle	<ul style="list-style-type: none"> • Do not modify, disassemble, assemble or use of maintenance parts not specified based at your own discretion.
10	Disposal	<ul style="list-style-type: none"> • When the product becomes no longer usable or necessary, dispose of it properly as an industrial waste. • When removing the actuator for disposal, pay attention to drop of components when detaching screws. • Do not put the product in a fire when disposing of it. <p>The product may burst or generate toxic gases.</p>
11	Other	<ul style="list-style-type: none"> • Do not come close to the product or the harnesses if you are a person who requires a support of medical devices such as a pacemaker. Doing so may affect the performance of your medical device. • See Overseas Specifications Compliance Manual to check whether complies if necessary. • For the handling of actuators and controllers, follow the dedicated operation manual of each unit to ensure the safety.



Alert Indication

The safety precautions are divided into “Danger”, “Warning”, “Caution” and “Notice” according to the warning level, as follows, and described in the Operation Manual for each model.

Level	Degree of Danger and Damage	Symbol
Danger	This indicates an imminently hazardous situation which, if the product is not handled correctly, will result in death or serious injury.	 Danger
Warning	This indicates a potentially hazardous situation which, if the product is not handled correctly, could result in death or serious injury.	 Warning
Caution	This indicates a potentially hazardous situation which, if the product is not handled correctly, may result in minor injury or property damage.	 Caution
Notice	This indicates lower possibility for the injury, but should be kept to use this product properly.	 Notice



Caution in Handling

1. Do not set speeds and accelerations/decelerations equal to or greater than the respective ratings.

If the actuator is operated at a speed or acceleration/deceleration exceeding the allowable value, abnormal noise or vibration, failure, or shorter life may result.

In the case of interpolated operation of combined axes, the speed and acceleration/deceleration settings should correspond to the minimum values among all combined axes.

2. Keep the load moment within the allowable value.

If the actuator is operated under a load equal to or greater than the allowable load moment, abnormal noise or vibration, failure, or shorter life may result. In an extreme case, flaking may occur.

3. Make sure to attach the actuator properly by following this Operation manual.

Using the product with the actuator not being certainly retained or affixed may cause abnormal noise, vibration, malfunction or shorten the product life.



Chapter 1 Installation

1.1 Introduction

Thank you for purchasing the Tabletop Robot.

Inappropriate use or handling will prevent this product from demonstrating its full function and may even cause unexpected failure or result in a shortened service life. Please read this manual carefully, and handle the product with due care and operate it correctly. Keep this manual in a safe place and reference relevant items when needed.

The Tabletop Robot is an all-in-one actuator that can be used as an independent standalone robot. The robot can also be used to control various peripheral equipment by utilizing the robot's built-in controller and supplied input/output (general-purpose input/output) connector. In general, connecting additional equipment will make the system larger and more complex, which often increases the probability of accident due to malfunction, carelessness, etc. If you are configuring the Tabletop Robot to operate with other equipment, please take sufficient safety measures.

- Actuator duty

Based on the relationship of service life and precision, keep the duty to 50% or less for all actuators of IAI as a guideline.

The duty is calculated by the formula below:

$$\text{Duty (\%)} = \frac{\text{Operating hours}}{\text{Operating hours} + \text{Stopped hours}} \times 100$$

- After turning off the main power, be sure to wait for at least 5 seconds before turning it on. Any shorter interval may generate "E88: Power system error (Other)."
- Do not plug in/out the connectors while the power is still supplied to the controller. Doing so may result in malfunction.

If you have purchased our optional PC software and/or teaching pendant, read the respective operation manuals, as well.

- * Utmost effort has been made to ensure that the information contained in this manual is true and correct. However, should you find any error or if you have any comment regarding the content, please contact IAI.



1.2 Models

Example of Model Code

TT — A3 — I — 2020 — 05B — DV
[1] [2] [3] [4] [5] [6]

Model table

[1] Series	[2] Type	[3] Encoder type	[4] XY stroke (mm)	[5] Z stroke	[6] Options
TT	A2 (Gate 2-axis type) C2 (Cantilever 2-axis type)	I (Incremental)	2020 (200 mm)		DV (DeviceNet) CC (CC-Link) PR (ProfiBus) ET (Ethernet) FT (Mounting bracket) P (External I/O: PNP specification)
	A3 (Gate 3-axis type) C3 (Cantilever 3-axis type)		4040 (400 mm)	05B (50 mm) 10B (100 mm)	

**⚠ Caution**

1.3 Safety Precautions

This system product was developed as a drive unit for an automated machine, etc., and as such the maximum torque and speed are limited to levels acceptable for an automatically driven machine. However, strict observance of the following items is requested to prevent unforeseen danger.

1. Do not handle this product in manners not specified in this manual. If you have any question regarding the content of this manual, please contact IAI.
2. Do not enter the operation area of the machine while the machine is operating or ready to operate (the controller power is on). If the machine is used in a place accessible to other people, provide an appropriate safety measure such as enclosing the machine with a cage.
3. When assembling/adjusting or maintaining/inspecting the machine, always turn off the controller power at the source beforehand. The operator should display in a conspicuous place a plate or other sign saying that operation is in progress and that the power should not be turned on. The operator should keep the entire power cable beside him or her to prevent another person from inadvertently plugging in the cable.
4. When two or more operators are to work together, set call-out signals to ensure safety of all personnel during the work. In particular, a person turning on/off the power or moving an axis—either via a motor or manually—must always say what he or she is going to do out loud and confirm the responses from the others first before actually performing the operation.



1.4 Warranty

1.4.1 Warranty Period

One of the following periods, whichever is shorter:

- 18 months after shipment from our company
- 12 months after delivery to the specified location

1.4.2 Scope of Warranty

Our products are covered by warranty when all of the following conditions are met. Faulty products covered by warranty will be replaced or repaired free of charge:

- (1) The breakdown or problem in question pertains to our product as delivered by us or our authorized dealer.
- (2) The breakdown or problem in question occurred during the warranty period.
- (3) The breakdown or problem in question occurred while the product was in use for an appropriate purpose under the conditions and environment of use specified in the operation manual and catalog.
- (4) The breakdown of problem in question was caused by a specification defect or problem, or by a quality issue with our product.

Note that breakdowns due to any of the following reasons are excluded from the scope of warranty:

- [1] Anything other than our product
- [2] Modification or repair performed by a party other than us (unless we have approved such modification or repair)
- [3] Anything that could not be easily predicted with the level of science and technology available at the time of shipment from our company
- [4] A natural disaster, man-made disaster, incident or accident for which we are not liable
- [5] Natural fading of paint or other symptoms of aging
- [6] Wear, depletion or other expected result of use
- [7] Operation noise, vibration or other subjective sensation not affecting function or maintenance

Note that the warranty only covers our product as delivered and that any secondary loss arising from a breakdown of our product is excluded from the scope of warranty.

1.4.3 Honoring the Warranty

As a rule, the product must be brought to us for repair under warranty.

1.4.4 Limited Liability

- (1) We shall assume no liability for any special damage, consequential loss or passive loss such as a loss of expected profit arising from or in connection with our product.
- (2) We shall not be liable for any program or control method created by the customer to operate our product or for the result of such program or control method.



1.4.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications

- (1) If our product is combined with another product or any system, device, etc., used by the customer, the customer must first check the applicable standards, regulations and/or rules. The customer is also responsible for confirming that such combination with our product conforms to the applicable standards, etc. In such a case we will not be liable for the conformance of our product with the applicable standards, etc.
- (2) Our product is for general industrial use. It is not intended or designed for the applications specified below, which require a high level of safety. Accordingly, as a rule our product cannot be used in these applications. Contact us if you must use our product for any of these applications:
 - [1] Medical equipment pertaining to maintenance or management of human life or health
 - [2] A mechanism or mechanical equipment intended to move or transport people (such as a vehicle, railway facility or aviation facility)
 - [3] Important safety parts of mechanical equipment (such as safety devices)
 - [4] Equipment used to handle cultural assets, art or other irreplaceable items
- (3) Contact us at the earliest opportunity if our product is to be used in any condition or environment that differs from what is specified in the catalog or operation manual.

1.4.6 Other Items Excluded from Warranty

The price of the product delivered to you does not include expenses associated with programming, the dispatch of engineers, etc. Accordingly, a separate fee will be charged in the following cases even during the warranty period:

- [1] Guidance for installation/adjustment and witnessing of test operation
- [2] Maintenance and inspection
- [3] Technical guidance and education on operating/wiring methods, etc.
- [4] Technical guidance and education on programming and other items related to programs



2. Specifications

2.1 Basic Specifications

Item	Description
Number of controlled axes	Maximum 3 axes (Factory setting)
Power-source voltage	Single-phase, 100 to 230 VAC \pm 10%
Power-source frequency	50 Hz/60 Hz
Withstand voltage	2000 V 1 minute
Rush current	15 A (100 VAC), 30 A (200 VAC)
Leak current	0.75 mA (60 Hz)
Resistance to momentary power failure	Max 500 μ s
Electric-shock protection mechanism	Class 1 basic isolation
Surrounding air temperature range	0°C to 40°C
Surrounding humidity range	20% to 90% (Non-condensing)
Storage temperature range	-10°C to 65°C
Maximum speed	300 mm/sec
Rated acceleration	Gate type: 0.3 G, Cantilever type: 0.2 G
Programming language	Super SEL language
Program steps	6000 steps (total)
Number of positions	3000 positions
Number of programs	64 programs
Multi-tasking	16 programs
Standard inputs	16 points (General-purpose inputs, port Nos. 016 to 031)
Standard outputs	16 points (General-purpose outputs, port Nos. 316 to 331)
Dedicated inputs	Digital switch for program number input Function switch, etc.
Dedicated outputs	Alarm status indicator LED Ready status indicator LED Emergency-stop status indicator LED Home-return completion status indicator LED, etc.
Serial communication	For teaching pendant/PC connection
Supported Fieldbus standards	CC-LINK DeviceNet Profibus ModBus/TCP Ethernet



Note: The parameters are normally set to the above general-purpose input and general-purpose output port numbers before shipment.






2.2 Name and Function of Each Part

2.2.1 Robot Body

Gate 2-axis type




Gate 3-axis type






Cantilever 2-axis type




Cantilever 3-axis type





- X-axis actuator
Various loads can be attached to the X-axis actuator of the gate-type robot.
 - Y-axis actuator
Various tools can be attached to the Y-axis actuator of the 2-axis robot.
 - Z-axis actuator
Various tools can be attached to the Z-axis actuator of the 3-axis robot.
 - T-groove
Auxiliary tools can be attached by utilizing the T-grooves/T-slots and nuts.
 - Position adjustment volume
You can fine-tune the slider position easily by turning this volume with a flathead screwdriver, etc.
This function is useful when manually adjusting the slider position to read position data.
This adjustment volume is provided on various actuators.
- (Note) Before fine-tuning the slider position using this volume, be sure to actuate an emergency stop.
Do not insert an adjustment tool, finger or other object into the operating range of the robot while the servo is ON or slider is operating.

2.2.2 Front Panel



- [1] Emergency button (emergency-stop button)
This switch is used to cut off the drive power when the robot must be stopped in case of emergency.
- [2] Digital program selector switch
This switch provides a 2-digit decimal digital switch input for selecting the program you want to start from among the group of programs stored in the Tabletop Robot. Pressing the start switch [3] will start the selected program.
- [3] Start switch (function switch)
This switch issues a trigger to start the program set by the digital program selector switch [2].
(Factory setting)
This switch is enabled in the AUTO mode.
In the MANU mode, this switch is enabled after the teaching pendant or PC software has been connected online. (Once the teaching pendant or PC software is connected online, the switch will remain enabled until the robot is restarted (via software reset), even after the connection is switched offline.)
(This switch turns ON/OFF input port No. 000. Since I/O parameter No. 30 is set to "1" at the factory, input port No. 000 is used as the program start signal (dedicated input). You can use input port No. 000 as a general-purpose input by setting I/O parameter No. 30 to "0.")

Note: The parameters are normally set to the above input port numbers before shipment.



[4] Panel window

The panel window consists of a 4-digit, 7-segment LED display and four LED lamps indicating the status of the robot.

The status indicated by each LED lamp when the lamp is lit is explained below:

RDY: The robot is ready to perform PIO program operation.

(This lamp is connected to dedicated output No. 301.)

ALM: An error of operation-cancellation level or higher has occurred.

(This lamp is connected to dedicated output No. 300.)

EMG: An emergency stop has been actuated.

(This lamp is connected to dedicated output No. 302.)

HPS: All axes have completed their home return.

(This lamp is connected to dedicated output No. 304.)

For the specific codes shown on the 4-digit, 7-segment LED display, refer to 2.2.3, "Codes Displayed on the Panel Window" or the "Error Code Table."

Note: The parameters are normally set to the above output port numbers before shipment.

[5] LED indicator lamps

The status indicated by each LED lamp when the lamp is lit is explained below:

CKE: System clock error

ALM: CPU alarm (system-down level error)

PWR: Power ON

[6] Brake switch

This switch is used to release the axis brake.

Tilt the switch upward (BKRLS side) to forcibly release the brake, or tilt it downward (BKNOM side) to allow the brake to be controlled automatically by the controller. Set this switch to the BKNOM side in normal conditions of use.

[7] USB connector

This connector is used for USB connection. Use it to connect the PC software to the controller via USB cable.

Applicable connector: USB connector B: XM7B-0442

Mating connector: USB cable

Notes

- If the USB port is used, all TT robots comprising the system must be connected one by one to install the USB driver included in the CD-ROM "X-SEL PC Software IA-101-TT-USB." For details on how to install the driver, refer to the operation manual for X-SEL PC software.
- If the USB port is used, a dummy plug must be connected to the teaching connector [9].
Dummy plug model: DP-1

[8] Mode switch

This switch is used to specify the operation mode of the Tabletop Robot.

Tilt the switch upward to select the MANU mode (manual mode), or tilt it downward to select the AUTO mode (automatic mode).

Operations from the teaching pendant or PC software (such as teaching) must be performed in the MANU mode. (They cannot be performed in the AUTO mode.)

Auto program start is enabled in the AUTO mode. (The function cannot be used in the MANU mode.)



[9] Teaching connector

When an optional teaching pendant or PC is connected, this D-sub, 25-pin connector will be used to input program and position data in the MANU mode.

Interface Specifications of Teaching Serial Interface

Item	Description
Connector name	TP
Connector	DSUB-25 XM3B-2542-502L (Omron)
Communication method	RS232C-compliant, start-stop synchronous method
Baud rate	38.4 kbps max.; half-duplex communication
Maximum connection distance	10 m (38.4 kbps)
Interface standard	RS232C
Connected to	X-SEL teaching pendant

Interface Specifications of Teaching Serial Interface

Item	No.	Direction	Signal name	Description
Terminal assignments	1		FG	Frame ground
	2	Out	TXD	Transmitted data
	3	In	RXD	Received data
	4	Out	RTS	Request to send
	5	In	CTS	Clear to send
	6	Out	DSR	Equipment ready
	7		SG	Signal ground
	8			
	9	In		Connection prohibited
	10	In		Connection prohibited
	11			
	12	Out	EMGOUT	Emergency stop
	13	In	EMGIN	
	14			
	15	Out		Connection prohibited
	16	Out		Connection prohibited
	17	Out		Connection prohibited
	18	Out	VCC	Power output (5-V power source for teaching pendant)
	19	In	ENBTBX	Enable input
	20	In	DTR	Terminal ready
	21			
	22			
	23	Out	EMGS	Emergency-stop status
	24			
	25		SG	Signal ground



2.2.3 Codes Displayed on the Panel Window

(1) Application

Display	Priority (*1)	Description
ACF	1	AC power is cut off (including momentary power failure or drop in power-source voltage).
EFXX	1	System-down level error
Prd	2	Writing data to the flash ROM.
Erg	3	Emergency stop is being actuated (except during the update mode).
oPG	4	Safety gate is open (except during the update mode).
EEXX	5	Cold-start level error
EaXX	5	Cold-start level error
ELXX	5	Operation-cancellation level error
EbXX	5	Operation-cancellation level error
- rP	6	Waiting for a drive-source cutoff reset input (except during the update mode).
- rS	6	Operation is in pause (waiting for restart) (except during the update mode).
- IL	7	All servo axes are interlocked (except during the update mode).
EAXX	8	Message level error
E9XX	8	Message level error
rUd	9	Core update mode
Ud	9	Core update is in progress.
FUdc	9	Core update has completed.
rUdS	9	Slave update mode
UdS	9	Slave update is in progress.
FUdS	9	Slave update has completed.
PNo.	9	Running a program (last started program); "No." indicates program number.
InXX	9	Initialization sequence number
dbG	9	Debug mode
ardg	9	Ready status (auto mode)
rdg	9	Ready status (manual mode)
dSF	10	Deadman switch OFF (manual mode)

(*1) The priority increases as the number decreases.




(2) Core

Display				Priority (*1)	Description
	A	E	F	1	AC power is cut off (including momentary power failure or drop in power-source voltage).
E	E	X	X	1	Cold-start level error
E	d	X	X	1	Cold-start level error
E	E	X	X	1	Operation-cancellation level error
E	b	X	X	1	Operation-cancellation level error
E	A	X	X	2	Message level error
E	9	X	X	2	Message level error
r	U	d	A	2	Application update mode
	U	d	A	2	Application update is in progress.
r	U	d	A	2	Application update has completed.
P	-	-	-	2	Hardware test mode process
	E	r	A	2	Clearing the application flash ROM.
r	E	r	A	2	Application flash ROM has been cleared.
	U	P	A	2	Jump to the application
E	H	E	E	2	Core flash-ROM check process
E	H	E	A	2	Application flash-ROM check process
E	H	S	d	2	SDRAM check process

(*1) The priority increases as the number decreases.

2.2.4 Rear Panel



[9] Power connector

Connect the power cable to this connector.


Use the supplied socket for cable connection with the power connector.

(Note) The allowable range of power-source voltage is 100 to 230 VAC ($\pm 10\%$).

Providing a power cable and attaching it to the supplied socket is the user's responsibility.

Use a cable appropriate for the power-source voltage used.

How to attach a cable to the supplied socket





[10] Ground terminal

This terminal is used to connect FG of the enclosure to ground.

[11] Power switch

[12] Gate X-axis actuator position adjustment volume (This volume is not available on the cantilever type.)

You can fine-tune the X-axis slider position easily by turning this volume with a flathead screwdriver, etc. This function is useful when manually adjusting the slider position to read position data.

(Note) Before fine-tuning the slider position using this volume, be sure to actuate an emergency stop. Do not insert an adjustment tool, finger or other object into the operating range of the robot while the servo is ON or slider is operating.

[13] I/O connector (general-purpose I/Os)

This general-purpose I/O connector is used to connect peripheral equipment, etc.

It is a 34-pin flat connector that comprises 16 general-purpose input/16 general-purpose output DIOs.




2.2.5 I/O Connector Pin Assignments

Pin No.	Category	Port No.	Function	Cable color
1	+24 V		I/O power supply + 24 V	Brown-1
2	Input	016	General-purpose input	Red-1
3		017	General-purpose input	Orange-1
4		018	General-purpose input	Yellow-1
5		019	General-purpose input	Green-1
6		020	General-purpose input	Blue-1
7		021	General-purpose input	Purple-1
8		022	General-purpose input	Gray-1
9		023	General-purpose input	White-1
10		024	General-purpose input	Black-1
11		025	General-purpose input	Brown-2
12		026	General-purpose input	Red-2
13		027	General-purpose input	Orange-2
14		028	General-purpose input	Yellow-2
15		029	General-purpose input	Green-2
16		030	General-purpose input	Blue-2
17		031	General-purpose input	Purple-2
18	Output	316	General-purpose output	Gray-2
19		317	General-purpose output	White-2
20		318	General-purpose output	Black-2
21		319	General-purpose output	Brown-3
22		320	General-purpose output	Red-3
23		321	General-purpose output	Orange-3
24		322	General-purpose output	Yellow-3
25		323	General-purpose output	Green-3
26		324	General-purpose output	Blue-3
27		325	General-purpose output	Purple-3
28		326	General-purpose output	Gray-3
29		327	General-purpose output	White-3
30		328	General-purpose output	Black-3
31		329	General-purpose output	Brown-4
32		330	General-purpose output	Red-4
33		331	General-purpose output	Orange-4
34	0 V		I/O power supply 0 V	Yellow-4

Note: The parameters are normally set to the above port numbers before shipment.

I/O flat cable (supplied) Model: CB-DS-PIO020



No.	Color	Wiring	No.	Color	Wiring
1	Brown1	Flat cable, pressure welded	18	Gray2	Flat cable, pressure welded
2	Red1		19	White2	
3	Orange1		20	Black2	
4	Yellow1		21	Brown-3	
5	Green1		22	Red3	
6	Blue1		23	Orange3	
7	Purple1		24	Yellow3	
8	Gray1		25	Green3	
9	White1		26	Blue3	
10	Black1		27	Purple3	
11	Brown-2		28	Gray3	
12	Red2		29	White3	
13	Orange2		30	Black3	
14	Yellow2		31	Brown-4	
15	Green2		32	Red4	
16	Blue2		33	Orange4	
17	Purple2		34	Yellow4	



2.3 Interfaces of the Tabletop Robot

2.3.1 Standard Interface (Main Application Version 0.18 or Earlier)

The standard interface of the Tabletop Robot uses input port Nos. 000 to 047 and output port Nos. 300 to 347.

The standard interface is subject to limitations on use.

Only input port Nos. 016 to 031 and output port Nos. 316 to 331 can send/receive signals to/from peripheral equipment via the I/O connector on the rear panel as external DIOs.

Other ports are used as internal DIOs, dedicated ports for switches/LEDs on the front panel or ports used by SEL programs, or reserved for future expansion.

[Internal DI, Internal DO]

- Internal DI No. 000 is an input port connected from the start switch on the front panel.
- Internal DI Nos. 007 to 010 and Nos. 011 to 013 are input ports connected from the digital switch on the front panel.
- Although dedicated functions can be assigned to internal DI Nos. 001 to 006, 014 and 015, these ports cannot be controlled directly. To control internal DI Nos. 001 to 006, 014 and 015, turn ON/OFF internal DO Nos. 308 to 315 in a SEL program. For details, refer to © Appendix, "How to Use Internal DIOs."
- Internal DI No. 300 to 304 is an output port to the panel window LED and start switch LED from the front panel.
- Internal DO Nos. 332 to 346 are used to control the 7-segment LED display in the panel window on the front panel.

System information and user program data can be shown alternately on the 7-segment LED display by using a SEL program. For details, refer to © Appendix, "How to Use Internal DIOs."



Internal DIO Table

	Port No.	Function		Port No.	Function
Internal DI	000	Start	Internal DO	300	ALM (LED on the front panel)
	001	(Software reset)		301	RDY (LED on the front panel)
	002	(Servo ON)		302	EMG (LED on the front panel)
	003	(Auto program start)		303	Automatic operation mode (start switch LED)
	004	(Software interlock)		304	HPS (LED on the front panel)
	005	(Pause reset)		305	For future expansion
	006	(Pause)		306	For future expansion
	007	Program number specification Ones place of the digital switch		307	For future expansion
	008			308	Internal DI No. 001 ON/OFF
	009			309	Internal DI No. 002 ON/OFF
	010	Program number specification Tens place of the digital switch		310	Internal DI No. 003 ON/OFF
	011			311	Internal DI No. 004 ON/OFF
	012			312	Internal DI No. 005 ON/OFF
	013	(Drive-source cutoff input) (Home return, etc.)		313	Internal DI No. 006 ON/OFF
	014			314	Internal DI No. 014 ON/OFF
	015			315	Internal DI No. 015 ON/OFF
External DI	016 to 031	General-purpose input (I/O connector on the rear panel)	External DO	316 to 331	General-purpose output (I/O connector on the rear panel)
Internal DI	032	For future expansion	Internal DO	332	7-segment user display digit specification
	033			333	7-segment user display digit specification
	034			334	For future expansion
	035			335	For future expansion
	036			336	For future expansion
	037			337	7-segment display refresh
	038			338	7-segment user/system alternate display
	039			339	7-segment user display specification
	040			340	DT0 (7-segment user display bit)
	041			341	DT1 (7-segment user display bit)
	042			342	DT2 (7-segment user display bit)
	043			343	DT3 (7-segment user display bit)
	044			344	DT4 (7-segment user display bit)
	045			345	DT5 (7-segment user display bit)
	046			346	DT6 (7-segment user display bit)
	047			347	For future expansion
External DI	048 to 299	Used for field network (Optional)	External DO	348 to 599	Used for field network (Optional)



2.3.2 Standard Interface (Main Application Version 0.19 or Later)

The input port to which to assign the input function selection from 000 to 015 currently set by “Input function selection ***” can be set (changed) using the I/O parameter “Physical input port number for input function selection ***.”

The output port to which to assign the output function selection from 300 to 315 currently set by “Output function selection ***” can be set (changed) using the I/O parameter “Physical output port number for output function selection ***.”

In addition to output function selections 300 to 315 described above, you can also use the I/O parameter “Physical output port number for output function selection *** (area 2)” to set (assign) an output port for the output function selection from 300 (area 2) to 315 (area 2) currently set by “Output function selection *** (area 2),” and output the applicable signal from the specified port.

Note: The above functions are supported by the X SEL PC software of version 7.0.2.0 or later.

(1) Assignment example of input function selection

The following is an example of assigning input function selection 000 (start), currently set by “Input function selection 000,” to a different input port.

Set the function of input function selection 000 (start) using I/O parameter No. 30, “Input function selection 000.” For details, refer to Appendix, “Parameter List.”

The physical input port number for input function selection 000 (start) is set by I/O parameter No. 283, “Physical input port number for input function selection 000.”

If “016” is set in this parameter, for example, the function of input function selection 000 (start) is assigned to “input port No. 016.”

Accordingly, input port 016 becomes the signal input port for input function selection 000 (start). After the assignment has been changed, “input port No. 000” returns to a general-purpose input port.

Note, however, that the above parameter will become invalid when “-1 (default value: normally the parameter is set to this value before shipment)” is set, in which case the function of input function selection 000 (start) will be assigned to “input port No. 000” as shown in the internal DIO table.

[Notes]

- If input function selection 000 (start) is assigned to a different input port, the start switch on the front panel will no longer function as the “program start signal.”
- If any of input function selections 007 to 013 is assigned to a different input port, the digital program selector switch on the front panel will no longer function as the “start program number.”
- If a network is available, input function selections 000 to 015 can also be assigned to port Nos. 048 to 299 assigned to the network.

Note: Although ports of desired output numbers can be set separately, error No. 685, “I/O function selection physical port number error” will generate if duplicate port numbers are set or the “start program number” is set to a non-continuous port.



(2) Assignment example of output function selection

The following is an example of assigning output function selection 300 (ALM), currently set by "Output function selection 300," to a different output port.

Set the function of output function selection 300 using I/O parameter No. 46, "Output function selection 300." For details, refer to Appendix, "Parameter List."

The physical output port number for output function selection 300 (ALM) is set by I/O parameter No. 299, "Physical output port number for output function selection 300."

If "316" is set in this parameter, for example, the function of output function selection 300 (ALM) is assigned to "output port No. 316."

Accordingly, the signal of output function selection 300 (ALM) is output to output port 316.

Note, however, that the above parameter will become invalid when "0 (default value: normally the parameter is set to this value before shipment)" is set, in which case the function of output function selection 300 (ALM) will be assigned to "output port No. 300" as shown in the internal DIO table.

After the assignment has been changed, "output port No. 300" returns to a general-purpose output port.

- * To output system outputs to an external device, it is recommended that the signals be output separately using "Output function selection *** (area 2)" and "Physical output port number for output function selection *** (area 2)" explained later.

[Notes]

- If output function selection 300 (ALM) is assigned to a different output port, the panel window LED "ALM" on the front panel will no longer function. As a result, this LED will not illuminate even when the ALM signal is output.
- If output function selection 301 (RDY) is assigned to a different output port, the panel window LED "RDY" on the front panel will no longer function. As a result, this LED will not illuminate even after the controller becomes ready (ready to perform PIO program operation).
- If output function selection 302 (EMG) is assigned to a different output port, the panel window LED "EMG" on the front panel will no longer function. As a result, this LED will not illuminate even when the EMG signal is output (emergency stop is actuated).
- If output function selection 303 (start switch) is assigned to a different output port, the start switch LED on the front panel will no longer function. As a result, this LED will not illuminate even during continuous operation.
- If output function selection 304 (HSP) is assigned to a different output port, the panel window LED "HSP" on the front panel will no longer function. As a result, this LED will not illuminate even when the HSP signal is output (all valid axes completed home return).
- Even when the input port number assigned to a given input function selection *** is changed by setting "Physical input port number for input function selection ***" accordingly, the functions where the ON/OFF statuses of output port Nos. 308 to 315 are reflected in input port Nos. 1 to 6, 14 and 15 will be maintained, as shown in the internal DIO table. For example, setting "Input function selection 001" and "Physical input port number for input function selection 001" to "1" (soft reset) and "16," respectively, and then turning output port No. 308 ON will turn input port No. 1 ON, but soft reset will not be executed.

Note: Although ports of desired output numbers can be set separately, error No. 685, "I/O function selection physical port number error" will generate if duplicate port numbers are set.



(3) Assignment example of output function selection (area 2)

Output function selection 300 (area 2) (ALM), currently set by “Output function selection 300 (area 2),” can be assigned to the output port set by “Physical output port number for output function selection 300 (area 2)” to output the applicable signal from this port. An example is given below.

Set the function of output function selection 300 (area 2) using I/O parameter No. 331, “Output function selection 300 (area 2).” For details, refer to Appendix, “Parameter List.”

The physical output port number for output function selection 300 (area 2) (ALM) is set by I/O parameter No. 315, “Physical output port number for output function selection 300 (area 2).”

If “316” is set in this parameter, for example, the function of output function selection 300 (area 2) (ALM) is assigned to “output port No. 316.”

Accordingly, the signal of output function selection 300 (area 2) (ALM) is output to output port 316.

Note, however, that the above parameter will become invalid when “0 (default value: normally the parameter is set to this value before shipment)” is set, in which case the signal will not be output.

Based on the above setting, the ALM signal can now be output to a different port (output port set for area 2) without disabling the ALM LED on the front panel (without changing the setting of “Physical input port number for output function selection 300” for output signal selection 300).

Note: Although ports of desired output numbers can be set separately, error No. 685, “I/O function selection physical port number error” will generate if duplicate port numbers are set.



(4) Use example

The following is a setting example of assigning the system I/Os to external DIOs as shown below when the external DIOs are assigned to input port Nos. 16 to 31 and output port Nos. 316 to 331 (default settings: the external DIOs are normally assigned to these ports before shipment). Settings that allow the panel window LEDs (RDY, ALM, EMG, HPS) to continue functioning normally are explained.

Input port No. 16 = Program start number (ON edge) (specified by BCD)

Input port No. 17 = Servo ON signal

Input port Nos. 18 to 23 = Start program number

Input port No. 24 = Error reset (ON edge)

Input port No. 25 = Home return of all valid axes (ON edge)

Output port No. 316 = Error of operation-cancellation level or higher (ON)

Output port No. 317 = READY output (PIO trigger program operation permitted)

Output port No. 318 = Emergency stop output (ON)

Output port No. 319 = Output during automatic operation

Output port No. 320 = Output if all valid axes completed home return (coordinates have been confirmed)

Output port Nos. 321 to 323 = Output when axis 1 to 3 servos are ON

I/O Parameter Settings

No.	Parameter name	Settings	Remarks
30	Input function selection 000	1	1 (default value) = Program start signal (ON edge) (specified by BCD)
32	Input function selection 002	1	1 = Servo ON
37 to 42	Input function selection 007 to 012	1	1 (default value) = Start program number
43	Input function selection 013	2	2 = Error reset (ON edge)
45	Input function selection 015	1	1 = Home return of all valid axes (ON edge)
283	Physical input port number for input function selection 000	16	Input port number = 16
285	Physical input port number for input function selection 002	17	Input port number = 17
290 to 295	Physical input port number for input function selection 007 to 012	18 to 23	Input port number = 18 to 23
296	Physical input port number for input function selection 013	24	Input port number = 24
298	Physical input port number for input function selection 015	25	Input port number = 25
315 to 330	Physical input port number for output function selection 300 (area 2) to physical input port number for output function selection 307 (area 2)	316 to 323	Output port numbers = 316 to 323
331	Output function selection 300 (area 2)	1	1 = Error of operation-cancellation level or higher (ON)
332	Output function selection 301 (area 2)	1	1 = READY output (PIO trigger program operation permitted)
333	Output function selection 302 (area 2)	1	1 = Emergency stop output (ON)
334	Output function selection 303 (area 2)	2	2 = Output during automatic operation (Other parameter No. 12)
335	Output function selection 304 (area 2)	2	2 = Output if all valid axes completed home return (coordinates have been confirmed)
336 to 338	Output function selection 305 (area 2) to output function selection 307 (area 2)	2	2 = Output when axis 1 to 3 servos are ON (system monitor task output)

[Notes]

- If input function selection 000 (start) is assigned to a different input port, the start switch on the front panel will no longer function as the "program start signal."
- If any of input function selections 007 to 013 (digital switches) is assigned to a different input port, the digital program selector switch on the front panel will no longer function as the "start program number."




2.4 External I/O Specifications

2.4.1 NPN Specification

(1) Input part

External Input Specifications (NPN Specification)

Item	Specification
Input voltage	24 VDC $\pm 10\%$
Input current	7 mA per circuit
ON/OFF voltage	ON voltage --- 16.0 VDC min. OFF voltage --- 5.0 VDC max.
Isolation method	Photocoupler isolation
External devices	[1] No-voltage contact (minimum load of approx. 5 VDC/1 mA) [2] Photoelectric/proximity sensor (NPN type) [3] Sequencer transistor output (open-collector type) [4] Sequencer contact output (minimum load of approx. 5 VDC/1 mA)



Note: The parameters are normally set to the above port numbers before shipment.

Caution

If a non-contact circuit is connected externally, malfunction may result from leakage current. Use a circuit in which leakage current in a switch-off state does not exceed 1 mA.

⊙ Input signals to the Tabletop Robot



At the default settings, the system recognizes the ON/OFF durations of input signals if they are approx. 4 msec or longer. The ON/OFF duration settings can also be changed using I/O parameter No. 20 (input filtering frequency).


(2) Output part

External Output Specifications (NPN Specification)

Item	Specification	
Load voltage	24 VDC	TD62084 (or equivalent)
Maximum load current	100 mA per point, 400 mA per 8 ports Note)	
Leakage current	0.1 mA max. per point	
Isolation method	Photocoupler isolation	
External devices	[1] Miniature relay	
	[2] Sequencer input unit	

Note) 400 mA is the maximum total load current of every eight ports from output port No. 316.

[Output circuit]



Note: The parameters are normally set to the above port numbers before shipment.

⚠ Caution

In the event that the load is short-circuited or current exceeding the maximum load current is input, the overcurrent protection circuit will be actuated to cut off the circuit. However, give due consideration to the circuit connection layout to prevent short-circuit or overcurrent.




2.4.2 PNP Specification

(1) Input part

External Input Specifications (PNP Specification)

Item	Specification
Input voltage	24 VDC $\pm 10\%$
Input current	7 mA per circuit
ON/OFF voltage	ON voltage --- 8 VDC max. OFF voltage --- 19 VDC min.
Isolation method	Photocoupler isolation
External devices	[1] No-voltage contact (minimum load of approx. 5 VDC/1 mA) [2] Photoelectric/proximity sensor (PNP type) [3] Sequencer transistor output (open-collector type) [4] Sequencer contact output (minimum load of approx. 5 VDC/1 mA)

[Input circuit]



Note: The parameters are normally set to the above port numbers before shipment.

Caution

If a non-contact circuit is connected externally, malfunction may result from leakage current. Use a circuit in which leakage current in a switch-off state does not exceed 1 mA.

⊙ Input signals to the Tabletop Robot




At the default settings, the system recognizes the ON/OFF durations of input signals if they are approx. 4 msec or longer. The ON/OFF duration settings can also be changed using I/O parameter No. 20 (input filtering frequency).

(2) Output part

External Output Specifications

Item	Specification	
Load voltage	24 VDC	TD62784 (or equivalent)
Maximum load current	100 mA per point, 400 mA per 8 ports Note)	
Leakage current	0.1 mA max. per point	
Isolation method	Photocoupler isolation	
External devices	[1] Miniature relay	
	[2] Sequencer input unit	

Note) 400 mA is the maximum total load current of every eight ports from output port No. 300.



Note: The parameters are normally set to the above port numbers before shipment.


Caution

In the event that the load is short-circuited or a current exceeding the maximum load current is input, the overcurrent protection circuit will be actuated to cut off the circuit. However, give due consideration to the circuit connection layout to prevent short-circuit or overcurrent.




2.5 External Dimensions

Compact, cantilever 2-axis type with 200-mm XY-axis stroke






Compact, cantilever 3-axis type with 200-mm XY-axis stroke







Weight [kg]	18
-------------	----

Large, cantilever 2-axis type with 400-mm XY-axis stroke




Y-slider mounting hole



Weight [kg]	35
-------------	----




Large, cantilever 3-axis type with 400-mm XY-axis stroke




Weight [kg]	37
-------------	----



Compact, gate 2-axis type with 200-mm XY-axis stroke




Compact, gate 3-axis type with 200-mm XY-axis stroke






Large, gate 2-axis type with 400-mm XY-axis stroke



Large, gate 3-axis type with 400-mm XY-axis stroke



Weight [kg]	35
-------------	----



3. Installation Environment, Noise Measures and Other

As for the use environment, the products explained in this manual can be used in an environment of pollution degree 2*¹ or equivalent.

*1 Pollution degree 2: An environment normally subject to non-conductive contaminants only, but conductive contaminants may generate temporarily due to bedewing.
(EN60947-5-1)

3.1 Installation Environment

- (1) When installing and wiring the Tabletop Robot, do not block the ventilation holes provided for cooling. (Insufficient ventilation will not only prevent the robot from functioning fully, but it may also result in failure.)
- (2) Prevent foreign matter from entering the Tabletop Robot through the ventilation holes. Since the controller inside the robot is not designed as dustproof or waterproof (oilproof), avoid using the robot in a dusty place or place subject to oil mist or splashed cutting fluid.
- (3) Do not expose the Tabletop Robot to direct sunlight or radiant heat from a high heat source such as a heat-treating furnace.
- (4) Use the Tabletop Robot in a non-condensing environment free from corrosive or inflammable gases.
- (5) Use the Tabletop Robot in an environment where it will not receive external vibration or impact.
- (6) Prevent electrical noise from entering the Tabletop Robot or its cables.




3.2 Installation

3.2.1 Brackets (Optional)

The Tabletop Robot is fitted with rubber feet to prevent movement on the installed surface. However, the robot may still move depending on the conditions of use (load, acceleration/deceleration).

Optional brackets securely affix the robot and prevent it from moving.

Install the brackets to the robot using the dedicated T-slots and hexagon socket head bolts (M6x12).



3.2.2 Installing the Load, Etc.

Tapped holes and positioning holes are provided on the X-axis slider (gate type only), Y-axis slider and Z-axis slider. Use these holes to install a load, tool, etc., to each slider.

For details, refer to the external dimension view of the robot.




3.2.3 Using the T-grooves

T-grooves of M4 size are provided on the frame that supports the actuator.

Auxiliary tools and other items can be installed in these T-grooves using nuts.

Use of square nuts is recommended for affixing items using T-grooves, but general hexagonal nuts can also be used.

As for the bolts used for installation, pay attention to their length to ensure that the tip of the bolt will not contact the bottom of the T-groove.



3.3 Power Source

The Tabletop Robot takes power from a single-phase power source of 100 to 230 VAC \pm 10%.

The voltage-source capacity varies depending on the power-source voltage and number of axes, as follows.


		Power-source voltage	
		100 V	200 V
Number of axes	2 axes	150 VA	155 VA
	3 axes	210 VA	215 VA




3.4 Noise Measures and Grounding

3.4.1 Grounding

Power terminal E is used for protective grounding. Provide Class D grounding from this terminal.



Provide dedicated grounding from the Tabletop Robot.




Do not ground the robot as shown above.

3.4.2 Noise sources and noise elimination

There are many noise sources, but solenoid valves, magnet switches and relays are of particular concern when building a system. Noise from these parts can be eliminated using the measures specified below:

[1] AC solenoid valve, magnet switch, relay


Measure --- Install a surge killer in parallel with the coil.





[2] DC solenoid valve, magnet switch, relay


Measure --- Install a diode in parallel with the coil. Determine the diode capacity in accordance with the load capacity.



In a DC circuit, connecting a diode in reversed polarity will damage the diode, internal parts of the controller and DC power supply. Exercise due caution.

The above noise elimination measures are particularly important when a 24-VDC relay is driven directly by a controller output and there is also a 100-VAC solenoid valve, etc.


Reference Circuit Diagram





4. System Setup


4.1 Connecting the Tabletop Robot with Peripheral Equipment





4.2 I/O Connection Diagram (External DIOs)

4.2.1 NPN specification



Note: The parameters are normally set to the above port numbers before shipment.



4.2.2 PNP specification

Pin No	Category	Port No	Function	Cable color
1			I/O power supply + 24 V	Brown-1
2	Input	016	General-purpose input	Red-1
3		017	General-purpose input	Orange-1
4		018	General-purpose input	Yellow-1
5		019	General-purpose input	Green-1
6		020	General-purpose input	Blue-1
7		021	General-purpose input	Purple-1
8		022	General-purpose input	Gray-1
9		023	General-purpose input	White-1
10		024	General-purpose input	Black-1
11		025	General-purpose input	Blown-2
12		026	General-purpose input	Red-2
13		027	General-purpose input	Orange-2
14		028	General-purpose input	Yellow-2
15		029	General-purpose input	Green-2
16		030	General-purpose input	Blue-2
17		031	General-purpose input	Purple-2
18	Output	316	General-purpose output	Gray-2
19		317	General-purpose output	White-2
20		318	General-purpose output	Black-2
21		319	General-purpose output	Blown-3
22		320	General-purpose output	Red-3
23		321	General-purpose output	Orange-3
24		322	General-purpose output	Yellow-3
25		323	General-purpose output	Green-3
26		324	General-purpose output	Blue-3
27		325	General-purpose output	Purple-3
28		326	General-purpose output	Gray-3
29		327	General-purpose output	White-3
30		328	General-purpose output	Black-3
31		329	General-purpose output	Blown-4
32		330	General-purpose output	Red-4
33		331	General-purpose output	Orange-4
34			I/O power supply 0 V	Yellow-4

+ 24V 0V

Note: The parameters are normally set to the above port numbers before shipment.



Chapter 2 Operation


1. Operation

1.1 How to Start a Program

With the Tabletop Robot, the stored programs can be started (run) using the four methods specified below:

- Starting from the PC software
- Starting from the teaching pendant
- Starting automatically by a parameter setting (auto start)
- Starting via the digital program selector switch and function switch

The starting methods using the PC software and teaching pendant are used for simple operation checks as part of debugging process. For the specific operating procedures to start Tabletop Robot programs from the PC software or teaching pendant, refer to the operation manual for the PC software or teaching pendant.






1.2 Starting a Program by Auto-Start via Parameter Setting

I/O parameter No. 33 (input function selection 003) = 1 (default factory setting)

This parameter is set using the teaching pendant or PC software.



Caution

[Note on starting a program by auto-start]

The automatic operation will begin immediately after the controller is reset, so the user may be surprised by unexpected movements of the equipment, particularly those caused by a sudden activation of the servo actuator. To ensure safety, always provide an interlocking function, such as allowing the program execution to proceed only after receiving a confirmation signal at the beginning of the program.

If you wish to start multiple programs at the same time, write multiple “EXPG” commands at the beginning of the main program to start the remaining programs. Provide safety measures for each program to be started.



1.3 Starting via the Digital Program Selector Switch and Function Switch

Set a desired program number using the digital program selector switch.
Pressing the function switch will start the specified program.


To use this starting method, one of the following conditions must be satisfied:

- The robot is in the AUTO mode.
- The robot is in the MANU mode, where the teaching pendant or PC software has been connected to the robot online and the robot is not yet restarted. (Once the teaching pendant or PC software is connected online and the digital switch is set, the specified program can be started using the function switch even after the connection is switched offline.)

2. Controller Data

2.1 Data Structure

The controller unit of the Tabletop Robot stores parameters as well as position data and application programs needed to execute SEL commands.




The user must create position data and application programs. The parameters are predefined, but their settings can be changed in accordance with the user's system. Refer to Appendix, "List of Parameters," for details on the parameters.

2.2 Saving Data

When data is created/edited using the PC software or teaching pendant is sent to the controller (or when the [WRT] key is pressed on the teaching pendant), the data is stored in the controller's temporary memory. The data stored in the controller's temporary memory will be erased once the controller is powered off or restarted (via software reset). For important data, always write to the flash memory so that they will not be lost.

Note: Global data (variables, flags and strings) and error lists will be erased once the controller is powered off or restarted (via software reset). (These data cannot be retained after the power is turned off.) The error list is retained after a software reset, but will be cleared once the power is turned off.



Content 1: Parameters other than content 2 and encoder parameters

Content 2: Parameters of driver card, I/O slot card (power system card)

Content 3: Flags, variables, strings

Since the programs, parameters, symbols and positions are read from the flash memory at restart, the data in the temporary memory will return to the original data before editing unless the edited data are written to the flash memory. The controller always operates in accordance with the data in the temporary memory (inside the dotted line) (excluding the parameters).



Points to Note

Point to note when transferring data and writing to the flash memory

Never turn off the main power while data is being transferred or written to the flash memory.

The data will be lost and the controller operation may be disabled.



Chapter 3 X-SEL Language Data

1. Values and Symbols Used in SEL Language

1.1 List of Values and Symbols Used

The various functions required in a program are represented by values and symbols.

Function	Global range	Local range	Remarks
Input port	000 to 299 (300)		Varies depending on the function.
Output port	300 to 599 (300)		Varies depending on the function.
Flag	600 to 899 (300)	900 to 999 (100)	
Variable (integer)	200 to 299 (100) 1200 to 1299 (100)	1 to 99 (99) 1001 to 1099 (99)	99 is used for IN, INB, OUT, OUTB, etc.
Variable (real)	300 to 399 (100) 1300 to 1399 (100)	100 to 199 (100) 1100 to 1199 (100)	199 is used for PPUT, PGET, PARG, etc.
String	300 to 999 (700)	1 to 299 (299)	
Tag number		1 to 99 (99)	
Subroutine number		1 to 99 (99)	
Zone number	1 to 4 (4)		
Pallet number		1 to 10 (10)	
Axis number	1 to 3 (3)		Varies depending on the function.
Axis pattern	0 to 111		
Position number	1 to 3000 (3000)		
Program number	1 to 64 (64)		
Step number	1 to 6000 (6000)		
Task level	NORMAL/HIGH (2)		
SIO channel number	1 to 1 (1) (Also used for TP/PC)		
Wait timer		1	
1-shot pulse timer		16 (Number of timers that can be operated simultaneously)	
Ladder timer		Local flag (100)	
Virtual input port (SEL system → SEL user program)	7000 to 7299 (300)		
Virtual output port (SEL user program → SEL system)	7300 to 7599 (300)		
Number of symbol definitions	1000		
Number of times symbol can be used in commands	5000 (including literals)		
	Used in common from any program.	Referenced separately in each program. Cleared when the program is started.	

Caution

- Variables 99 and 199 are special variables this system uses in operations. Avoid using these two variables for general purposes.
- The values in the table represent ranges that can be processed by software. Items that require physical devices, such as I/O ports and functions relating to axis number and SIO, will be determined by possible combinations and models of commercial boards, etc., available for each device application.



- The variables and flags in the global range are retained until the controller is powered off.
- The variables and flags in the local range are cleared when the program is started (the data are also cleared when the controller is powered off).
- Ranges of values that can be used in SEL language
Integers and real numbers can be used. However, pay due attention to the following limitations:

[1] Numeric data

The Tabletop Robot can handle values of maximum eight digits including a sign and a decimal point.

Integer: -9,999,999 to 99,999,999

Real number: Maximum eight digits including a sign and decimal point, regardless of the size of value

Example) 999999.9, 0.123456, -0.12345

If a floating point is used in operations, the number of valid digits will be limited to seven. Also note that operations using a floating point are subject to error.

[2] Position data

The input range of position data consists of four integer digits and three decimal digits.

-9999.999 to 9999.999

(The maximum value varies depending on the Tabletop Robot.)

If position data are used in internal operations as numeric data (repeated multiplications and divisions), the precision of the last digit may decrease.

Consider the above limitations fully when using values. Particularly when the CPEQ command is used in a comparison operation using real numbers, a match will rarely result. In this case, the CPLE or CPGE command that looks at the magnitude relationship of two terms must be used.

1-2 I/O Ports (External DIOs)

(1) Input ports

Used as input ports for limit switches, sensor switches, etc.

Input number assignment
016 to 031 (standard)

(2) Output ports

Used as various output ports.

Output number assignment
316 to 331 (standard)

Note: The parameters are normally assigned to the above input port and output port numbers before shipment.



1-3 Virtual I/O Ports

(1) Virtual input ports

Port No.	Function
7000	Always OFF
7001	Always ON
7002	Voltage low warning for system-memory backup battery
7003	Abnormal voltage of system-memory backup battery
7004	For future expansion = Use prohibited
7005	For future expansion = Use prohibited
7006	Top-level system error = Message level error is present
7007	Top-level system error = Operation-cancellation level error is present
7008	Top-level system error = Cold-start level error is present
7009	For future expansion = Use prohibited
7010	Drive-source cutoff factor is present (including when waiting for cutoff reset input)
7011	Latch signal indicating that all-operation-cancellation factor is present (latch signal for recognizing 1-shot cancellation factor; latch is cancelled by 7300-ON)
7012	All-operation-pause factor is present (including when waiting for restart switch signal) (Valid only during automatic operation recognition)
7013	All-servo-axis-interlock factor is present (all-operation-pause factor + interlock input-port factor)
7014	For future expansion = Use prohibited
7015	For future expansion = Use prohibited
7016	For future expansion = Use prohibited
7017	For future expansion = Use prohibited
7018	For future expansion = Use prohibited
7019	For future expansion = Use prohibited
7020	For future expansion = Use prohibited
7021	For future expansion = Use prohibited
7022	For future expansion = Use prohibited
7023 to 7030	For future expansion = Use prohibited
7031	For future expansion = Use prohibited
7032	For future expansion = Use prohibited
7033	For future expansion = Use prohibited
7034	For future expansion = Use prohibited
7035	For future expansion = Use prohibited
7036	For future expansion = Use prohibited
7037	For future expansion = Use prohibited
7038 to 7040	For future expansion = Use prohibited
7041 to 7070	For future expansion = Use prohibited
7071	In AUTO mode
7072	During automatic operation
7073 to 7100	For future expansion = Use prohibited
7101	Running program No. 01 (including during pause)
~	~
7164	Running program No. 64 (including during pause)
7165 to 7299	For future expansion = Use prohibited



(2) Virtual output ports

Port No.	Function
7300	Latch cancellation output for a latch signal indicating that all-operation-cancellation factor is present (7011) (latch is cancelled only when operation-cancellation factor is no longer present) (7300 will be turned OFF following an attempt to cancel latch.)
7301 to 7380	For future expansion = Use prohibited
7381 to 7399	For future expansion = Use prohibited
7400 to 7599	For future expansion = Use prohibited


1-4 Flags

Contrary to its common meaning, the term “flag” as used in programming means “memory.” Flags are used to set or reset data. They correspond to “auxiliary relays” in a sequencer.

Flags are divided into global flags (Nos. 600 to 899) that can be used in all programs, and local flags (Nos. 900 to 999) that can be used only in each program.

General-purpose flags (global flags) are retained until the controller is powered off. Dedicated flags (local flags) are cleared when the program is started.

Flag number	600 to 899	Can be used in all programs “Global flags”
Flag number	900 to 999	Used only in each program “Local flags”




1-5 Variables

(1) Meaning of variable


“Variable” is a technical term used in software programming. Simply put, it means “a box in which a value is put.” Variables can be used in many ways, such as putting in or taking out a value and performing addition or subtraction.

A variable can be used in many ways, such as:



Command	Operand 1	Operand 2
ADD	1	1

If this command is applied to variable box 1, which already contains 2, then 1 will be added to the current value and 3 will result.






(2) Types of variables

Variables are classified into two types, as follows:

[1] Integer variables

These variables cannot handle decimal places.

[Example] 1234



Integer variable number	200 to 299 1200 to 1299	Can be used in all programs	“Global integer variables”
Integer variable number	1 to 99 1001 to 1099	Used only in each program	“Local integer variables”

**Caution**


Integer 99 is a special register this system uses in integer operations. Any value in the range from -9,999,999 to 99,999,999 can be input in programs.

[2] Real variables

Actual values. These variables can handle decimal places.

[Example] 1234.567

↑
(Decimal point)



Real variable number	300 to 399 1300 to 1399	Can be used in all programs	“Global real variables”
Real variable number	100 to 199 1100 to 1199	Used only in each program	“Local real variables”

**Caution**

Real number 199 is a special register this system uses in real-number operations. Any value in the range from -99,999.9 to 999,999.9 (eight digits including a sign) can be input in programs.




[3] Variables with “*” (asterisk) (indirect specification)


An “*” (asterisk) is used to specify a variable.

In the following example, the content of variable box 1 will be put in variable box 2. If variable box 1 contains “1234,” then “1234” will be put in variable box 2.

Command	Operand 1	Operand 2
LET	1	1234



Command	Operand 1	Operand 2
LET	2	*1



The above use of variables is called “indirect specification.”

An “*” is also used when indirectly specifying a symbol variable (refer to 1-8, “Symbols”).

Command	Operand 1	Operand 2
LET	ABC	1
LET	BCD	2
ADD	ABC	*BCD

Put 1 in variable ABC.

Put 2 in variable BCD.

Add the content of variable BCD, or 2, to variable ABC.
(The content of variable ABC becomes 3.)




1-6 Tags

The term “tag” means “heading.”


Tags are used in the same way you attach labels to the pages in a book you want to reference frequently.

A tag is a destination specified in a jump command “GOTO.”



Command	Operand 1
TAG	Tag number (Integer between 1 and 99)

They are used only in each program.





1-7 Subroutines

By taking out the parts of a program that are used repeatedly and registering them as “subroutines,” the same processing can be performed with fewer steps. (A maximum of 15 nests are accommodated.)

They are used only in each program.

Command	Operand 1
EXSR	Subroutine number (Integer between 1 and 99; variable is also supported)


Subroutine execution command

Command	Operand 1
BGSR	Subroutine number (Integer between 1 and 99)

Subroutine start declaration

Command	Operand 1
EDSR	---

Subroutine end declaration





1-8 Symbols

In the Tabletop Robot, values such as variable numbers and flag numbers can be handled as symbols. For the method to edit symbols, refer to “Editing Symbols” in the operation manual for X-SEL teaching pendant or “Symbol Edit Window” in the operation manual for X-SEL PC software.

(1) Supported symbols

The following items can be expressed using symbols:

Variable number, flag number, tag number, subroutine number, program number, position number, input port number, output port number, axis number, constant

(2) Description rules of symbols

- [1] A maximum of nine single-byte alphanumeric characters or underscore starting with an alphabet

(Note: The length of a character-string literal must not exceed eight single-byte characters.)

* If the PC software version is 1.1.0.5 or later or the teaching pendant version is 1.04 or later, an underscore can be used as the first character in a symbol.

* If the PC software version is 1.1.0.5 or later, single-byte ASCII code characters from 21h to 7Eh (limited to those that can be input via keyboard) can be used as the second and subsequent characters.

* Exercise caution that the same ASCII code may be expressed differently between the PC software and the teaching pendant because of the different fonts used by the two. (The same applies to character-string literals.)

5Ch --- PC software: Backslash \ (overseas specifications, etc.)

Teaching pendant: Yen mark ¥

7Eh --- PC software: ~

Teaching pendant: Right arrow →

- [2] Symbols of the same name must not be defined within each function. (The same local symbol can be used in different programs.)

- [3] Symbols of the same name must not be defined within the flag number, input-port number or output-port number group. (The same local symbol can be used in different programs.)

- [4] Symbols of the same name must not be defined within the integer-variable number or real-variable number group. (The same local symbol can be used in different programs.)

- [5] Symbols of the same name must not be defined within the integer constant or real constant group.

(3) Number of symbols that can be defined: Maximum 1000

(4) Number of times symbols can be used in all SEL programs: Maximum 5000 times including character-string literals

* If symbol is used in all of the input condition, operand 1, operand 2 and output fields, it is deemed that symbol is used four times in one step.

1-9 Character-String Literals

Character-string literals are used in certain string-operation commands and consist of the portion enclosed by single quotation marks (' ') (maximum eight single-byte characters).

With the PC software, single-byte ASCII code characters from 20h to 7Eh (limited to those that can be input via keyboard) can be used inside the single quotation marks. With the teaching pendant, single-byte alphanumeric characters and single-byte underscores can be used.



1-10 Axis Specification

Axes can be specified based on axis number or axis pattern.

(1) Axis numbers and how axes are stated

Each of multiple axes is stated as follows:

Axis number	How axis is stated
1	Axis 1
2	Axis 2
3	Axis 3



The axis numbers stated above can also be expressed using symbols.

Use axis number if you wish to specify only one of multiple axes.

- Commands that use axis specification based on axis number
BASE, PPUT, PGET, AXST, PASE, PCHZ, ACHZ, PARG



(2) Axis pattern

Whether or not each axis will be used is indicated by “1” or “0.”

	(Upper)		(Lower)
Axis number	Axis 3	Axis 2	Axis 1
Used	1	1	1
Not used	0	0	0

[Example] When axes 1 and 2 are used

Axis 2



011 --- (The 0 in front is not necessary. With the 0 removed, the expression reads “11.”)



Axis 1

[Example] When axes 1 and 3 are used

Axis 3



101 --- (In this case, the 0 is needed to indicate the position of axis 3.)



Axis 1

Indirect specification of axis pattern in a variable

The axis pattern is considered a binary value, and a converted decimal value is assigned to a variable.

[Example] To perform home return for axis 3 only, you can specify as follows based on axis pattern:

```
HOME 100
```

In indirect specification, 100 (binary) is expressed as 4 (decimal), so the same operation can be specified as follows:

```
LET 6 4  
HOME *6
```

If you must select and specify multiple axes at the same time, use axis pattern.

- Commands that use axis specification based on axis pattern
OFST, GRP, SVON, SVOF, HOME, JFWN, JFWF, JBWN, JBWF, STOP, PTST, PRED
CHVL, PBND, WZNA, WZNO, WZFA, WZFO



X-SEL language consists of a position part (position data = coordinates, etc.) and a command part (application program).

2. Position Part

As position data, coordinates, speeds, accelerations and decelerations are set and stored.

* Maximum
Gate type: 0.3 G
Cantilever type: 0.2 G

1 to 300/mm sec

* Maximum
Gate type: 0.3 G
Cantilever type: 0.2 G

Position No.	Axis 1	Axis 2	Axis 3	Speed	Acceleration	Deceleration
1						
2						
3						
⋮						
2998						
2999						
3000						

- * If speed, acceleration or deceleration is set in the position data, the setting will be given priority over the corresponding data set in the application program. Leave the position data fields empty if you wish to enable the corresponding data in the application program.

The effective speed and acceleration are determined based on the following priorities.

Priority	Speed	Acceleration (deceleration)
1	Position data value set in operand 1	Position data value set in operand 1
2	Value set by a VEL command	Value set by an ACC (DCL) command
3		All-axis parameter No. 11, "Default acceleration" (All-axis parameter No. 12, "Default deceleration")



3. Command Part


The primary feature of SEL language is its very simple command structure. Since the structure is simple, there is no need for a compiler (to translate into computer language) and high-speed operation is possible via an interpreter (the program runs as commands are translated).

3.1 SEL language Structure


The table below shows the structure of one command step.

Extension condition (AND, OR)	Input condition (I/O, flag)	Command, declaration			Output (Output port, flag)
		Command, declaration	Operand 1	Operand 2	

Using a ladder diagram, this is expressed as follows:




(1) The condition before the command is equivalent to "IF ~ THEN..." in BASIC.



To the next step

- [1] If the input condition is satisfied, the command will be executed. If there is an output specification, the specified output port will be turned ON. If the input condition is not satisfied, the program will proceed to the next step regardless of the command that follows (e.g., WTON, WTOF). Obviously nothing will happen at the output port, but caution must be exercised.
- [2] If no condition is set, the command will be executed unconditionally.
- [3] To use the condition in reverse logic (so-called "contact b logic" \overline{X}), add "N" (NOT) to the condition.
- [4] The input condition supports input port, output port and flag.
- [5] The operand 1, operand 2 and output fields can be specified indirectly.

(2) The output field, which follows the command, operand 1 and operand 2 fields, will specify the following action:



- [1] In the case of a control command relating to actuator operation, etc., the output will turn OFF the moment the execution of command is started, and turn ON when the execution is completed. In the case of a calculation operation command, etc., the output will turn ON if the result corresponds to a certain value, and turn OFF if not.
- [2] The output field supports output port and flag.




3.2 Extension Condition

Conditions can be combined in a complex manner.

AND extension


(Ladder diagram)



(SEL language)


Extension condition	Input condition	Command			Output
		Command	Operand 1	Operand 2	
	Condition 1				
A	Condition 2				
A	Condition 3	Command	Operand 1	Operand 2	

OR extension



Extension condition	Input condition	Command			Output
		Command	Operand 1	Operand 2	
	Condition 1				
O	Condition 2	Command	Operand 1	Operand 2	

AND extension and OR extension



Extension condition	Input condition	Command			Output
		Command	Operand 1	Operand 2	
	Condition 1				
A	Condition 2				
O	Condition 3	Command	Operand 1	Operand 2	



Chapter 4 Commands

1. List of SEL Language Command Codes by Function

Variables can be specified indirectly in the operand 1, operand 2 and output fields.

Symbols can be input in the condition, operand 1, operand 2 and output fields.

The input items in () under operand 1 and operand 2 are optional.

Once an “actuator control declaration” command is executed in a program, the command will remain valid as long as the program is running. To change the values (in operand 1, operand 2, etc.) already set by the “actuator control declaration” command, the necessary parts of the program must be set again. In other words, the values set by the last executed command will prevail.

The output field will be turned OFF when the command is executed. Once the execution is completed, the output field may be turned ON depending on the operation type condition in the output field. (The output field will remain OFF if the condition is not satisfied.)

Note: The output field of a comparison command CPXX (CPEQ, CPNE, CPGT, CPGE, CPLT or CPLE) will not be turned OFF when the command is executed.

1.1 List of Commands by Function

Operation type in the output field

CC: Command was executed successfully,

ZR: Operation result is zero, PE: Operation is complete,

CP: Command part has passed, TU: Time up

EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,

GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,

LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Category	Condition	Command	Operand 1	Operand 2	Output	Function	Page
Variable assignment	Optional	LET	Assignment variable	Assigned value	ZR	Assign	75
	Optional	TRAN	Copy-destination variable	Copy-source variable	ZR	Copy	75
	Optional	CLR	Start-of-clear variable	End-of-clear variable	ZR	Clear variable	76
Arithmetic operation	Optional	ADD	Augend variable	Addend	ZR	Add	77
	Optional	SUB	Minuend variable	Subtrahend	ZR	Subtract	77
	Optional	MULT	Multiplicand variable	Multiplier	ZR	Multiply	78
	Optional	DIV	Dividend variable	Divisor	ZR	Divide	78
	Optional	MOD	Remainder assignment variable	Divisor	ZR	Calculate remainder	79
Function operation	Optional	SIN	Sine assignment variable	Operand [radian]	ZR	Sine	80
	Optional	COS	Cosine assignment variable	Operand [radian]	ZR	Cosine	80
	Optional	TAN	Tangent assignment variable	Operand [radian]	ZR	Tangent	81
	Optional	ATN	Inverse-tangent assignment variable	Operand	ZR	Inverse tangent	81
	Optional	SQR	Root assignment variable	Operand	ZR	Root	82
Logical operation	Optional	AND	AND operand variable	Operand	ZR	Logical AND	83
	Optional	OR	OR operand variable	Operand	ZR	Logical OR	84
	Optional	EOR	Exclusive-OR operand variable	Operand	ZR	Logical exclusive-OR	85
Comparison	Optional	CPXX	Comparison variable	Comparison value	<u>EQ, NE,</u> <u>GT, GE,</u> <u>LT, LE</u>	Compare	86
Timer	Optional	TIMW	Wait time (sec)	Prohibited	TU	Wait	87
	Optional	TIMC	Program number	Prohibited	CP	Cancel waiting	88
	Optional	GTTM	Time assignment variable	Prohibited	CP	Get time	89
I/O, flag operation	Optional	BTXX	Start output, flag	(End output, flag)	CP	Output, flag [ON, OF, NT]	90
	Optional	BTPN	Output port, flag	Timer setting	CP	Output ON pulse	91
	Optional	BTPF	Output port, flag	Timer setting	CP	Output OFF pulse	92
	Optional	WTXX	I/O, flag	(Wait time)	TU	Wait for I/O, flag [ON, OF]	93
	Optional	IN	Head I/O, flag	End I/O, flag	CC	Input binary (32 bits max.)	94
	Optional	INB	Head I/O, flag	Conversion digits	CC	Input BCD (8 digits max.)	95
	Optional	OUT	Head output, flag	End I/O, flag	CC	Output binary (32 bits max.)	96
	Optional	OUTB	Head output, flag	Conversion digits	CC	Output BCD (8 digits max.)	97
	Optional	FMIO	Format type	Prohibited	CP	Set IN (B)/OUT (B) command format	98



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Category	Condition	Command	Operand 1	Operand 2	Output	Function	Page
Program control	Optional	GOTO	Jump-destination tag number	Prohibited	CP	Jump	101
	Prohibited	TAG	Declaration tag number	Prohibited	CP	Declare jump destination	101
	Optional	EXSR	Execution subroutine number	Prohibited	CP	Execute subroutine	102
	Prohibited	BGSR	Declaration subroutine number	Prohibited	CP	Start subroutine	102
	Prohibited	EDSR	Prohibited	Prohibited	CP	End subroutine	103
Task management	Optional	EXIT	Prohibited	Prohibited	CP	End program	104
	Optional	EXPG	Execution program number	(Execution program number)	CC	Start program	105
	Optional	ABPG	Stop program number	(Stop program number)	CC	Stop other program	106
	Optional	SSPG	Pause program number	(Pause program number)	CC	Pause program	107
	Optional	RSPG	Resumption program number	(Resumption program number)	CC	Resume program	108
Position operation	Optional	PGET	Axis number	Position number	CC	Assign position to variable 199	109
	Optional	PPUT	Axis number	Position number	CP	Assign value of variable 199	110
	Optional	PCLR	Start position number	End position number	CP	Clear position data	111
	Optional	PCPY	Copy-destination position number	Copy-source position number	CP	Copy position data	112
	Optional	PRED	Read axis pattern	Save-destination position number	CP	Read current axis position	113
	Optional	PRDQ	Axis number	Variable number	CP	Read current axis position (1 axis direct)	114
	Optional	PTST	Confirmation axis pattern	Confirmation position number	CC	Confirm position data	115
	Optional	PVEL	Speed [mm/sec]	Assignment-destination position number	CP	Assign position speed	116
	Optional	PACC	Acceleration [G]	Assignment-destination position number	CP	Assign position acceleration	117
	Optional	PDCL	Deceleration [G]	Assignment-destination position number	CP	Assign position deceleration	118
	Optional	PAXS	Axis-pattern assignment variable number	Position number	CP	Read axis pattern	119
	Optional	PSIZ	Size assignment variable number		CP	Confirm position size	120
	Optional	GVEL	Variable number	Position number	CP	Get speed data	121
	Optional	GACC	Variable number	Position number	CP	Get acceleration data	122
	Optional	GDCL	Variable number	Position number	CP	Get deceleration data	123
Actuator control declaration	Optional	VEL	Speed [mm/sec]	Prohibited	CP	Set speed	124
	Optional	OVRD	Speed ratio [%]	Prohibited	CP	Set speed coefficient	125
	Optional	ACC	Acceleration [G]	Prohibited	CP	Set acceleration	126
	Optional	DCL	Deceleration [G]	Prohibited	CP	Set deceleration	127
	Optional	SCRV	Ratio [%]	Prohibited	CP	Set sigmoid motion ratio	128
	Optional	OFST	Setting axis pattern	Offset value [mm]	CP	Set offset	129
	Optional	DEG	Division angle [deg]	Prohibited	CP	Set division angle	130
	Optional	BASE	Reference axis number	Prohibited	CP	Set reference axis	131
	Optional	GRP	Valid axis pattern	Prohibited	CP	Set group axes	132
	Optional	HOLD	(Input port to pause)	(HOLD type)	CP	Declare port to pause	133
	Optional	CANC	(Input port to abort)	(CANC type)	CP	Declare port to abort	134
	Optional	VLMX	Prohibited	Prohibited	CP	Specify VLMX speed	135
	Optional	DIS	Distance	Prohibited	CP	Set spline division distance	136
	Optional	POTP	0 or 1	Prohibited	CP	Set PATH output type	137
	Optional	PAPR	Distance	Speed	CP	Set PUSH command distance, speed	138
	Optional	QRTN	0 or 1	Prohibited	CP	Set quick-return mode	139



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Category	Condition	Command	Operand 1	Operand 2	Output	Function	Page
Actuator control command	Optional	SVXX	Operation axis pattern	Prohibited	PE	Servo [ON, OF]	140
	Optional	HOME	Home-return axis pattern	Prohibited	PE	Return to home	141
	Optional	MOVP	Destination position number	Prohibited	PE	Move to specified position	142
	Optional	MOVL	Destination position number	Prohibited	PE	Move to specified position via interpolation	143
	Optional	MVPI	Travel position number	Prohibited	PE	Move to relative position	144
	Optional	MVLI	Travel position number	Prohibited	PE	Move to relative position via interpolation	145
	Optional	PATH	Start position number	End position number	PE	Move along path	146
	Optional	JXWX	Axis operation pattern	Start I/O, flag	PE	Jog [FN, FF, BN, BF]	147
	Optional	STOP	Axis stop pattern	Prohibited	CP	Decelerate and stop axis	148
	Optional	PSPL	Start position number	End position number	PE	Move along spline	149
	Optional	PUSH	Target position number	Prohibited	PE	Move by push motion	150
	Optional	CIR2	Passing position 1 number	Passing position 2 number	PE	Move along circle 2 (arc interpolation)	152
	Optional	ARC2	Passing position number	End position number	PE	Move along arc 2 (arc interpolation)	153
	Optional	CIRS	Passing position 1 number	Passing position 2 number	PE	Move three-dimensionally along circle	154
	Optional	ARCS	Passing position number	Passing position number	PE	Move three-dimensionally along arc	155
	Optional	CHVL	Axis pattern	Speed	CP	Change speed	156
	Optional	ARCD	End position number	Center angle [deg]	PE	Move along arc via specification of end position and center angle	157
	Optional	ARCC	Center position number	Center angle [deg]	PE	Move along arc via specification of center position and center angle	158
	Optional	PBND	Axis pattern	Distance	CP	Set positioning band	159
	Optional	CIR	Passing position 1 number	Passing position 2 number	PE	Move along circle (CIR2 is recommended)	160
	Optional	ARC	Passing position number	End position number	PE	Move along arc (ARC2 is recommended)	161
	Refer to the page on palletizing for commands relating to arch motion.						
	Optional	ARCH	Position number	Position number	PE	Arch motion	211
	Optional	ACHZ	Axis number	Prohibited	CP	Declare arch-motion Z-axis	201
	Optional	ATRG	Position number	Position number	CP	Set arch trigger	202
	Optional	AEXT	(Position number)	Prohibited	CP	Set arch-motion composition	203
	Optional	OFAZ	Offset value	Prohibited	CP	Set arch-motion Z-axis offset	203
Structural IF	Optional	IFXX	Comparison variable	Comparison value	CP	Compare [EQ, NE, GT, GE, LT, LE]	162
	Optional	ISXX	Column number	Column number, character literal	CP	Compare strings	163
	Prohibited	ELSE	Prohibited	Prohibited	CP	Declare execution destination when IF command condition is not satisfied	164
	Prohibited	EDIF	Prohibited	Prohibited	CP	Declare end of IF	164
Structural DO	Optional	DWXX	Comparison variable	Comparison value	CP	Loop [EQ, NE, GT, GE, LT, LE]	165
	Optional	LEAV	Prohibited	Prohibited	CP	Pull out from DO	165
	Optional	ITER	Prohibited	Prohibited	CP	Repeat DO	166
	Prohibited	EDDO	Prohibited	Prohibited	CP	Declare end of DO	166
Multi-branching	Optional	SLCT	Prohibited	Prohibited	CP	Declare start of multi-branching	167
	Prohibited	WHXX	Comparison variable	Comparison value	CP	Branch value [EQ, NE, GT, GE, LT, LE]	168
	Prohibited	WSXX	Column number	Column number, character literal	CP	Branch character string [EQ, NE]	169
	Prohibited	OTHE	Prohibited	Prohibited	CP	Declare branching destination when condition is not satisfied	170
	Prohibited	EDSL	Prohibited	Prohibited	CP	Declare end of SLCT	170



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Category	Condition	Command	Operand 1	Operand 2	Output	Function	Page
System information acquisition	Optional	AXST	Variable number	Axis number	CP	Get axis status	171
	Optional	PGST	Variable number	Program number	CP	Get program status	172
	Optional	SYST	Variable number	Prohibited	CP	Get system status	173
Zone	Optional	WZNA	Zone number	Axis pattern	CP	Wait for zone ON, with AND	174
	Optional	WZNO	Zone number	Axis pattern	CP	Wait for zone ON, with OR	175
	Optional	WZFA	Zone number	Axis pattern	CP	Wait for zone OFF, with AND	176
	Optional	WZFO	Zone number	Axis pattern	CP	Wait for zone OFF, with OR	177
Communication	Optional	OPEN	Channel number	Prohibited	CP	Open channel	178
	Optional	CLOS	Channel number	Prohibited	CP	Close channel	178
	Optional	READ	Channel number	Column number	CC	Read from channel	179
	Optional	TMRD	Timer setting	Prohibited	CP	Set READ timeout value	180
	Optional	WRIT	Channel number	Column number	CP	Output to channel	181
	Optional	SCHA	Character code	Prohibited	CP	Set end character	182
String operation	Optional	SCPY	Column number	Column number, character literal	CC	Copy character string	183
	Optional	SCMP	Column number	Column number, character literal	EQ	Compare character strings	184
	Optional	SGET	Variable number	Column number, character literal	CP	Get character	185
	Optional	SPUT	Column number	Data	CP	Set character	186
	Optional	STR	Column number	Data	CC	Convert character string; decimal	187
	Optional	STRH	Column number	Data	CC	Convert character string; hexadecimal	188
	Optional	VAL	Variable number	Column number, character literal	CC	Convert character string data; decimal	189
	Optional	VALH	Variable number	Column number, character literal	CC	Convert character string data; hexadecimal	190
	Optional	SLEN	Character string length	Prohibited	CP	Set length	191



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Category	Condition	Command	Operand 1	Operand 2	Output	Function	Page
Palletizing-related	Optional	BGPA	Palletizing number	Prohibited	CP	Declare start of palletizing setting	192
	Prohibited	EDPA	Prohibited	Prohibited	CP	Declare end of palletizing setting	192
	Optional	PAPI	Count	Count	CP	Set palletizing counts	193
	Optional	PAPN	Pattern number	Prohibited	CP	Set palletizing pattern	193
	Optional	PASE	Axis number	Axis number	CP	Set palletizing axes	194
	Optional	PAPT	Pitch	Pitch	CP	Set palletizing pitches	194
	Optional	PAST	(Position number)	Prohibited	CP	Set palletizing reference point	195
	Optional	PAPS	Position number	Prohibited	CP	Set 3 palletizing points for teaching	196
	Optional	PSLI	Offset amount	(Count)	CP	Set zigzag	197
	Optional	PCHZ	(Axis number)	Prohibited	CP	Set palletizing Z-axis	198
	Optional	PTRG	Position number	Position number	CP	Set palletizing arch triggers	199
	Optional	PEXT	(Position number)	Prohibited	CP	Set palletizing composition	200
	Optional	OFPZ	Offset amount	Prohibited	CP	Set palletizing Z-axis offset	200
	Optional	ACHZ	Axis number	Prohibited	CP	Declare arch-motion Z-axis	201
	Optional	ATRG	Position number	Position number	CP	Set arch triggers	202
	Optional	AEXT	(Position number)	Prohibited	CP	Set arch-motion composition	203
	Optional	OFAZ	Offset amount	Prohibited	CP	Set arch-motion Z-axis offset	203
	Optional	PTNG	Palletizing number	Variable number	CP	Get palletizing position number	204
	Optional	PINC	Palletizing number	Prohibited	CC	Increment palletizing position number by 1	204
	Optional	PDEC	Palletizing number	Prohibited	CC	Decrement palletizing position number by 1	205
	Optional	PSET	Palletizing number	Data	CC	Set palletizing position number directly	205
	Optional	PARG	Palletizing number	Axis number	CP	Get palletizing angle	206
	Optional	PAPG	Palletizing number	Position number	CP	Get palletizing calculation data	206
	Optional	PMVP	Palletizing number	(Position number)	PE	Move to palletizing points via PTP	207
	Optional	PMVL	Palletizing number	(Position number)	PE	Move to palletizing points via interpolation	208
	Optional	PACH	Palletizing number	Position number	PE	Palletizing-point arch motion	209
	Optional	ARCH	Position number	Position number	PE	Arch motion	211
Building of pseudo-ladder task	Extension conditions LD (LOAD), A (AND), O (OR), AB (AND BLOCK) and OB (OR BLOCK) are supported.						
	Optional	CHPR	0 or 1	Prohibited	CP	Change task level	213
	Prohibited	TPCD	0 or 1	Prohibited	CP	Specify processing to be performed when input condition is not specified	213
	Prohibited	TSLP	Time	Prohibited	CP	Task sleep	214
	Optional	OUTR	Output, flag number	Prohibited	CP	Output relay for ladder	See 236
	Optional	TIMR	Local flag number	Timer setting	CP	Timer relay for ladder	See 236



1.2 List of Commands in Alphabetical Order

Operation type in the output field

CC: Command was executed successfully

ZR: Operation result is zero

PE: Operation is complete

CP: Command part has passed

TU: Time up

EQ: Operand 1 = Operand 2

NE: Operand 1 ≠ Operand 2

GT: Operand 1 > Operand 2

GE: Operand 1 ≥ Operand 2

LT: Operand 1 < Operand 2

LE: Operand 1 ≤ Operand 2

Command	Page	Condition	Operation1	Operation2	Output	Function
A						
ABPG	106	Optional	Stop program number	(Stop program number)	CC	Stop other program
ACC	126	Optional	Acceleration	Prohibited	CP	Set acceleration
ACHZ	201	Optional	Axis number	Prohibited	CP	Declare arch-motion Z-axis
ADD	77	Optional	Augend variable	Addend	ZR	Add
AEXT	203	Optional	(Position number)	Prohibited	CP	Set arch-motion composition
AND	83	Optional	AND operand variable	Operand	ZR	Logical AND
ARC	161	Optional	Passing position number	End position number	PE	Move along arc
ARC2	153	Optional	Passing position number	End position number	PE	Move along arc 2
ARCC	158	Optional	Center position number	Center angle	PE	Move along arc via specification of center position and center angle
ARCD	157	Optional	End position number	Center angle	PE	Move along arc via specification of end position and center angle
ARCH	211	Optional	Position number	Position number	PE	Arch motion
ARCS	155	Optional	Passing position number	Passing position number	PE	Move three-dimensionally along arc
ATN	81	Optional	Inverse-tangent assignment variable	Operand	ZR	Inverse tangent
ATRG	202	Optional	Position number	Position number	CP	Set arch trigger
AXST	171	Optional	Variable number	Axis number	CP	Get axis status
B						
BASE	131	Optional	Reference axis number	Prohibited	CP	Set reference axis
BGPA	192	Optional	Palletizing number	Prohibited	CP	Declare start of palletizing setting
BGSR	102	Prohibited	Declaration subroutine number	Prohibited	CP	Start subroutine
BTPF	92	Optional	Output port, flag	Timer setting	CP	Output OFF pulse
BTPN	91	Optional	Output port, flag	Timer setting	CP	Output ON pulse
BTXX	90	Optional	Start output, flag	(End output, flag)	CP	Output, flag [ON, OF, NT]
C						
CANC	134	Optional	(Input port to abort)	(CANC type)	CP	Declare port to abort
CHPR	213	Optional	0 or 1	Prohibited	CP	Change task level
CHVL	156	Optional	Axis pattern	Speed	CP	Change speed
CIR	160	Optional	Passing position 1 number	Passing position 2 number	PE	Move along circle
CIR2	152	Optional	Passing position 1 number	Passing position 2 number	PE	Move along circle 2
CIRS	154	Optional	Passing position 1 number	Passing position 2 number	PE	Move three-dimensionally along circle
CLOS	178	Optional	Channel number	Prohibited	CP	Close channel
CLR	76	Optional	Start-of-clear variable	End-of-clear variable	ZR	Clear variable
COS	80	Optional	Cosine assignment variable	Operand	ZR	Cosine
CPXX	86	Optional	Comparison variable	Comparison value		Compare
D						
DCL	127	Optional	Deceleration	Prohibited	CP	Set deceleration
DEG	130	Optional	Division angle	Prohibited	CP	Set division angle
DIS	136	Optional	Distance	Prohibited	CP	Set spline division distance
DIV	78	Optional	Dividend variable	Divisor	ZR	Divide
DWXX	165	Optional	Comparison variable	Comparison value	CP	Loop [EQ, NE, GT, GE, LT, LE]



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Command	Page	Condition	Operation1	Operation2	Output	Function
E						
EDDO	166	Prohibited	Prohibited	Prohibited	CP	Declare end of DO
EDIF	164	Prohibited	Prohibited	Prohibited	CP	Declare end of IF
EDPA	192	Prohibited	Prohibited	Prohibited	CP	Declare end of palletizing setting
EDSL	170	Prohibited	Prohibited	Prohibited	CP	Declare end of SLCT
EDSR	103	Prohibited	Prohibited	Prohibited	CP	End subroutine
ELSE	164	Prohibited	Prohibited	Prohibited	CP	Declare execution destination when IF command condition is not satisfied
EOR	85	Optional	Exclusive-OR operand variable	Operand	ZR	Logical exclusive-OR
EXIT	104	Optional	Prohibited	Prohibited	CP	End program
EXPG	105	Optional	Execution program number	(Execution program number)	CC	Start program
EXSR	102	Optional	Execution subroutine number	Prohibited	CP	Execute subroutine
F						
FMIO	98	Optional	Format type	Prohibited	CP	Set IN (B)/OUT (B) command format
G						
GACC	122	Optional	Variable number	Position number	CP	Get acceleration data
GDCL	123	Optional	Variable number	Position number	CP	Get deceleration data
GOTO	101	Optional	Jump-destination tag number	Prohibited	CP	Jump
GRP	132	Optional	Valid axis pattern	Prohibited	CP	Set group axes
GTTM	89	Optional	Time assignment variable	Prohibited	CP	Get time
GVEL	71	Optional	Variable number	Position number	CP	Get speed data
H						
HOLD	133	Optional	(Input port to pause)	(HOLD type)	CP	Declare port to pause
HOME	141	Optional	Home-return axis pattern	Prohibited	PE	Return to home
I						
IFXX	162	Optional	Comparison variable	Comparison value	CP	Compare [EQ, NE, GT, GE, LT, LE]
INB	95	Optional	Head I/O, flag	Conversion digits	CC	Input BCD (8 digits max.)
IN	94	Optional	Head I/O, flag	End I/O, flag	CC	Input binary (32 bits max.)
ISXX	163	Optional	Column number	Column number, character literal	CP	Compare strings
ITER	166	Optional	Prohibited	Prohibited	CP	Repeat DO
J						
JXWX	147	Optional	Axis operation pattern	Start I/O, flag	PE	Jog [FN, FF, BN, BF]
L						
LEAV	165	Optional	Prohibited	Prohibited	CP	Pull out from DO
LET	75	Optional	Assignment variable	Assigned value	ZR	Assign
M						
MOD	79	Optional	Remainder assignment variable	Divisor	ZR	Calculate remainder
MOVL	143	Optional	Destination position number	Prohibited	PE	Move to specified position via interpolation
MOVVP	142	Optional	Destination position number	Prohibited	PE	Move to specified position
MULT	78	Optional	Multiplicand variable	Multiplier	ZR	Multiply
MVLI	145	Optional	Travel position number	Prohibited	PE	Move to relative position via interpolation
MVPI	144	Optional	Travel position number	Prohibited	PE	Move to relative position



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Command	Page	Condition	Operation1	Operation2	Output	Function
O						
OFAZ	203	Optional	Offset amount	Prohibited	CP	Set arch-motion Z-axis offset
OFMZ	200	Optional	Offset amount	Prohibited	CP	Set palletizing Z-axis offset
OFST	120	Optional	Setting axis pattern	Offset value	CP	Set offset
OPEN	178	Optional	Channel number	Prohibited	CP	Open channel
OR	84	Optional	OR operand variable	Operand	ZR	Logical OR
OTHE	170	Prohibited	Prohibited	Prohibited	CP	Declare branching destination when condition is not satisfied
OUT	96	Optional	Head output, flag	End I/O, flag	CC	Output binary (32 bits max.)
OUTB	97	Optional	Head output, flag	Conversion digits	CC	Output BCD (8 digits max.)
OUTR	236	Optional	Output, flag number	Prohibited	CP	Output relay for ladder
OVRD	125	Optional	Speed ratio	Prohibited	CP	Set speed ratio
P						
PACC	117	Optional	Acceleration	Assignment-destination position number	CP	Assign position acceleration
PACH	209	Optional	Palletizing number	Position number	PE	Palletizing-point arch motion
PAPG	206	Optional	Palletizing number	Position number	CP	Get palletizing calculation data
PAPI	193	Optional	Count	Count	CP	Set palletizing counts
PAPN	193	Optional	Pattern number	Prohibited	CP	Set palletizing pattern
PAPR	138	Optional	Distance	Prohibited	CP	Set PUSH command distance, speed
PAPS	196	Optional	Position number	Prohibited	CP	Set 3 palletizing points for teaching
PAPT	194	Optional	Pitch	Pitch	CP	Set palletizing pitches
PARG	206	Optional	Palletizing number	Axis number	CP	Get palletizing angle
PASE	194	Optional	Axis number	Axis number	CP	Set palletizing axes
PAST	195	Optional	(Position number)	Prohibited	CP	Set palletizing reference point
PATH	146	Optional	Start position number	End position number	PE	Move along path
PAXS	119	Optional	Axis-pattern assignment variable number	Position number	CP	Read axis pattern
PBND	159	Optional	Axis pattern	Distance	CP	Set positioning band
PCHZ	198	Optional	(Axis number)	Prohibited	CP	Set palletizing Z-axis
PCLR	111	Optional	Start position number	End position number	CP	Clear position data
PCPY	112	Optional	Copy-destination position number	Copy-source position number	CP	Copy position data
PDCL	118	Optional	Deceleration	Assignment-destination position number	CP	Assign position deceleration
PDEC	205	Optional	Palletizing number	Prohibited	CC	Decrement palletizing position number by 1
PEXT	200	Optional	(Position number)	Prohibited	CP	Set palletizing composition
PGET	109	Optional	Axis number	Position number	CC	Assign position to variable 199
PGST	172	Optional	Variable number	Program number	CP	Get program status
PINC	204	Optional	Palletizing number	Prohibited	CC	Increment palletizing position number by 1
PMVL	208	Optional	Palletizing number	(Position number)	PE	Move to palletizing points via interpolation
PMVP	207	Optional	Palletizing number	(Position number)	PE	Move to palletizing points via PTP
POTP	137	Optional	0 or 1	Prohibited	CP	Set PATH output type
PPUT	110	Optional	Axis number	Position number	CP	Assign value of variable 199
PRDQ	114	Optional	Axis number	Variable number	CP	Read current axis position (1 axis direct)
PRED	113	Optional	Read axis pattern	Save-destination position number	CP	Read current axis position
PSET	205	Optional	Palletizing number	Data	CC	Set palletizing position number directly
PSIZ	120	Optional	Size assignment variable number		CP	Confirm position size
PSLI	197	Optional	Offset amount	(Count)	CP	Set zigzag
PSPL	149	Optional	Start position number	End position number	PE	Move along spline
PTNG	204	Optional	Palletizing number	Variable number	CP	Get palletizing position number



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Command	Page	Condition	Operation1	Operation2	Output	Function
P						
PTRG	199	Optional	Position number	Position number	CP	Set palletizing arch triggers
PTST	115	Optional	Confirmation axis pattern	Confirmation position number	CP	Confirm position data
PUSH	150	Optional	Target position number	Prohibited	PE	Move by push motion
PVEL	116	Optional	Speed	Assignment-destination position number	CP	Assign position speed
Q						
QRTN	139	Optional	0 or 1	Prohibited	CP	Set quick-return mode
R						
READ	179	Optional	Channel number	Column number	CC	Read from channel
RSPG	108	Optional	Resumption program number	(Resumption program number)	CC	Resume program
S						
SCHA	182	Optional	Character code	Prohibited	CP	Set end character
SCMP	184	Optional	Column number	Column number, character literal	EQ	Compare character strings
SCPY	183	Optional	Column number	Column number, character literal	CC	Copy character string
SCRV	128	Optional	Ratio	Prohibited	CP	Set sigmoid motion ratio
SGET	185	Optional	Variable number	Column number, character literal	CP	Get character
SIN	80	Optional	Sine assignment variable	Operand	ZR	Sine
SLCT	167	Optional	Prohibited	Prohibited	CP	Declare start of multi-branching
SLEN	191	Optional	Character string length	Prohibited	CP	Set length
SPUT	186	Optional	Column number	Data	CP	Set character
SQR	82	Optional	Root assignment variable	Operand	ZR	Root
SSPG	107	Optional	Pause program number	(Pause program number)	CC	Pause program
STOP	148	Optional	Axis stop pattern	Prohibited	CP	Decelerate and stop axis
STR	187	Optional	Column number	Data	CC	Convert character string; decimal
STRH	188	Optional	Column number	Data	CC	Convert character string; hexadecimal
SUB	77	Optional	Minuend variable	Subtrahend	ZR	Subtract
SVXX	140	Optional	Operation axis pattern	Prohibited	PE	Servo [ON, OF]
SYST	173	Optional	Variable number	Prohibited	CP	Get system status



Operation type in the output field

CC: Command was executed successfully, ZR: Operation result is zero,
 PE: Operation is complete, CP: Command part has passed, TU: Time up
 EQ: Operand 1 = Operand 2, NE: Operand 1 ≠ Operand 2,
 GT: Operand 1 > Operand 2, GE: Operand 1 ≥ Operand 2,
 LT: Operand 1 < Operand 2, LE: Operand 1 ≤ Operand 2

Command	Page	Condition	Operation1	Operation2	Output	Function
T						
TAG	101	Prohibited	Declaration tag number	Prohibited	CP	Declare jump destination
TAN	81	Optional	Tangent assignment variable	Operand	ZR	Tangent
TIMC	88	Optional	Program number	Prohibited	CP	Cancel waiting
TIMR	236	Optional	Local flag number	Timer setting	CP	Timer relay for ladder
TIMW	87	Optional	Wait time	Prohibited	TU	Wait
TMRD	180	Optional	Timer setting	Prohibited	CP	Set READ timeout value
TPCD	213	Prohibited	0 or 1	Prohibited	CP	Specify processing to be performed when input condition is not specified
TRAN	75	Optional	Copy-destination variable	Copy-source variable	ZR	Copy
TSLP	214	Prohibited	Time	Prohibited	CP	Task sleep
V						
VAL	189	Optional	Variable number	Column number, character literal	CC	Convert character string data; decimal
VALH	190	Optional	Variable number	Column number, character literal	CC	Convert character string data; hexadecimal
VEL	124	Optional	Speed	Prohibited	CP	Set speed
VLMX	135	Optional	Prohibited	Prohibited	CP	Specify VLMX speed
W						
WHXX	168	Prohibited	Comparison variable	Comparison value	CP	Branch value [EQ, NE, GT, GE, LT, LE]
WRIT	181	Optional	Channel number	Column number	CC	Output to channel
WSXX	169	Prohibited	Column number	Column number, character literal	CP	Branch character string [EQ, NE]
WTXX	93	Optional	I/O, flag	(Wait time)	TU	Wait for I/O, flag [ON, OF]
WZFA	176	Optional	Zone number	Axis pattern	CP	Wait for zone OFF, with AND
WZFO	177	Optional	Zone number	Axis pattern	CP	Wait for zone OFF, with OR
WZNA	174	Optional	Zone number	Axis pattern	CP	Wait for zone ON, with AND
WZNO	175	Optional	Zone number	Axis pattern	CP	Wait for zone ON, with OR



2. Explanation of Commands

1. Commands

1-1 Variable Assignment

● LET (Assign)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	LET	Variable number	Data	ZR

[Function] Assign the value specified in operand 2 to the variable specified in operand 1.
The output will turn ON when 0 is assigned to the variable specified in operand 1.

[Example 1] LET 1 10 Assign 10 to variable 1.

[Example 2] LET 1 2 Assign 2 to variable 1.
 LET 3 10 Assign 10 to variable 3.
 LET *1 *3 Assign the content of variable 3 (10) to the
 variable of the content of variable 1 (variable 2).

● TRAN (Copy)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	TRAN	Variable number	Variable number	ZR

[Function] Assign the content of the variable specified in operand 2 to the variable specified in operand 1.
The output will turn ON when 0 is assigned to the variable specified in operand 1.

[Example 1] TRAN 1 2 Assign the content of variable 2 to variable 1.

 LET 1 *2 A LET command of the same effect as the above
 operation

[Example 2] LET 1 2 Assign 2 to variable 1.
 LET 2 3 Assign 3 to variable 2.
 LET 3 4 Assign 4 to variable 3.
 LET 4 10 Assign 10 to variable 4.
 TRAN *1 *3 Assign the content of variable 3 (which is variable
 4, or 10) to the variable of the content of variable 1
 (variable 2).

The variables change as follows:

1	2	3	4		1	2	3	4
2	3	4	10	→	2	10	4	10



● CLR (Clear variable)

F condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CLR	Variable number	Variable number	ZR

[Function] Clear the variables from the one specified in operand 1 through the other specified in operand 2.

The contents of the variables that have been cleared become 0.

The output will turn ON when 0 is assigned to the variable specified in operand 1.

[Example 1] CLR 1 5 Clear variables 1 through 5.

[Example 2] LET 1 10 Assign 10 to variable 1.
LET 2 20 Assign 20 to variable 2.
CLR *1 *2 Clear the variables from the content of variable 1 (variable 10) through the content of variable 2 (variable 20).

1-2 Arithmetic Operation

- ADD (Add)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ADD	Variable number	Data	ZR

[Function] Add the content of the variable specified in operand 1 and the value specified in operand 2, and assign the result to the variable specified in operand 1.
The output will turn ON when the operation result becomes 0.

[Example 1]	LET	1	3	Assign 3 to variable 1.
	ADD	1	2	Add 2 to the content of variable 1 (3). 5 (3+2=5) will be stored in variable 1.

[Example 2]	LET	1	2	Assign 2 to variable 1.
	LET	2	3	Assign 3 to variable 2.
	LET	3	2	Assign 2 to variable 3.
	ADD	*1	*3	Add the content of variable 3 (2) to the content of variable 1 (variable 2). 5 (3+2=5) will be stored in variable 2.

- SUB (Subtract)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SUB	Variable number	Data	ZR

[Function] Subtract the value specified in operand 2 from the content of the variable specified in operand 1, and assign the result to the variable specified in operand 1. The output will turn ON when the operation result becomes 0.

[Example 1]	LET	1	3	Assign 3 to variable 1.
	SUB	1	2	Subtract 2 from the content of variable 1 (3). 1 (3-2=1) will be stored in variable 1.

[Example 2]	LET	1	2	Assign 2 to variable 1.
	LET	2	3	Assign 3 to variable 2.
	LET	3	2	Assign 2 to variable 3.
	SUB	*1	*3	Subtract the content of variable 3 (2) from the content of variable 1 (variable 2). 1 (3-2=1) will be stored in variable 2.



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MULT	Variable number	Data	ZR

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	DIV	Variable number	Data	ZR

[Example 2]	LET	1	2	Assign 2 to variable 1.
	LET	2	6	Assign 6 to variable 2.
	LET	3	2	Assign 2 to variable 3.
	DIV	*1	*3	Divide the content of variable 1 (variable 2) by the content of variable 3 (2). 3 (6÷2=3) will be stored in variable 2.



● MOD (Remainder of division)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MOD	Variable number	Data	ZR

[Function] Assign, to the variable specified in 1, the remainder obtained by dividing the content of the variable specified in operand 1 by the value specified in operand 2.
The output will turn ON when the operation result becomes 0.

(Note) A MOD command is used with integer variables.

[Example 1]

LET	1	7	Assign 7 to variable 1.
MOD	1	3	Obtain the remainder of dividing the content of variable 1 (7) by 3. 1 ($7 \div 3 = 2$ with a remainder of 1) will be assigned to variable 1.

[Example 2]

LET	1	2	Assign 2 to variable 1.
LET	2	7	Assign 7 to variable 2.
LET	3	3	Assign 3 to variable 3.
MOD	*1	*3	Obtain the remainder of dividing the content of variable 1 (variable 2) by the content of variable 3 (3). 1 ($7 \div 3 = 2$ with a remainder of 1) will be assigned to variable 2.



1-3 Function Operation

● SIN (Sine operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SIN	Variable number	Data	ZR

[Function] Assign the sine of the data specified in operand 2 to the variable specified in operand 1.
 The output will turn ON when the operation result becomes 0.
 The setting in operand 1 must be a real variable in a range of 100 to 199, 1100 to 1199, 300 to 399 or 1300 to 1399.
 The unit of data in operand 2 is radian.

(Note 1) $\text{Radian} = \text{Angle} \times \pi \div 180$

[Example 1] SIN 100 0.523599 Assign the sine of 0.523599 (0.5) to variable 100.

[Example 2] LET 1 100 Assign 100 to variable 1.
 LET 101 30 $30 \times \pi \div 180$ (radian)
 MULT 101 3.141592 (30° will be converted to radian and assigned to
 DIV 101 180 variable 101.)
 SIN *1 *101 Assign the sine of the content of variable 101 (0.5) to
 the content of variable 1 (variable 100).

● COS (Cosine operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	COS	Variable number	Data	ZR

[Function] Assign the cosine of the data specified in operand 2 to the variable specified in operand 1.
 The output will turn ON when the operation result becomes 0.
 The setting in operand 1 must be a real variable in a range of 100 to 199, 1100 to 1199, 300 to 399 or 1300 to 1399.
 The unit of data in operand 2 is radian.

(Note 1) $\text{Radian} = \text{Angle} \times \pi \div 180$

[Example 1] COS 100 1.047197 Assign the cosine of 1.047197 (0.5) to variable 100.

[Example 2] LET 1 100 Assign 100 to variable 1.
 LET 101 60 $60 \times \pi \div 180$ (radian)
 MULT 101 3.141592 (60° will be converted to radian and assigned to
 DIV 101 180 variable 101.)
 COS *1 *101 Assign the cosine of the content of variable 101 (0.5)
 to the content of variable 1 (variable 100).



● TAN (Tangent operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	TAN	Variable number	Data	ZR

[Function] Assign the tangent of the data specified in operand 2 to the variable specified in operand 1.
The output will turn ON when the operation result becomes 0.
The setting in operand 1 must be a real variable in a range of 100 to 199, 1100 to 1199, 300 to 399 or 1300 to 1399.
The unit of data in operand 2 is radian.

(Note 1) $\text{Radian} = \text{Angle} \times \pi \div 180$

[Example 1] TAN 100 0.785398 Assign the tangent of 0.785398 (1) to variable 100.

[Example 2] LET 1 100 Assign 100 to variable 1.
 LET 101 45 $45 \times \pi \div 180$ (radian)
 MULT 101 3.141592 (45° will be converted to radian and assigned to
 DIV 101 180 variable 101.)
 TAN *1 *101 Assign the tangent of the content of variable 101 (1)
 to the content of variable 1 (variable 100).

● ATN (Inverse-tangent operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ATN	Variable number	Data	ZR

[Function] Assign the inverse tangent of the data specified in operand 2 to the variable specified in operand 1.
The output will turn ON when the operation result becomes 0.
The setting in operand 1 must be a real variable in a range of 100 to 199, 1100 to 1199, 300 to 399 or 1300 to 1399.
The unit of inverse tangent is radian.

(Note 1) $\text{Radian} = \text{Angle} \times \pi \div 180$

[Example 1] ATN 100 1 Assign the inverse tangent of 1 (0.785398) to variable 100.

[Example 2] LET 1 100 Assign 100 to variable 1.
 LET 101 1 Assign 1 to variable 101.
 ATN *1 *101 Assign the inverse tangent of the content of variable 101 (0.785398) to the content of variable 1 (variable 100).



● SQR (Root operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SQR	Variable number	Data	ZR

[Function] Assign the root of the data specified in operand 2 to the variable specified in operand 1.
The output will turn ON when the operation result becomes 0.

[Example 1] SQR 1 4 Assign the root of 4 (2) to variable 1.

[Example 2] LET 1 10 Assign 10 to variable 1.
 LET 2 4 Assign 4 to variable 2.
 SQR *1 *2 Assign the root of the content of variable 2 (4) to the
 content of variable 1 (variable 10).

- AND (Logical AND)

[Function] Assign the logical AND operation result of the content of the variable specified in operand 1 and the value specified in operand 2, to the variable specified in operand 1.
The output will turn ON when the operation result becomes 0.

[Example 2]	LET	1	2	Assign 2 to variable 1.
	LET	2	204	Assign 204 to variable 2.
	LET	3	170	Assign 170 to variable 3.
	AND	*1	*3	Assign the logical AND operation result (136) of the content of variable 1 (which is variable 2, or 204) and the content of variable 3 (170), to the content of variable 1 (variable 2).

$$\begin{array}{r} 204 \\ \text{AND } 170 \\ \hline 136 \end{array} \qquad \begin{array}{r} 11001100 \\ \text{AND } 10101010 \\ \hline 10001000 \end{array}$$



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OR	Variable number	Data	ZR

[Example 1]	LET	1	204	Assign 204 to variable 1.
	OR	1	170	Assign the logical OR operation result (238) of the content of variable 1 (204) and 170, to variable 1.

Decimal	Binary
204	11001100
OR 170	OR 10101010
<u>238</u>	<u>11101110</u>



● EOR (Logical exclusive-OR)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	EOR	Variable number	Data	ZR

[Function] Assign the logical exclusive-OR operation result of the content of the variable specified in operand 1 and the value specified in operand 2, to the variable specified in operand 1. The output will turn ON when the operation result becomes 0.

[Example 1] LET 1 204 Assign 204 to variable 1.
 EOR 1 170 Assign the logical exclusive-OR operation result (102) of the content of variable 1 (204) and 170, to variable 1.

[Example 2] LET 1 2 Assign 2 to variable 1.
 LET 2 204 Assign 204 to variable 2.
 LET 3 170 Assign 170 to variable 3.
 EOR *1 *3 Assign the logical exclusive-OR operation result (102) of the content of variable 1 (which is variable 2, or 204) and the content of variable 3 (170), to the content of variable 1 (variable 2).

Decimal	Binary
204	11001100
EOR 170	EOR 10101010
102	01100110



1-5 Comparison Operation

● CPXX (Compare)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)	
		Command, declaration	Operand 1	Operand 2		
Optional	Optional	CPXX	Variable number	Data	<u>EQ</u> <u>GT</u> <u>LT</u>	<u>NE</u> <u>GE</u> <u>LE</u>

[Function] The output will be turned ON if the comparison result of the content of the variable specified in operand 1 and the value specified in operand 2 satisfies the condition.
The value in the variable does not change.
The output will be turned OFF if the condition is not satisfied.

CPXX			
EQ	Operand 1 =	Operand 2
NE	Operand 1 ≠	Operand 2
GT	Operand 1 >	Operand 2
GE	Operand 1 ≥	Operand 2
LT	Operand 1 <	Operand 2
LE	Operand 1 ≤	Operand 2

[Example 1]

	LET	1	10		Assign 10 to variable 1.
	CPEQ	1	10	600	Turn ON flag 600 if the content of variable 1 is 10.
600	ADD	2	1		Add 1 to variable 2 if flag 600 is ON.

[Example 2]

	LET	1	2		Assign 2 to variable 1.
	LET	2	10		Assign 10 to variable 2.
	LET	3	10		Assign 10 to variable 3.
	CPEQ	*1	*3	310	Turn ON output 310 if the content of variable 1 (variable 2) is equal to the content of variable 3.



1-6 Timer

● TIMW (Timer)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	TIMW	Time	Prohibited	TU

[Function] Stop the program and wait for the time specified in operand 1.
The setting range is 0.01 to 99, and the unit is second.
The output will turn ON when the specified time has elapsed and the program proceeds to the next step.

[Example 1] TIMW 1.5 Wait for 1.5 seconds.

[Example 2] LET 1 10 Assign 10 to variable 1.
 TIMW *1 Wait for the content of variable 1 (10 seconds).



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	TIMC	Program number	Prohibited	CP

(Note) Timers in TIMW, WTON, WTOF and READ commands can be cancelled. In the case of WTON, WTOF and READ commands, even if timeout is not specified it is assumed that an unlimited timer has been specified and the wait time will be cancelled.

[Example 2]	LET	1	10	Assign 10 to variable 1.
	TIMC	*1		Cancel the wait time in the content of variable 1 (program 10).

[Example 3]	Program 1	Program 10	
	:	:	
	:	WTON 8 20	Program 10 waits for input 8 for 20 seconds.
	:	(Wait for input 8)	
	TIMC	10 (Wait for input 8)	Cancel the wait time in program 10.
	:	:	

97



● GTTM (Get time)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GTTM	Variable number	Prohibited	CP

[Function] Read system time to the variable specified in operand 1. The time is specified in units of 10 milliseconds.

The time obtained here has no base number. Therefore, this command is called twice and the difference will be used to calculate the elapsed time.

[Example 1]

GTTM	1		Read the reference time to variable 1.
ADD	1	500	Set the ending time to 5 seconds later.
GTTM	2		Read the current system time to variable 2.
DWLE	2	*1	Proceed to the step next to EDDO when 5 seconds elapsed.
:			The above process will be repeated for 5 seconds.
:			
GTTM	2		Read the current system time to variable 2.
EDDO			

[Example 2]

LET	1	5	Assign 5 to variable 1.
GTTM	*1		Store the current system time in the content of variable 1 (variable 5).



1-7 I/O, Flag Operation

● BTXX (Output port, flag operation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	BTXX	Output, flag	(Output, flag)	CP

[Function] Reverse the ON/OFF status of the output ports or flags from the one specified in operand 1 through the other specified in operand 2.

BTXX			
	ON	Switch the status to ON.
	OF	Switch the status to OFF.
	NT	Reverse the status.


[Example 1]	BTON	316		Turn ON output port 316.
[Example 2]	BTOF	316	323	Turn OFF output ports 316 through 323.
[Example 3]	LET	1	600	Assign 600 to variable 1.
	BTNT	*1		Reverse the content of variable 1 (flag 600).
[Example 4]	LET	1	600	Assign 600 to variable 1.
	LET	2	607	Assign 607 to variable 2.
	BTON	*1	*2	Turn ON the flags from the content of variable 1 (flag 600) through the content of variable 2 (flag 607).



● BTPN (Output ON pulse)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	BTPN	Output port, flag	Timer setting	CP

[Function] Turn ON the specified output port or flag for the specified time.
When this command is executed, the output port or flag specified in operand 1 will be turned ON and then the program will proceed to the next step. The output port or flag will be turned OFF automatically upon elapse of the timer setting specified in operand 2.
The timer is set in a range from 0.01 to 99.00 seconds (including up to two decimal places).



The output port or flag turns ON here, after which the program will proceed to the next step.

- (Note 1) If this command is executed with respect to an output port or flag already ON, the output port or flag will be turned OFF upon elapse of the timer setting.
- (Note 2) If the program ends after the command has been executed but before the timer is up, the output port or flag will not be turned OFF.
- (Note 3) This command will not be cancelled by a TIMC command.
- (Note 4) A maximum of 16 timers, including BTPN and BTPF, can be operated simultaneously in a single program. (There is no limitation as to how many times these timers can be used in a single program.)


[Example] BTPN 316 1 Turn ON output port 316 for 1 second.
 BTPN 600 10 Turn ON flag 600 for 10 seconds.



● BTPF (Output OFF pulse)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	BTPF	Output port, flag	Timer setting	CP

[Function] Turn OFF the specified output port or flag for the specified time.
When this command is executed, the output port or flag specified in operand 1 will be turned OFF and then the program will proceed to the next step. The output port or flag will be turned ON automatically upon elapse of the timer setting specified in operand 2.
The timer is set in a range from 0.01 to 99.00 seconds (including up to two decimal places).



- (Note 1) If this command is executed with respect to an output port or flag already OFF, the output port or flag will be turned ON upon elapse of the timer setting.
- (Note 2) If the program ends after the command has been executed but before the timer is up, the output port or flag will not be turned ON.
- (Note 3) This command will not be cancelled by a TIMC command.
- (Note 4) A maximum of 16 timers, including BTPN and BTPF, can be operated simultaneously in a single program. (There is no limitation as to how many times these timers can be used in a single program.)

[Example]

BTPF	316	1	Turn OFF output port 316 for 1 second.
BTPF	600	10	Turn OFF flag 600 for 10 seconds.



● WTXX (Wait for I/O port, flag)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WTXX	I/O, flag	(Time)	TU

[Function] Wait for the I/O port or flag specified in operand 1 to turn ON/OFF.
The program can be aborted after the specified time by setting the time in operand 2.
The setting range is 0.01 to 99 seconds.
The output will turn ON upon elapse of the specified time (only when operand 2 is specified).
Note) A local flag cannot be entered in operand 1.


WTXX
└── ON Wait for the applicable I/O port or flag to turn ON.
└── OF Wait for the applicable I/O port or flag to turn OFF.

[Example 1]	WTON	16		Wait for input port 16 to turn ON.
[Example 2]	WTOF	324	10	Wait for 10 seconds for output port 324 to turn OFF.
[Example 3]	LET	1	600	Assign 600 to variable 1.
	WTON	*1		Wait for the content of variable 1 (flag 600) to turn ON.
[Example 4]	LET	1	18	Assign 18 to variable 1.
	LET	2	5	Assign 5 to variable 2.
	WTOF	*1	*2	Wait for the content of variable 2 (5 seconds) for the content of variable 1 (input port 18) to turn OFF.

- IN (Read I/O, flag as binary)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	IN	I/O, flag	I/O, flag	CC

[Function] Read the I/O ports or flags from the one specified in operand 1 through the other specified in operand 2, to variable 99 as a binary.



(Note 1) A maximum of 32 bits can be input.

(Note 2) When 32 bits have been input and the most significant bit is ON, the value read to variable 99 will be treated as a negative value.

(Note 3) The read data format can be changed using a FMIO command (refer to the section on FMIO command).

[Example 1]	IN	16	23	Read input ports 16 through 23, to variable 99 as a binary.
-------------	----	----	----	---


[Example 2]	LET	1	16	Assign 16 to variable 1.
	LET	2	23	Assign 23 to variable 2.
	IN	*1	*2	Read the input ports from the content of variable 1 (input port 16) through the content of variable 2 (input port 23), to variable 99 as a binary.



● INB (Read I/O, flag as BCD)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	INB	I/O, flag	BCD digits	CC

[Function] Read the I/O ports or flags from the one specified in operand 1 for the number of digits specified in operand 2, to variable 99 as a BCD.



(Note 1) A maximum of eight digits (32 bits) can be input.

(Note 2) The number of I/O ports and flags that can be used is 4 x n (digits).

(Note 3) The read data format can be changed using a FMIO command (refer to the section on FMIO command).

[Example 1] INB 16 2 Read the input ports from 16 for two digits (until input port 23), to variable 99 as a BCD.


[Example 2] LET 1 16 Assign 16 to variable 1.
LET 2 2 Assign 2 to variable 2.
INB *1 *2 Read the input ports from the content of variable 1 (input port 16) for the content of variable 2 (two digits) (until input port 23), to variable 99 as a BCD.



● OUT (Write output, flag as binary)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OUT	Output, flag	Output, flag	CC

[Function] Write the value in variable 99 to the output ports or flags from the one specified in operand 1 through the other specified in operand 2.



(Note 1) A maximum of 32 bits can be output.

(Note 2) The write data format can be changed using a FMIO command (refer to the section on FMIO command).

[Example 1] OUT 316 323 Write the value in variable 99 to output ports 316 through 323 as a binary.


[Example 2] LET 1 316 Assign 316 to variable 1.
 LET 2 323 Assign 323 to variable 2.
 OUT *1 *2 Write the value in variable 99 to the output ports from the content of variable 1 (output port 316) through the content of variable 2 (output port 323) as a binary.



● OUTB (Write output, flag as BCD)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OUTB	Output, flag	BCD digits	CC

[Function] Write the value in variable 99 to the output ports or flags from the one specified in operand 1 for the number of digits specified in operand 2 as a BCD.



(Note 1) A maximum of eight digits (32 bits) can be output.

(Note 2) The number of output ports and flags that can be used is 4 x n (digits).

(Note 3) The write data format can be changed using a FMIO command (refer to the section on FMIO command).

[Example 1] OUTB 316 2 Write the value in variable 99 to the output ports from 316 for two digits (until output port 327) as a BCD.

[Example 2] LET 1 316 Assign 316 to variable 1.
 LET 2 2 Assign 2 to variable 2.
 OUTB *1 *2 Write the value in variable 99 to the output ports from the content of variable 1 (output port 316) for the content of variable 2 (two digits) (until output port 323) as a BCD.




● FMIO (Set IN, INB, OUT, OUTB command format)


Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	FMIO	Format type	Prohibited	CP

[Function] Set the data format for reading or writing I/O ports and flags with an IN, INB, OUT or OUTB command.


- [1] Operand 1 = 0 (Default status when a FMIO command has not been executed)
Data is read or written without being reversed.



- [2] Operand 1 = 1
Data is read or written after its upper eight bits and lower eight bits are reversed every 16 bits.




- [3] Operand 1 = 2
Data is read or written after its upper 16 bits and lower 16 bits are reversed every 32 bits.






[4] Operand 1 = 3

Data is read or written after its upper 16 bits and lower 16 bits are reversed every 32 bits and its upper eight bits and lower eight bits are reversed every 16 bits.




(Note) FMIO command is supported in main application version 0.56 or later, PC software version 2.0.45 or later and teaching pendant version 1.13 or later.

[Example 1] Variable 99 = 00123456h (Decimal: 1193046, BCD: 123456)






[Example 2] Variable 99 = 00001234h (Decimal: 4660, BCD: 1234)



[Example 3] Variable 99 = 00000012h (Decimal: 18, BCD: 12)





1-8 Program Control

● GOTO (Jump)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GOTO	Tag number	Prohibited	CP

[Function] Jump to the position of the tag number specified in operand 1.

(Note) A GOTO command is valid only within the same program.

[Example 1]

TAG	1	Set a tag.
⋮		
⋮		
GOTO	1	Jump to tag 1.

Using a GOTO command to branch out of or into any of the syntaxes listed below is prohibited.

Since the maximum number of nests is defined for each conditional branching command or subroutine call, a nest will be infinitely repeated if an EDXX is not passed, and a nest overflow error will generate. In the case of palletizing setting, an error will generate if the second BGPA is declared after the first BGPA declaration without passing an EDPA.

- (1) IFXX or ISXX and EDIF syntax
- (2) DWXX and EDDO syntax
- (3) SLCT and EDSL syntax
- (4) BGSR and EDSR syntax
- (5) BGPA and EDPA syntax

● TAG (Declare tag)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	TAG	Tag number	Prohibited	CP

[Function] Set the tag number specified in operand 1.

[Example 1] Refer to the section on GOTO command.



● EXSR (Execute subroutine)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	EXSR	Subroutine number	Prohibited	CP

[Function] Execute the subroutine specified in operand 1.
A maximum of 15 nested subroutine calls are supported.

(Note) This command is valid only for subroutines within the same program.

[Example 1] EXSR 1 Execute subroutine 1.

⋮

EXIT

BGSR 1 Start subroutine 1.

⋮

EDSR

End subroutine 1.

[Example 2] LET 1 10 Assign 10 to variable 1.
EXSR *1 Execute the content of variable 1 (subroutine 10).

● BGSR (Start subroutine)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	BGSR	Subroutine number	Prohibited	CP

[Function] Declare the start of the subroutine specified in operand 1.

[Example 1] Refer to the section on EXSR command.

(Note) Using a GOTO command to branch out of or into a BGSR-EDSR syntax is prohibited.



- EDSR (End subroutine)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	EDSR	Prohibited	Prohibited	CP

[Function] Declare the end of a subroutine.
This command is always required at the end of a subroutine.
Thereafter, the program will proceed to the step next to the EXSR that has been called.

[Example 1] Refer to the section on EXSR command.



1-9 Task Management

● EXIT (End program)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	EXIT	Prohibited	Prohibited	CP

[Function] End the program.
If the last step has been reached without encountering any EXIT command, the program will return to the beginning.

(Note) Status at program end

- Output ports.....Retained
- Local flags.....Cleared
- Local variables.....Cleared
- Current values.....Retained
- Global flags.....Retained
- Global variables.....Retained

[Example 1] :
 :
 EXIT End the program.



● EXPG (Start other program)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	EXPG	Program number	(Program number)	CC

[Function] Start the programs from the one specified in operand 1 through the other specified in operand 2, and run them in parallel. Specification in operand 1 only is allowed.

[Example 1] EXPG 10 12 Start program Nos. 10, 11 and 12.

Error-generation/output-operation conditions

When one EXPG program is specified (only operand 1 is specified)

When one EXR-C program is specified (only operation is specified)				
Status of the specified program	No program number error *1			Program number error *1
	Program already registered		Program not yet registered	
	Program running	Program not running		
Error	A57 “Multiple program start error”	None	C03 “Non-registered program specification error”	C2C “Program number error”
Output operation	ON	ON	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 1 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

When multiple EXPG programs are specified (both operands 1 and 2 are specified)

Status of the specified program	No program number error *2			Program number error *1
	Registered program exists inside the specified range *3		None of programs inside the specified range are registered	
	Running program exists inside the specified range	None of programs inside the specified range are running		
Error	A57 "Multiple program start error"	None	C03 "Non-registered program specification error"	C2C "Program number error"
Output operation	ON	ON	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 2 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

* 3 --- In this case, non-registered programs inside the specified range are not treated as a target of operation. This will not affect error generation or output operation.



● ABPG (Abort other program)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ABPG	Program number	(Program number)	CC

[Function] Forcibly end the programs from the one specified in operand 1 to the other specified in operand 2. Specification in operand 1 only is allowed.

(Note 1) If an ABPG command is issued while a movement command is being executed, the axes will immediately decelerate and stop.

(Note 2) Not only the operation but also the execution of the step itself will be terminated.

[Example 1] ABPG 10 12 End program Nos. 10, 11 and 12.

Error-generation/output-operation conditions

When one ABPG program is specified (only operand 1 is specified)

Status of the specified program	No program number error *1			Program number error *1
	Program already registered		Program not yet registered	
	Program running	Program not running		
Error	None	None	None	C2C “Program number error”
Output operation	ON (OFF *2)	ON	ON	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 1 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

* 2 --- If an own task (own program) is specified in an ABPG command, the own task will be terminated and then deleted. The output will turn OFF.

When multiple ABPG programs are specified (both operands 1 and 2 are specified)

Status of the specified program	No program number error *3			Program number error *1
	Registered program exists inside the specified range *4		None of programs inside the specified range are registered	
	Running program exists inside the specified range	None of programs inside the specified range are running		
Error	None	None	None	C2C “Program number error”
Output operation	ON (OFF *5)	ON	ON	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 3 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

* 4 --- In this case, non-registered programs inside the specified range are not treated as a target of operation. This will not affect error generation or output operation.

* 5 --- If an own task (own program) is included in the specified range, the own task will be terminated, upon which the processing of the ABPG command will end. Since the own task will be deleted, the result of ending the processing of specified programs will become indeterminable. Exercise caution. The output will always turn OFF regardless of the result.



● SSPG (Pause program)


Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SSPG	Program number	(Program number)	CC

[Function] Pause the program from the one specified in operand 1 through the other specified in operand 2, at the current step. Specification in operand 1 only is allowed.

(Note 1) Pausing a program will also pause the operation the program has been executing.

(Note 2) Not only the operation but also the execution of the step itself will be paused.

[Example 1] SSPG 10 12 Pause program Nos. 10, 11 and 12 at the current step.



Error-generation/output-operation conditions

When one SSPG program is specified (only operand 1 is specified)

Status of the specified program	No program number error *1			Program number error *1
	Program already registered		Program not yet registered	
	Program running	Program not running		
Error	None	None	C03 “Non-registered program specification error”	C2C “Program number error”
Output operation	ON	OFF	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 1 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

When multiple SSPG programs are specified (both operands 1 and 2 are specified)

Status of the specified program	No program number error *2			Program number error *1
	Registered program exists inside the specified range *3		None of programs inside the specified range are registered	
	Running program exists inside the specified range *4	None of programs inside the specified range are running		
Error	None	None	C03 “Non-registered program specification error”	C2C “Program number error”
Output operation	ON	OFF	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 2 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

* 3 --- In this case, non-registered programs inside the specified range are not treated as a target of operation with EXPG, ABPG, SSPG and PSPG commands. This will not affect error generation or output operation.

* 4 --- In this case, programs not running (but already registered) inside the specified range are not treated as a target of operation with SSPG and RSPG commands. This will not affect error generation or output operation.




● RSPG (Resume program)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	RSPG	Program number	(Program number)	CC

[Function] Resume the programs from the one specified in operand 1 through the other specified in operand 2. Specification in operand 1 only is allowed.

(Note 1) Resuming a program will also resume the operation the program had been executing before the pause.

[Example 1] RSPG 10 12 Resume program Nos. 10, 11 and 12 from the paused step.



Error-generation/output-operation conditions

When one RSPG program is specified (only operand 1 is specified)

Status of the specified program	No program number error *1			Program number error *1
	Program already registered		Program not yet registered	
	Program running	Program not running		
Error	None	None	C03 “Non-registered program specification error”	C2C “Program number error”
Output operation	ON	OFF	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 1 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

When multiple RSPG programs are specified (both operands 1 and 2 are specified)

When multiple PC's programs are specified (both operands *1 and *2 are specified)				
Status of the specified program	No program number error *2			Program number error *1
	Registered program exists inside the specified range *3		None of programs inside the specified range are registered	
	Running program exists inside the specified range *4	None of programs inside the specified range are running		
Error	None	None	C03 "Non-registered program specification error"	C2C "Program number error"
Output operation	ON	OFF	OFF	OFF

* The errors shown in the table represent those that generate in accordance with the status of the specified program. Errors caused by other factors are excluded.

* 2 --- Program number error indicates specification of a number smaller than 1 or exceeding 64.

* 3 --- In this case, non-registered programs inside the specified range are not treated as a target of operation. This will not affect error generation or output operation.

* 4 --- In this case, programs not running (but already registered) inside the specified range are not treated as a target of operation with SSPG and RSPG commands. This will not affect error generation or output operation.



1-10 Position Operation

● PGET (Read position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PGET	Axis number	Position number	CC

[Function] Read to variable 199 the data of the axis number specified in operand 1 in the position data specified in operand 2.
Data will not be stored in variable 199 (this command will not be executed) if the data being read is XXX.XX.

[Example 1] PGET 2 3 Read to variable 199 the data of axis 2 at position 3.
 [Example 2] LET 1 2 Assign 2 to variable 1.
 LET 2 3 Assign 3 to variable 2.
 PGET *1 *2 Read to variable 199 the data of the content of variable 1
 (axis 2) at the content of variable 2 (position 3).



● PPUT (Write position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PPUT	Axis number	Position number	CP

[Function] Write the value in variable 199 to the axis number specified in operand 1 in the position data specified in operand 2.

[Example 1] LET 199 150 Assign 150 to variable 199.
 PPUT 2 3 Write the content of variable 199 (150) to axis 2 at position 3.

[Example 2] LET 199 150 Assign 150 to variable 199.
 LET 1 2 Assign 2 to variable 1.
 LET 2 3 Assign 3 to variable 2
 PPUT *1 *2 Write the content of variable 199 (150) to the content of
 variable 1 (axis 2) at the content of variable 2 (position 3).



● PCLR (Clear position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PCLR	Position number	Position number	CP

[Function] Clear the position data from the one specified in operand 1 through the other specified in operand 2.

The cleared data will be expressed as XX.XXX (not 0.000).

[Example 1] PCLR 10 20 Clear the data from position Nos. 10 through 20.

[Example 2] LET 1 10 Assign 10 to variable 1.
 LET 2 20 Assign 20 to variable 2.
 PCLR *1 *2 Clear the data of the content of variable 1 (position 10)
 through the content of variable 2 (position 20).



● PCPY (Copy position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PCPY	Position number	Position number	CP

[Function] Copy the position data specified in operand 2 to the position number specified in operand 1.

[Example 1]	PCPY	20	10	Copy the data of position No. 10 to position No. 20.
[Example 2]	LET	1	20	Assign 20 to variable 1.
	LET	2	10	Assign 10 to variable 2.
	PCPY	*1	*2	Copy the data of the content of variable 2 (position 10) to the content of variable 1 (position 20).



● PRED (Read current position)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PRED	Axis pattern	Position number	CP

[Function] Read the current position of the axis specified in operand 1 to the position specified in operand 2.

[Example 1] PRED 11 10 Read the current positions of axes 1 and 2 to position No. 10.

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:

11 (binary) → 3 (decimal)

LET 1 3 Assign 3 to variable 1.

PRED *1 *10

[Example 3] LET 1 10 Assign 10 to variable 1.
PRED 11 *1 Read the current positions of axes 1 and 2 to the content of variable 1 (position 10).



- PRDQ (Read current axis position (1 axis direct))

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PRDQ	Axis number	Variable number	CP

This command is available with the PC software of version 1.1.0.5 or later and teaching pendant of version 1.05 or later.

[Function] Read the current position of the axis number specified in operand 1 to the variable specified in operand 2.
The current position can be obtained more quickly than when a PRED command is used.
The current position of a synchronized slave axis can also be read.

[Example] PRDQ 2 100 Read the current position of axis 2 to variable 100.



● PTST (Check position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PTST	Axis pattern	Position number	CC

[Function] Check if valid data is contained in the axis pattern specified in operand 1 at the position number specified in operand 2.
The output will turn ON when all of the data specified by the axis pattern is invalid (XX.XXX).
“0” is treated as valid data.

[Example 1] PTST 11 10 300 Turn ON output 300 if there are no valid values of axes 1 and 2 at position 10.
Output 300 will turn OFF if the position data is given as follows:

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
11 (binary) → 3 (decimal)
LET 1 3 Assign 3 to variable 1.
PTST *1 10 300

[Example 3] LET 1 11 Assign 11 to variable 1.
PTST 11 *1 600 Turn ON flag 600 if there are no valid values in the data of axes 1 and 2 at the content of variable 1 (position 11).
Flag 600 will turn ON if the position data is given as follows:

No.	Axis 1	Axis 2	Axis 3	Speed	Acceleration	Deceleration
10	100.000	50.000	XXXX.XXX	XXX	XXXX	XXXX
11	XXXX.XXX	XXXX.XXX	200.000	XXX	XXXX	XXXX



● PVEL (Assign speed data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PVEL	Speed	Position number	CP

[Function] Write the speed specified in operand 1 to the position number specified in operand 2.

(Note) If a negative value is written with a PVEL command, an alarm will generate when that position is specified in a movement operation, etc. Exercise caution.

[Example 1]	PVEL	100	10	Write speed 100 mm/s to position No. 10.
[Example 2]	LET	1	100	Assign 100 to variable 1.
	LET	2	10	Assign 10 to variable 2.
	PVEL	*1	*2	Write the content of variable 1 (speed 100 mm/s) to the content of variable 2 (position 10).



● PACC (Assign acceleration data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PACC	Acceleration	Position number	CP

[Function] Write the acceleration specified in operand 1 to the position number specified in operand 2.

(Note) Range check is not performed for a PACC command. Be careful not to exceed the limit set for each actuator.

[Example 1] PACC 0.3 10 Write acceleration 0.3 G to position No. 10.

[Example 2] LET 100 0.3 Assign 0.3 to variable 100.

LET 2 10 Assign 10 to variable 2.

PACC *100 *2 Write the content of variable 100 (acceleration 0.3 G) to the content of variable 2 (position 10).



- PDCL (Assign deceleration data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PDCL	Deceleration	Position number	CP

[Function] Assign the deceleration data specified in operand 1 to the deceleration item in the position data specified in operand 2.

The deceleration is set in G and may include up to two decimal places.

[Example 1] PDCL 0.3 3 Assign 0.3 to the deceleration data at position No. 3.



● PAXS (Read axis pattern)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAXS	Variable number	Position number	CP

[Function] Store the axis pattern at the position specified in operand 2 to the variable specified in operand 1.

[Example 1] PAXS 1 99 Read the axis pattern at position 99 to variable 1.
If the position is given as follows, "1" (binary 01) will be read to variable 1.

[Example 2] LET 1 3 Assign 3 to variable 1.
LET 2 101 Assign 101 to variable 2.
PAXS *1 *2 Read the axis pattern at the content of variable 2 (position 101) to the content of variable 1 (variable 3).
If the point is given as follows, "3" (binary 11) will be stored in variable 3.

The table below shows different positions and corresponding values stored in a variable.

	Axis 1	Axis 2		
98	XX.XXX	XX.XXX	0 0 = 0 + 0 = 0
99	100.XXX	XX.XXX	0 1 = 0 + 1 = 1
100	XX.XXX	150.000	1 0 = 2 + 0 = 2
101	100.000	50.000	1 1 = 2 + 1 = 3



- PSIZ (Check position data size)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PSIZ	Variable number	Prohibited	CP

[Function] Set an appropriate value in the variable specified in operand 1 in accordance with the parameter setting.

- When “Other parameter No. 23, PSIZ function type” = 0
The maximum number of position data that can be stored in the controller will be set.
(Regardless of whether the data are used or not.)
- When “Other parameter No. 23, PSIZ function type” = 1
The number of point data used will be set.

[Example] PSIZ 1

When “Other parameter No. 23, PSIZ function type” = 0
The maximum number of position data that can be stored in variable 1 will be set.
When “Other parameter No. 23, PSIZ function type” = 1
The number of point data currently used will be set in variable 1.



● GVEL (Get speed data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GVEL	Variable number	Position number	CP

[Function] Obtain speed data from the speed item in the position data specified in operand 2, and set the value in the variable specified in operand 1.

[Example] GVEL 100 10 Set the speed data at position No. 10 in variable 100.

Position No.	Axis 1	Axis 2	Axis 3	Vel	Acc	Dcl
1	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
2	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
•						
•						
•						
•						
10	50.000	100.000	150.000	200	0.30	0.30
•						
•						

If the position data is set as above when the command is executed, 200 will be set in variable 100.



- GACC (Get acceleration data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GACC	Variable number	Position number	CP

[Function] Obtain acceleration data from the acceleration item in the position data specified in operand 2, and set the value in the variable specified in operand 1.

[Example 1] GACC 100 10 Set the acceleration data at position No. 10 in variable 100.

Position No.	Axis 1	Axis 2	Axis 3	Vel	Acc	Dcl
1	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
2	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
•						
•						
•						
•						
10	50.000	100.000	150.000	200	0.30	0.30
•						
•						

If the position data is set as above when the command is executed, 0.3 will be set in variable 100.



● GDCL (Get deceleration data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GDCL	Variable number	Position number	CP

[Function] Obtain deceleration data from the deceleration item in the position data specified in operand 2, and set the value in the variable specified in operand 1.

[Example] GDCL 100 10 Set the deceleration data at position No. 10 in variable 100.

Position No.	Axis 1	Axis 2	Axis 3	Vel	Acc	Dcl
1	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
2	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
•						
•						
•						
•						
10	50.000	100.000	150.000	200	0.30	0.30
•						
•						

If the position data is set as above when the command is executed, 0.3 will be set in variable 100.



1-11 Actuator Control Declaration

● VEL (Set speed)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	VEL	Speed	Prohibited	CP

[Function] Set the actuator travel speed in the value specified in operand 1.
The unit is mm/s.
The maximum speed will vary depending on the model of the actuator connected. Set a speed not exceeding the applicable maximum speed.

(Note 1) Decimal places cannot be used. An error will generate

(Note 2) The minimum speed is 1 mm/s.

[Example 1]	VEL	100		Set the speed to 100 mm/s.
	MOVP	1		Move to point 1 at 100 mm/s.
[Example 2]	VEL	200		Set the speed to 200 mm/s.
	MOVP	2		Move to point 2 at 200 mm/s.
[Example 3]	LET	1	300	Assign 300 to variable 1.
	VEL	*1		Set the speed to the content of variable 1 (300 mm/s).



● OVRD (Override)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OVRD	Speed ratio	Prohibited	CP

[Function] Reduce the speed in accordance with the ratio specified in operand 1 (speed coefficient setting). The speed ratio is set in a range from 1 to 100%.
A speed command specifying a speed below 1 mm/sec can be generated using OVRD.
Command limit speed for smooth operation: 1 pulse/msec
Command limit speed that can be generated: 1 pulse/256 msec
(Smoothness of actual operation cannot be guaranteed. Movement must be checked on the actual machine.)
1 pulse: Lead [mm] / 800 --- Standard product with a gear ratio of 1:1
(The speed set in a PAPR command (push-motion approach speed) will be clamped by the minimum speed of 1 mm/sec.)

[Example 1] VEL 100 Set the speed to 100 mm/s.
 OVRD 50 Reduce the speed to 50%.
 As a result, the actual speed will become 50 mm/s.



● ACC (Set acceleration)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ACC	Acceleration	Prohibited	CP

[Function] Set the travel acceleration of the actuator.
The maximum acceleration will vary depending on the load and model of the actuator connected.
The acceleration is set in G and may include up to two decimal places.

(Note) If the position data contains no acceleration AND acceleration is not set by an ACC command, the actuator will move based on the default value set in "All-axis parameter No. 11, Default acceleration."

[Example 1] ACC 0.3 Set the acceleration to 0.3 G.

(Note) Setting an acceleration exceeding the specified range for the actuator may generate an error.
It may also result in a failure or shorter product life.
Maximum acceleration: 0.3 G for the gate type and 0.2 G for the cantilever type



● DCL (Set deceleration)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	DCL	Deceleration	Prohibited	CP

[Function] Set the travel deceleration of the actuator.
The maximum deceleration will vary depending on the load and model of the actuator connected.
The deceleration is set in G and may include up to two decimal places.

(Note) If the position data contains no deceleration AND deceleration is not set by a DCL command, the actuator will move based on the default value set in “All-axis parameter No. 12, Default deceleration.”
A DCL command cannot be used with CIR and ARC commands.

[Example] DCL 0.3 Set the deceleration to 0.3 G.

(Note) Setting a deceleration exceeding the specified range for the actuator may generate an error.
It may also result in a failure or shorter product life.
Maximum acceleration: 0.3 G for the gate type and 0.2 G for the cantilever type



● SCR V (Set sigmoid motion ratio)


Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SCR V	Ratio	Prohibited	CP

[Function] Set the ratio of sigmoid motion control of the actuator in the value specified in operand 1. The ratio is set as an integer in a range from 0 to 50 (%).

$$\frac{b}{a} \times 100 (\%)$$

If the ratio is not set using this command or 0% is set, a trapezoid motion will be implemented.

A SCR V command can be used with the following commands: MOVP, MOVL, MVPI, MVLI, JBWF, JBWN, JFWF, JFWN



[Example 1] SCR V 30 Set the sigmoid motion ratio to 30%.



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OFST	Axis pattern	Offset value	CP

[Example 3]	LET	1	100	Assign 100 to variable 1.
	OFST	101	*1	Add the content of variable 1 (100 mm) to the specified positions of axes 1 and 3.



● DEG (Set arc angle)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	DEG	Angle	Prohibited	CP

[Function] Set a division angle for the interpolation implemented by a CIR (move along circle) or ARC (move along arc) command.
When CIR or ARC is executed, a circle will be divided by the angle set here to calculate the passing points.
The angle is set in a range from 0 to 120 degrees.
If the angle is set to "0," an appropriate division angle will be calculated automatically so that the actuator will operate at the set speed (maximum 180 degrees).
The angle is set in degrees and may include up to one decimal place.

(Note) If a CIR or ARC command is executed without setting an angle with this command, the default value registered in "All-axis parameter No. 30, Default division angle" will be used.

[Example] DEG 10 Set the division angle to 10 degrees.



● BASE (Specify axis base)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	BASE	Axis number	Prohibited	CP

Function] Count the axes sequentially based on the axis number specified in operand 1 being the first axis.

A BASE command can be used with PRED, PRDQ, AXST, actuator-control, ARCH, PACH, PMVP, PMVL and zone commands. Note that each zone range is assigned to the actuator via parameter.

[Example 1]

HOME	1	Axis 1 returns to the home.
BASE	2	Axis 2 is considered the first axis.
HOME	1	Axis 2 returns to the home.

Hereafter, axes 2 to 4 will operate based on the specifications for axes 1 to 3 (axis number, axis pattern, position data, etc.).

[Example 2]

LET	1	3	Assign 3 to variable 1.
BASE	*1		The content of variable 1 (axis 3) will be considered as the first axis.

Hereafter, axes 3 and 4 will operate based on the specifications for axes 1 and 2.



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	GRP	Axis pattern	Prohibited	CP

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
110 (binary) → 6 (decimal)
LET 1 6 Assign 6 to variable 1.
GRP *1
CIR2 1 2



● HOLD (Hold: Declare axis port to pause)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	HOLD	(Input port, global flag)	(HOLD type)	CP

[Function] Declare an input port or global flag to pause while a servo command is being executed. When operation is performed on the input port or global flag specified in operand 1, the current servo processing will pause. (If the axes are moving, they will decelerate to a stop.) If nothing is specified in operand 1, the current pause declaration will become invalid.

[HOLD type]

0 = Contact a (Deceleration stop)

1 = Contact b (Deceleration stop)

2 = Contact b (Deceleration stop → Servo OFF (The drive source will not be cut off))

The HOLD type is set to "0" (contact a) when the program is started.

If nothing is specified in operand 2, the current HOLD type will be used.

Using other task to issue a servo ON command to any axis currently stopped via a HOLD servo OFF will generate an "Error No. C66, Axis duplication error." If the servo of that axis was ON prior to the HOLD stop, the system will automatically turn on the servo when the HOLD is cancelled. Therefore, do not issue a servo ON command to any axis currently stopped via a HOLD servo OFF.


If any axis currently stopped via a HOLD servo OFF is moved by external force, etc., from the stopped position, and when the servo of that axis was ON prior to the HOLD stop, the axis will move to the original stopped position when the HOLD is cancelled before resuming operation.

(Note 1) The input port or global flag specified by a HOLD declaration will only pause the axes used in the task (program) in which the HOLD is declared. The declaration will not be valid on axes used in different tasks (programs).

(Note 2) An input port or global flag to pause is valid for all active servo commands other than a SVOF command. (A deceleration stop will also be triggered in JXWX and PATH operations.)

(Note 3) Following a pause of home return, the operation will resume from the beginning of the home-return sequence.

[Example] HOLD 16 0 The axes will decelerate to a stop when input port 16 turns ON.





● CANC (Cancel: Declare axis port to abort)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CANC	(Input port, global flag)	(CANC type)	CP

[Function] Declare an input port or global flag to abort while a servo command is being executed. When operation is performed on the input port or global flag specified in operand 1, the current servo processing will be aborted. (If the axes are moving, they will decelerate to a stop before the processing is aborted.)

If nothing is specified in operand 1, the current abort declaration will become invalid.

[CANC type]

0 = Contact a (Deceleration stop)

1 = Contact b (Deceleration stop)


The CANC type is set to "0" (contact a) when the program is started.

If nothing is specified in operand 2, the current CANC type will be used.

(Note 1) The input port or global flag specified by a CANC command will only abort the axes used in the task (program) in which the CANC is declared. The declaration will not be valid on axes used in different tasks (programs).

(Note 2) An input port or global flag to pause is valid for all active servo commands other than a SVOF command. (A deceleration stop will also be triggered in JXWX and PATH operations.)

[Example] CANC 17 0 The axes will decelerate to a stop when input port 17 turns ON.





● VLMX (Specify VLMX speed)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	VLMX	Prohibited	Prohibited	CP

[Function] Set the actuator travel speed to the VLMX speed (normally maximum speed).
Executing a VLMX command will set the value registered in “Axis-specific parameter No. 29, VLMX speed” as the travel speed.

(Note) If the VLMX speed is specified in a continuous position travel command (PATH, PSPL), the target speed to each position will become a composite VLMX speed not exceeding the maximum speed of each axis set in “Axis-specific parameter No. 28, Maximum operating speed of each axis.” To make the target speed constant, a desired speed must be expressly specified using a VEL command.

[Example]

VEL	200]	The speed becomes 200 mm/sec in this section.
MOVP	1		
MOVP	2		
VLMX]	The speed becomes VLMX mm/sec in this section.
MOVP	3		
MOVP	4		

DIS (Set division distance at spline movement)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	DIS	Distance	Prohibited	CP


[Function] Set a division distance for the interpolation implemented by a PSPL (move along spline) command.

When a PSPL command is executed, a passing point will be calculated at each distance set here and the calculated passing points will be used as interpolation points.

If the distance is set to "0," an appropriate division distance will be calculated automatically so that the actuator will operate at the set speed

The distance is input in mm.

Interpolation points



(Note) If a PSPL command is executed without setting a distance with a DIS command, the default value registered in "All-axis parameter No. 31, Default division distance" will be used.

[Example] DIS 10 Set the division distance to 10 mm.

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	POTP	0 or 1	Prohibited	CP

When a PATH or PSPL command is executed, the output will operate as follows in accordance with the setting of the POTP command.


- (Note 1) The default value of POTP, before it is set, is "0."
- (Note 2) If POTP = 1 and there is no valid data at the specified position, the output number will be incremented but the output will not turn ON. (The output number will be incremented regardless of the size of position numbers specified in operands 1 and 2 in a PATH or PSPL command.)

The diagram illustrates a zigzag path with five numbered positions (No. 1 to No. 5) and a 'Position origin'. The path starts at the 'Position origin', goes to 'Position No. 1', then to 'No. 2', 'No. 3', 'No. 4', and finally 'No. 5'. Solid arrows indicate the direction of travel between these points. Dashed curved arrows indicate the turns at each numbered position. Labels for 'Turn ON output port' are associated with each turn: 'Turn ON output port 316.' for the turn at Position No. 1, 'Turn ON output port 317.' for the turn at No. 2, 'Turn ON output port 318.' for the turn at No. 3, 'Turn ON output port 319.' for the turn at No. 4, and 'Turn ON output port 320.' for the turn at No. 5.

● PAPR (Set push-motion approach distance, speed)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPR	Distance	Speed	CP

[Function] Set the operation to be performed when a PUSH command is executed.
Set the distance (push-motion approach distance) over which push-motion approach operation (torque-limiting operation) will be performed in operand 1 (in mm), and set the speed (push-motion approach speed) at which push-motion approach operation (torque-limiting operation) will be performed in operand 2 (in mm/sec).
The push-motion approach distance specified in operand 1 may contain up to three decimal places, while the speed specified in operand 2 cannot contain any decimal place.



[Example] PAPR 100 30 Set the push-motion approach distance in a PUSH command to 100 mm and the push-motion approach speed to 30 mm/sec.

(Note) The push-motion approach speed in an OVRD command will be clamped by the minimum speed of 1 mm/sec. (Correct push-motion operation is not guaranteed at the minimum speed. Operation at slow push-motion approach must be checked on the actual machine by considering the effects of mechanical characteristics, etc.)

● QRTN (Set quick-return mode)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	QRTN	0 or 1	Prohibited	CP

[Function] Set and cancel the quick-return mode.


[1] QRTN [Operand 1] = 0 (Normal mode)

Positioning is deemed complete when all command pulses have been output and the current position is inside the positioning band.

* If a deceleration command is currently executed in the quick-return mode, the system will wait for all command pulses to be output.

[2] QRTN [Operand 1] = 1 (Quick-return mode)

Positioning is deemed complete when “a normal deceleration command is currently executed (excluding deceleration due to a stop command, etc.) or all command pulses have been output” AND “the current position is inside the positioning band.” This setting is used to perform other processing during deceleration, in conjunction with a PBND command.



(Note 1) The quick-return mode will be cancelled when the program ends. (The positioning band set by a PBND command will not be cancelled.)

(Note 2) If a given axis is used even once in the quick-return mode, the program will not release the right to use the axis until the QRTN is set to “0” (normal mode) or the program ends. Any attempt to use the axis from other program will generate an “Error No. C66, Axis duplication error.”

(Note 3) Following a return from a normal deceleration command in the quick-return mode, the next positioning will start after all command pulses for the previous positioning have been output. Therefore, in the quick-return mode a simple reciprocating operation will require a longer tact time because of the extra completion check. In this sense, this setting should be used only if you wish to reduce the overall tact time by performing other processing during deceleration.

(Note 4) The quick-return mode represents very irregular processing. Therefore, be sure to revert to the normal mode when the overlay processing is completed in the necessary section.

(Note 5) The quick-return mode cannot be used with a push-motion travel command or arc interpolation command.




1-12 Actuator Control Command

● SVXX (Turn ON/OFF servo)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SVXX	Axis pattern	Prohibited	PE

[Function] Turn ON/OFF the servos of the axes specified by the axis pattern in operand 1.



[Example 1] SVON 110 Turn ON the servos of axes 2 and 3. Nothing will occur if the axis servos are already ON.

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
110 (binary) → 6 (decimal)
LET 1 6 Assign 6 to variable 1.
SVON *1



Warning : Turning the servo ON near the mechanical end may disturb the magnetic pole phase detection, and may cause the magnetic pole unconfirmed error or the magnetic pole detection error.

Put the slider or rod away from the mechanical end when turning the servo ON.



● HOME (Return to home)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	HOME	Axis pattern	Prohibited	PE

[Function] Perform home return of the axes specified by the axis pattern in operand 1.
The servo of each home-return axis will turn ON automatically.
The output will turn OFF at the start of home return, and turn ON when the home return is completed.

(Note) Following a pause of home return, the operation will resume from the beginning of the home-return sequence.

[Example 1] HOME 100 Axis 3 return to the home.

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
100 (binary) → 4 (decimal)
LET 1 4 Assign 4 to variable 1.
HOME *1



Warning : Turning the servo ON near the mechanical end may disturb the magnetic pole phase detection, and may cause the magnetic pole unconfirmed error or the magnetic pole detection error.
Put the slider or rod away from the mechanical end when turning the servo ON.



● MOV P (Move PTP by specifying position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MOV P	Position number	Prohibited	PE


[Function] Move the actuator to the position corresponding to the position number specified in operand 1, without interpolation (PTP stands for “Point-to-Point”).
The output will turn OFF at the start of axis movement, and turn ON when the movement is complete.

[Example 1] VEL 100 Set the speed to 100 mm/sec.
 MOV P 1 Move the axes to the position corresponding to position No. 1 (200, 100).

[Example 2] VEL 100 Set the speed to 100 mm/sec.
 LET 1 2 Assign 2 to variable 1.
 MOV P *1 Move the axes to the position corresponding to the content of variable 1 (position No. 2, or (100, 100)).

No.	X-axis	Y-axis	Speed	Acceleration	Deceleration
1	200.000	100.000	XXX	XXXX	XXXX
2	100.000	100.000	XXX	XXXX	XXXX

Travel path from the home to the position corresponding to position No. 1 (200, 100)



Each axis moves at the specified speed.



● MOVL (Move by specifying position data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MOVL	Position number	Prohibited	PE


[Function] Move the actuator to the position corresponding to the position number specified in operand 1, with interpolation.
The output will turn OFF at the start of axis movement, and turn ON when the movement is complete.

[Example 1] VEL 100 Set the speed to 100 mm/sec.
 MOVL 1 Move the axes to the position corresponding to position No. 1 (200, 100), with interpolation.

[Example 2] VEL 100 Set the speed to 100 mm/sec.
 LET 1 2 Assign 2 to variable 1.
 MOVL *1 Move the axes to the position corresponding to the content of variable 1 (position No. 2, or (100, 100)), with interpolation.

No.	X-axis	Y-axis	Speed	Acceleration	Deceleration
1	200.000	100.000	XXX	XXXX	XXXX
2	100.000	100.000	XXX	XXXX	XXXX

Travel path from the home to the position corresponding to position No. 1 (200, 100)



The X and Y-axes complete movement simultaneously.

The tip of each axis moves at the specified speed.

- MVPI (Move via incremental PTP)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MVPI	Position number	Prohibited	PE

[Function] Move the actuator, without interpolation, from the current position by the travel distance corresponding to the position number specified in operand 1.

The output will turn OFF at the start of axis movement, and turn ON when the movement is complete.


Movement may not occur if the specified travel distance is below the resolution (1 pulse):
1 pulse: Lead [mm] / 16384 --- Standard product with a gear ratio of 1:1

[Example 1]	VEL	100	Set the speed to 100 mm/sec.
	MVPI	1	If the current position is (50, 50) and position No. 1 is set to (150, 100), the axes will move 150 in the X direction and 100 in the Y direction (200, 150) from the current position.

[Example 2]	VEL	100		Set the speed to 100 mm/sec.
	LET	1	2	Assign 2 to variable 1.
	MVPI	*1		Move from the current position by the travel distance corresponding to the content of variable 1 (position No. 2, or (100, 100)).

No.	X-axis	Y-axis	Speed	Acceleration	Deceleration
1	150.000	100.000	XXX	XXXX	XXXX
2	100.000	100.000	XXX	XXXX	XXXX

Travel path from (50, 50) by the travel distance corresponding to position No. 1 (150, 100)





● MVLI (Move via incremental interpolation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	MVLI	Position number	Prohibited	PE


[Function] Move the actuator, with interpolation, from the current position by the travel distance corresponding to the position number specified in operand 1.
The output will turn OFF at the start of axis movement, and turn ON when the movement is complete.
Movement may not occur if the specified travel distance is below the resolution (1 pulse):
1 pulse: Lead [mm] / 16384 --- Standard product with a gear ratio of 1:1

[Example 1] VEL 100 Set the speed to 100 mm/sec.
 MVLI 1 If the current position is (50, 50) and position No. 1 is set to (150, 100), the axes will move 150 in the X direction and 100 in the Y direction (200, 150) from the current position, with interpolation.

[Example 2] VEL 100 Set the speed to 100 mm/sec.
 LET 1 2 Assign 2 to variable 1.
 MVLI *1 Move from the current position by the travel distance corresponding to the content of variable 1 (position No. 2, or (100, 100)).

No.	X-axis	Y-axis	Speed	Acceleration	Deceleration
1	200.000	100.000	XXX	XXXX	XXXX
2	100.000	100.000	XXX	XXXX	XXXX

Travel path from (50, 50) by the travel distance corresponding to position No. 1 (150, 100)




The tip of each axis moves at the specified speed.

- PATH (Move along path)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PATH	Start position number	End position number	PE

[Function] Move continuously from the position specified in operand 1 to the position specified in operand 2.
The output type in the output field can be set using an actuator-declaration command POTP. Increasing the acceleration will make the passing points closer to the specified positions. If invalid data is set for any position number between the start and end position numbers, that position number will be skipped during continuous movement.



(Note 1) Multi-dimensional movement can be performed using a PATH command. In this case, input in operand 1 the point number of the next target, instead of the predicted current position upon execution of the applicable command. (Inputting a point number corresponding to the predicted current position will trigger movement to the same point during continuous movement, thereby causing the speed to drop.)

[Example 1]	VEL	100		Set the speed to 100 mm/sec.
	PATH	100	120	Move continuously from position Nos. 100 to 120.

[Example 2]	VEL	100		Set the speed to 100 mm/sec.
	LET	1	50	Assign 50 to variable 1.
	LET	2	100	Assign 100 to variable 2.
	PATH	*1	*2	Move continuously along the positions from the content of variable 1 (position No. 50) to the content of variable 2 (position No. 100).

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	JXWX	Axis pattern	Input, output, flag number	PE

JBWF.....	Move backward while the specified port is OFF.
JBWN.....	Move backward while the specified port is ON.
JFWF.....	Move forward while the specified port is OFF.
JFWN.....	Move forward while the specified port is ON.

[Example 1]	VEL	100		Set the speed to 100 mm/sec.
	JBWF	100	16	Move axis 3 backward while input 16 is OFF.

100 (binary) \rightarrow 4 (decimal)

VEL	100		Set the speed to 100 mm/sec.
LET	1	4	Assign 4 to variable 1.
JBWF	*1	16	

156



● STOP (Stop movement)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	STOP	Axis pattern	Prohibited	CP

[Function] Decelerate and stop the axes specified by the axis pattern in operand 1.

(Note 1) A STOP command can be used with all active servo commands other than a SVOF command.

(Note 2) A STOP command only issues a deceleration-stop command (operation stop) to a specified axis pattern and does not wait for stopping to complete. Issuing other servo commands to a decelerating axis will either become invalid or generate an “axis duplication error,” etc. Set a timer, etc., in the program so that the next servo command will be issued after a sufficient deceleration-stop processing time elapses.
Even when a STOP command is to be issued to an axis currently stopped, provide a minimum interval of 0.1 second before the next servo command is issued.

[Example 1] STOP 100 Decelerate and stop axis 3.

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:

100 (binary) → 4 (decimal)

LET 1 12 Assign 4 to variable 1.

STOP *1




● PSPL (Move along spline)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PSPL	Start position number	End position number	PE

[Function] Continuously move from the specified start position to end position via interpolation along a spline-interpolation curve.

The output type in the output field can be set using an actuator-declaration command POTP. If invalid data is set for any position number between the start and end position numbers, that position number will be skipped during continuous movement.



(The above diagram is only an example.)

(Note) If the acceleration and deceleration are different between points, the speeds will not be connected smoothly.

In this case, input in operand 1 the point number of the next target, instead of the predicted current position upon execution of the applicable command.


(Inputting a point number corresponding to the predicted current position will trigger movement to the same point during continuous movement, thereby causing the speed to drop.)

[Example] VEL 100 Set the speed to 100 mm/sec.
 PSPL 100 120 Continuously move from position Nos. 100 to 120 along a
 spline-interpolation curve.

● PUSH (Move by push motion)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PUSH	Target position number	Prohibited	PE

[Function] Perform push-motion operation until the target position specified in operand 1 is reached. The axes move in a normal mode from the position origin to the push-motion approach start position as determined by a PAPR command, after which push-motion approach operation (torque-limiting operation) will be performed. The speed of push-motion approach operation (torque-limiting operation) is determined by the push-motion approach speed specified by a PAPR command. If the output field is specified, the output will turn ON when a contact is confirmed, and turn OFF when a missed contact is detected.



The push force can be adjusted using “Driver-card parameter No. 33, Push torque limit at positioning” (default value: 70%).

- (Note 1) A PUSH command only moves a single axis. If multiple axes are specified, an “Error No. C91, Multiple push-axes specification error” will generate.
- (Note 2) A push-motion approach speed exceeding the maximum speed permitted by the system will be clamped at the maximum speed. (The maximum system speed is not the maximum practical speed. Determine a practical speed by considering the impact upon contact, etc.)



[Example] PAPR 100 20
 MOV 2
 PUSH 10


Set the push-motion approach distance to 100 mm and push-motion approach speed to 20 mm/sec.

Move from the current position to position No. 2.

Perform push-motion movement from position Nos. 2 to 10.

The diagram below describes a push-motion movement based on the position data shown in the table below:

Position No.	Axis 1	Axis 2	Axis 3	Vel	Acc	Dcl
1	XXX.XXX	XXX.XXX	XXX.XXX	XXX	X.XX	X.XX
2	50.000	100.000	XXX.XXX	XXX	X.XX	X.XX
•						
•						
•						
•						
10	200.000			200	0.30	0.30
•						
•						



- CIR2 (Move along circle 2 (arc interpolation))

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CIR2	Passing position 1 number	Passing position 2 number	PE

[Function] Move along a circle originating from the current position and passing positions 1 and 2, via arc interpolation.

The rotating direction of the circle is determined by the given position data.


The diagram below describes a CW (clockwise) movement. Reversing passing positions 1 and 2 will change the direction of movement to CCW (counterclockwise).

The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration (deceleration)
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1
2	Setting by VEL command	Setting by ACC (DCL) command
3		Default acceleration in all-axis parameter No. 11 (Default deceleration in all-axis parameter No. 12)


If speed is not set, a “C88 speed specification error” will generate.

If acceleration/deceleration is not valid, a “C89 acceleration/deceleration specification error” will generate.



(Note) This command is valid on arbitrary orthogonal planes. (Axis 2 may be selected automatically prior to axis 1 in accordance with the position data.)

[Example]	VEL	100		Set the speed to 100 mm/sec.
	CIR2	100	101	Move along a circle (circular interpolation) passing position Nos. 100 and 101.




Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARC2	Passing position number	End position number	PE

The speed and acceleration will take valid values based on the following priorities:


Priority	Speed	Acceleration (deceleration)
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1
2	Setting by VEL command	Setting by ACC (DCL) command
3		Default acceleration in all-axis parameter No. 11 (Default deceleration in all-axis parameter No. 12)

If acceleration/deceleration is not valid, a “C89 acceleration/deceleration specification error” will generate.



(Note) This command is valid on arbitrary orthogonal planes. (Axis 2 may be selected automatically prior to axis 1 in accordance with the position data.)

[Example]	VEL	100		Set the speed to 100 mm/sec.
	ARC2	100	101	Move along an arc (circular interpolation) from the current position to position No. 101 by passing position No. 100.




● CIRS (Move three-dimensionally along circle)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CIRS	Passing position 1 number	Passing position 2 number	PE

This command is available with the PC software of version 1.1.0.5 or later and teaching pendant of version 1.05 or later.

[Function] Move along a circle (three-dimensional movement) originating from the current position and passing positions 1 and 2 sequentially.
The rotating direction of the circle is determined by the given position data.
The movement in the diagram below will be performed in the reverse direction if passing positions 1 and 2 are reversed.



The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration	Deceleration
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1	Same as the valid acceleration value
2	Setting by VEL command	Setting by ACC command	
3		Default acceleration in all-axis parameter No. 11	

If speed is not set, a "C88 speed specification error" will generate.

If acceleration/deceleration is not valid, a "C89 acceleration/deceleration specification error" will generate.


- (Note 1) This command is valid on arbitrary planes in a three-dimensional space. (Axis 2 (if there are only two valid axes) or axis 3 may be selected automatically prior to axis 1 in accordance with the position data.)
- (Note 2) The locus tends to shift inward as the speed increases. Minor adjustment, such as setting the position data slightly outward, may be required.
- (Note 3) If the circle diameter is small with respect to the set speed, the speed may be limited. (Increasing the acceleration/deceleration will reduce the speed limitation, but they must not exceed the range permitted by the actuator.)

● ARCS (Move three-dimensionally along arc)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARCS	Passing position number	End position number	PE

This command is available with the PC software of version 1.1.0.5 or later and teaching pendant of version 1.05 or later.

[Function] Move along an arc (three-dimensional movement) originating from the current position, passing the specified position and terminating at the end position.



The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration	Deceleration
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1	Same as the valid acceleration value
2	Setting by VEL command	Setting by ACC command	
3		Default acceleration in all-axis parameter No. 11	

If speed is not set, a "C88 speed specification error" will generate.

If acceleration/deceleration is not valid, a "C89 acceleration/deceleration specification error" will generate.

- (Note 1) This command is valid on arbitrary planes in a three-dimensional space. (Axis 2 (if there are only two valid axes) or axis 3 may be selected automatically prior to axis 1 in accordance with the position data.)
- (Note 2) The locus tends to shift inward as the speed increases. Minor adjustment, such as setting the position data slightly outward, may be required.
- (Note 3) If the arc diameter is small with respect to the set speed, the speed may be limited. (Increasing the acceleration/deceleration will reduce the speed limitation, but they must not exceed the range permitted by the actuator.)



● CHVL (Change speed)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CHVL	Axis pattern	Speed	CP

[Function] Change the speed of the axes operating in other task.

When a CHVL command is executed, the speed of the axes specified in operand 1 will change to the value specified in operand 2.

(Note 1) This command is not valid on an axis operated by a CIR, ARC, PSPL, PUSH, ARCH, PACH, CIRS or ARCS command.

(Note 2) Executing a CHVL command for an axis operating in sigmoid motion (SCRV command) will generate an "Error No. CC1, Speed-change condition error."

(Note 3) This is a temporary speed-change command issued from other task to the active packet (point). It is not affected by the data declared by VEL.

Program 1	Program 2
CHVL 111 100	VEL 300 . MOV P 1 MOV P 2 MOV P 3 .

If CHVL is executed in program 1 while MOV P 2 is executed in program 2, the travel speed of MOV P 2 will become 100 mm/sec. The speeds of other move commands will remain 300 mm/sec.

The axis pattern can be specified indirectly using a variable.


When program 1 is rephrased based on indirect specification using a variable:

111 (binary) → 7 (decimal)

LET 1 7 Assign 7 to variable 1.

CHVL *1 100

(Note 4) Since this command is valid only for the packet that is active at the time of execution of the command for an axis subject to continuous motion in a PATH command, etc., caution must be exercised against the timing shift. The packet handling will be put on hold during speed-change processing, so caution must also be exercised against the locus shift.



If CHVL is executed in program 1 while PATH is executed in program 2, or specifically during the PATH movement from point No. 2 to point No. 3, the speed specified by CHVL (100 mm/sec in the above example) will become valid only during the PATH movement to point No. 3. Other travel speeds will remain at the speed specified by VEL (300 mm/sec in the above example).

(Note 5) Override of the CHVL call task will be applied, so caution must be exercised.

(Note 6) The maximum speed of the specified axis completing home return will be clamped by the minimum value set in "Axis-specific parameter No. 28, Maximum operating speed of each axis" or "Axis-specific parameter No. 27, Maximum speed limited by maximum motor speed" with respect to the specified axis and related interpolation axes currently operating. To prevent the maximum speed from being limited due to the effect of other axis whose maximum speed is lower than the speed specified in the CHVL command, issue a CHVL command in multiple steps corresponding to the respective axes having different maximum speeds. In particular, specification of a CHVL command in a separate step is recommended for a rotating axis.

[Example] CHVL 111 500 ⇒ CHVL 111 500
CHVL 1000 500

● ARCD (Move along arc via specification of end position and center angle (arc interpolation))

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARCD	End position number	Center angle	PE

[Function] Move along an arc originating from the current position and terminating at the end position, via arc interpolation.


Specify the end position of movement in operand 1, and the center angle formed by the position origin and end position in operand 2. The center angle is set in a range from – 359.999 to –0.001 or from 0.001 to 359.999. A positive value indicates CCW (counterclockwise) movement, while a negative value indicates CW (clockwise) movement. The center angle is set in degrees and may include up to three decimal places.

The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration (deceleration)
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1
2	Setting by VEL command	Setting by ACC (DCL) command
3		Default acceleration in all-axis parameter No. 11 (Default deceleration in all-axis parameter No. 12)

If speed is not set, a “C88 speed specification error” will generate.

If acceleration/deceleration is not valid, a “C89 acceleration/deceleration specification error” will generate.



(Note 1) This command is valid on arbitrary orthogonal planes. (Axis 2 may be selected automatically prior to axis 1 in accordance with the position data.)

[Example] VEL 100 Set the speed to 100 mm/sec.
 ARCD 100 120 Move along an arc from the position origin to position No. 100 for a center angle of 120 degrees (CCW direction).

(Note 2) The rotating direction of the actual operation locus varies depending on whether the system is of gate type or cantilever type. Be sure to perform test operation to check the rotating direction.

- ARCC (Move along arc via specification of center position and center angle (arc interpolation))

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARCC	Center position number	Center angle	PE


[Function] Move along an arc originating from the current position by keeping a specified radius from the center position, via arc interpolation.
Specify the center position in operand 1, and the center angle formed by the position origin and end position in operand 2. The center angle is set in a range from -3600 to 3600 degrees (± 10 revolutions). A positive value indicates CCW (counterclockwise-direction) movement, while a negative value indicates CW (clockwise-direction) movement (setting unit: degree). The center angle is set in degrees and may include up to three decimal places.

The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration (deceleration)
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1
2	Setting by VEL command	Setting by ACC (DCL) command
3		Default acceleration in all-axis parameter No. 11 (Default deceleration in all-axis parameter No. 12)

If speed is not set, a "C88 speed specification error" will generate.

If acceleration/deceleration is not valid, a "C89 acceleration/deceleration specification error" will generate.



(Note 1) This command is valid on arbitrary orthogonal planes. (Axis 2 may be selected automatically prior to axis 1 in accordance with the position data.)

[Example] VEL 100 Set the speed to 100 mm/sec.
 ARCC 100 120 Move along an arc from the position origin for a center angle of 120 degrees around position No. 100 being the center (CCW direction).

(Note 2) The rotating direction of the actual operation locus varies depending on whether the system is of gate type or cantilever type. Be sure to perform test operation to check the rotating direction.


● PBNB (Set positioning band)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PBNB	Axis pattern	Distance	CP

[Function] Set the positioning completion band for the axes in the axis pattern specified in operand 1. The distance in operand 2 is set in mm.

As a rule, positioning is deemed complete when all command pulses have been output and the current position is inside the positioning band. Therefore, this command is effective if you wish to reduce the tact time by shortening the approximate positioning settling time. (Normally a setting of approx. 3 to 5 mm will have effect, but the effect must be confirmed on the actual machine.)

(This command can be combined with a QRTN command for special purposes. Refer to the section on QRTN command for details.)



- (Note 1) If positioning band is not set with a PBNB command, the value set in "Axis-specific parameter No. 58, Positioning band" will be used.
- (Note 2) If the positioning band is changed, the new setting will remain valid even after the program ends. Therefore, to build a system using PBNB commands, a positioning band must be expressly specified with a PBNB command before operation of each program. An assumption that the positioning band will be reset to the original value when the operation ends in other program may lead to an unexpected problem, because the positioning band will become different from what is anticipated in case the applicable program is aborted due to error, etc.
- (Note 3) The value set in "Axis-specific parameter No. 58, Positioning band" will not be written by a PBNB command.

[Example 1] PBNB 11 5 Set the positioning band for axes 1 and 2 to 5 mm after this command.

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
11 (binary) → 3 (decimal)
LET 1 3 Assign 3 to variable 1.
PBNB *1 5



● CIR (Move along circle)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CIR	Passing position 1 number	Passing position 2 number	PE

[Function] Move along a circle originating from the current position and passing the positions specified in operands 1 and 2.

Therefore, reversing the settings of operands 1 and 2 will implement a circular movement in the reverse direction.

The output will turn OFF at the start of circular movement, and turn ON when the movement is complete.

Difference from CIR2:

CIR processing resembles moving along a polygon with a PATH command, while CIR2 actually performs arc interpolation.

Select an applicable command by considering the characteristics of each command.

(Normally CIR2 is used.)

(Note 1) If the division angle is set to "0" with a DEG command (division angle is calculated automatically based on priority speed setting), the speed set in the data at passing position 1 or speed set by a VEL command will be used (former is given priority). The speed set in the data at passing position 2 will have no meaning.

(Note 2) If the division angle is set to a value other than "0" with a DEG command (normal division angle), the speed specified in the target position data will be used. (The speed set by a VEL command will become valid if position data is not specified.)
In the case of circular movement, the axes will return from passing position 2 to the start position at the speed declared by a VEL command. Therefore, a VEL command must always be used with a CIR command.

(Note 3) The acceleration is selected in the order of the acceleration in the data at passing position 1, followed by the value in "All-axis parameter No. 11, Default acceleration."
The deceleration will become the same value as the valid acceleration selected above.
Therefore, the deceleration in the data at passing position 1 and the acceleration/deceleration in the data at passing position 2 will not have any meaning.

(Note 4) This command is valid on arbitrary orthogonal planes. (Axis 2 may be selected automatically prior to axis 1 in accordance with the position data.)

[Example 1] VEL 100 Set the speed to 100 mm/sec.
 CIR 100 101 Move along a circle from the current position by passing
 positions 100 and 101 sequentially.

[Example 2] LET 1 5 Assign 5 to variable 1.
 LET 2 6 Assign 6 to variable 2.
 CIR *1 *2 Move along a circle from the current position by passing the
 contents of variables 1 and 2 (positions 5 and 6)
 sequentially.

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARC	Passing position number	End position number	PE

The output will turn OFF at the start of arc movement, and turn ON when the movement is complete.

ARC processing resembles moving along a polygon with a PATH command, while ARC2 actually performs arc interpolation.

(Note 1) If the division angle is set to "0" with a DEG command (division angle is calculated automatically based on priority speed setting), the speed set in the data at passing position 1 or speed set by a VEL command will be used (former is given priority). The speed set in the data at passing position 2 will have no meaning.

(Note 3) The acceleration is selected in the order of the acceleration in the data at passing position 1, followed by the value in “All-axis parameter No. 11, Default acceleration.”
The deceleration will become the same value as the valid acceleration selected above.
Therefore, the deceleration in the data at passing position 1 and the acceleration/deceleration in the data at passing position 2 will not have any meaning.

[Example 1]	VEL	100		Set the speed to 100 mm/sec.
	ARC	100	101	Move along an arc from the current position to position 101 by passing position 100.

170



1-13 Structural IF

● IFXX (Structural IF)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	IFXX	Variable number	Data	CP

[Function] Compare the content of the variable specified in operand 1 with the value specified in operand 2, and proceed to the next step if the condition is satisfied.
If the condition is not satisfied, the program will proceed to the step next to the corresponding ELSE command, if any, or to the step next to the corresponding EDIF command.
If the input condition is not satisfied and the IFXX command is not executed, the program will proceed to the step next to the corresponding EDIF.
A maximum of 15 nests are supported when ISXX and DWXX are combined.

IFXX			
┌ ├ ├ ├ ├ └	EQ	Operand 1 = Operand 2
	NE	Operand 1 ≠ Operand 2
	GT	Operand 1 > Operand 2
	GE	Operand 1 ≥ Operand 2
	LT	Operand 1 < Operand 2
	LE	Operand 1 ≤ Operand 2

[Example 1]

	VEL	100		Set the speed to 100 mm/sec.
┌600	IFEQ	1	1	Select an axis.
├┌	IFGE	2	0	Select a moving direction.
├├┌	JFWN	01	5	Move axis 1 forward.
├├├┌	ELSE			
├├├├┌	JBWN	01	5	Move axis 1 backward.
├├├├├┌	EDIF			
├├├├├├┌	ELSE			
├├├├├├├┌	IFLT	2	0	Select a moving direction.
├├├├├├├├┌	JBWN	10	5	Move axis 2 backward.
├├├├├├├├├┌	ELSE			
├├├├├├├├├├┌	JFWN	10	5	Move axis 2 forward.
├├├├├├├├├├├┌	EDIF			
├├├├├├├├├├├├┌	EDIF			

Jog by selecting axis 1/axis 2 by variable 1 and forward/backward (+/–) by variable 2.
Nothing will happen if flag 600 is OFF, in which case the program will proceed to the step next to the last EDIF.

(Note) Using a GOTO command to branch out of or into an IFXX-EDIF syntax is prohibited.



● ISXX (Compare strings)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ISXX	Column number	Column number, character literal	CP

[Function] Compare the character strings in the columns specified in operands 1 and 2, and proceed to the next step if the condition is satisfied.
If the condition is not satisfied, the program will proceed to the step next to the corresponding ELSE command, if any, or to the step next to the corresponding EDIF command.
Comparison will be performed for the length set by a SLEN command.
If a character literal is specified in operand 2, comparison will be performed for the entire length of the literal.
If the input condition is not satisfied and the ISXX command is not executed, the program will proceed to the step next to the EDIF.
A maximum of 15 nests are supported when IFXX and DWXX are combined.

ISXX
└─ EQ Operand 1 = Operand 2
└─ NE Operand 1 ≠ Operand 2

[Example 1]

VEL	100			Set the speed to 100 mm/sec.
SCPY	10			
			'GOFD' (Move forward)	
SCPY	14			
			'GOBK' (Move backward)	
LET	1	5		
LET	2	14		
600	SLEN	4		Set the number of comparing characters to 4.
	ISEQ	1	'1AXS' (Axis 1)	Select an axis.
	ISEQ	5	10	Select a moving direction.
	JFWN	01	5	Move axis 1 forward.
	ELSE			
	JBWN	01	5	Move axis 1 backward.
	EDIF			
	ELSE			
	ISNE	*1	*2	Select a moving direction.
	JFWN	10	5	Move axis 2 backward.
	ELSE			
	JBWN	10	5	Move axis 2 forward.
	EDIF			
	EDIF			

Jog by selecting axis 1/axis 2 by columns 1 to 4 and forward/backward by columns 5 to 8.
Nothing will happen if flag 600 is OFF, in which case the program will proceed to the step next to the last EDIF.
If columns 1 to 8 contain the following data, axis 1 will be moved forward.

1	2	3	4	5	6	7	8
1A	XS	GO	FD				

(Note) Using a GOTO command to branch out of or into an ISXX-EDIF syntax is prohibited.



- ELSE (Else)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	ELSE	Prohibited	Prohibited	CP

[Function] An ELSE command is used arbitrarily in conjunction with an IFXX or ISXX command to declare the command part to be executed when the condition is not satisfied.

[Example 1] Refer to the sections on IFXX and ISXX.

- EDIF (End IFXX)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	EDIF	Prohibited	Prohibited	CP

[Function] Declare the end of an IFXX or ISXX command.

[Example 1] Refer to the sections on IFXX and ISXX.

- DWXX (DO WHILE)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	DWXX	Variable number	Data	CP

DWXX			
	EQ	Operand 1 = Operand 2
	NE	Operand 1 \neq Operand 2
	GT	Operand 1 > Operand 2
	GE	Operand 1 \geq Operand 2
	LT	Operand 1 < Operand 2
	LE	Operand 1 \leq Operand 2

If DWXX is specified at the start and input 8 is OFF, nothing will occur and the program will proceed to the step next to EDDO.

(Note) Using a GOTO command to branch out of or into a DWXX-EDDO syntax is prohibited.

- LEAV (Pull out of DO WHILE)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	LEAV	Prohibited	Prohibited	CP

[Example 1]	DWEQ	1	0	Repeat the commands up to an EDDO command while variable 1 contains '0.'
-------------	------	---	---	--

174



● ITER (Repeat)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ITER	Prohibited	Prohibited	CP

[Function] Forcibly switch the control to EDDO while in a DOXX loop.

[Example 1]

	DWEQ	1	0	← Repeat the commands up to an EDDO command while variable 1 contains "0."
	:			
600	ITER			
	:			
→	EDDO			Forcibly switch the control to an EDDO command and perform end judgment, if flag 600 is ON.

● EDDO (End DO WHILE)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	EDDO	Prohibited	Prohibited	CP

[Function] Declare the end of a loop that began with DWXX.
If the DWXX condition is not satisfied, the program will proceed to the step next to this command.

[Example 1] Refer to the section on DWXX.



1-15 Multi-Branching

● SLCT (Start selected group)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SLCT	Prohibited	Prohibited	CP

[Function] Branch to the step next to any WHXX or WSXX command that exists before an EDSL command and whose condition is satisfied, or to the step next to an OTHE command if none of the conditions are satisfied.
A SLCT command must be followed by a WHXX, WSXX or EDSL command.
A maximum of 15 nests are supported.

(Note) Using a GOTO command to branch out of or into a SLCT-EDSL syntax is prohibited.

[Example 1]

	SCPY	1	'Right'	Assign 'right' to columns 1 and 2.
	:			
600	SLCT			Jump to a WXXX whose condition is satisfied.
	WSEQ	1	'Right'	If 'right' is stored in columns 1 and 2, this command will be executed.
	:			
	WSEQ	1	'Left'	If 'left' is stored, this command will be executed.
	:			
	OTHE			If the content of columns 1 and 2 is neither of the above, this command will be executed.
	:			
	EDSL			If flag 600 is OFF, the processing will move here upon execution of any of the conditions.



● WHXX (Select if true; variable)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	WHXX	Variable number	Data	CP

[Function] This command is used between SLCT and EDSL commands to execute the subsequent commands up to the next WXXX command or an OTHE or EDSL command when the comparison result of the content of the variable specified in operand 1 with the value specified in operand 2 satisfies the condition.

WHXX			
	EQ	Operand 1 = Operand 2
	NE	Operand 1 ≠ Operand 2
	GT	Operand 1 > Operand 2
	GE	Operand 1 ≥ Operand 2
	LT	Operand 1 < Operand 2
	LE	Operand 1 ≤ Operand 2

[Example 1]

LET	1	20	Assign 20 to variable 1.
LET	2	10	Assign 10 to variable 2.
:			
SLCT			Execute multi-branching.
WHEQ	1	10	[1] will be executed if the content of variable 1 is 10.
:			Since variable 1 contains 20, however, the next
[1]			condition will be referenced.
:			
WHGT	1	*2	This command will be executed if the content of variable
:			1 is greater than the content of variable 2.
			Since variable 1 (= 20) > variable 2 (=10), [2] will be
			executed.
[2]			
:			
OTHE			This command will be executed if none of the conditions
:			are satisfied. In this example, since [2] was executed,
			[3] will not be executed.
[3]			
:			
EDSL			The processing will move here if any of the conditions
:			was satisfied and the applicable command executed. In
(4)			this example, [2] and [4] will be executed.
:			

* If multiple conditions are likely to be satisfied, remember that the first WXXX will become valid and any subsequent commands will not be executed. Therefore, state from the command with the most difficult condition or highest priority.



● WSXX (Select if true; character)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	WSXX	Column number	Column number, character literal	CP

[Function] This command is used between SLCT and EDSL commands to execute the subsequent commands up to the next WXXX command or an OTHE or EDSL command when the comparison result of the character strings in the columns specified in operands 1 and 2 satisfies the condition.

Comparison will be performed for the length set by a SLEN command.

If a character literal is specified in operand 2, comparison will be performed for the entire length of the literal.

WSXX

└─ EQ Operand 1 = Operand 2
└─ NE Operand 1 ≠ Operand 2

[Example 1]

SLEN	3		Set the number of comparing characters to 3.
SCPY	1	'ABC'	Assign 'ABC' to column 1.
LET	1	2	Assign 2 to variable 1.
:			
SLCT			Execute multi-branching.
WSEQ	1	'XYZ'	[1] will be executed if columns 1 to 3 contain 'XYZ.'
:			Since columns 1 to 3 contain 'ABC,' however, this command will not be executed.
[1]			
:			
WSEQ	2	*1	[2] will be executed if the content of the number of characters specified by SLEN after column 2 is the same as the content of the column specified in variable 1.
:			
[2]			
:			
OTHE			This command will be executed if none of the conditions are satisfied. In this example, since [2] was executed, [3] will not be executed.
:			
[3]			
:			
EDSL			The processing will move here if any of the conditions was satisfied and the applicable command executed. In this example, [2] and [4] will be executed.
:			
[4]			
:			

* If multiple conditions are likely to be satisfied, remember that the first WXXX will become valid and any subsequent commands will not be executed. Therefore, state from the command with the most difficult condition or highest priority.



- OTHE (Select other)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	OTHE	Prohibited	Prohibited	CP

[Function] This command is used between SLCT and EDSL commands to declare the command to be executed when none of the conditions are satisfied.

[Example 1] Refer to the sections on SLCT, WHXX and WSXX.

- EDSL (End selected group)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	EDSL	Prohibited	Prohibited	CP

[Function] Declare the end of a SLCT command.

[Example 1] Refer to the sections on SLCT, WHXX and WSXX.



1-16 System Information Acquisition

● AXST (Get axis status)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	AXST	Variable number	Axis number	CP

[Function] Store in the variable specified in operand 1 the status (axis error number) of the axis specified in operand 2.

(Note 1) If the obtained result is "0," it means no axis error is present.

(Note 2) Since the error lists are written in hexadecimal, they must be converted to decimals.

[Example] AXST 1 2 Read the error number for axis 2 to variable 1.

If 3188 (decimal) is stored in variable 1 after the execution of this command:

$$3188 \div 16 = 199 \text{ } \dots 4$$

$$199 \div 16 = 12 (= C) \text{ } \dots 7$$

$$\begin{aligned} 3188 &= 12 (= C) \times 16^2 + 7 \times 16^1 + 4 \\ &= C74 \text{ (HEX) (Hexadecimal number)} \end{aligned}$$

Therefore, an "Error No. C74, Actual-position soft limit over error" is present.



● PGST (Get program status)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PGST	Variable number	Program number	CP

[Function] Store in the variable specified in operand 1 the status (program error number) of the program specified in operand 2.

(Note 1) If the obtained result is "0," it means no program error is present.

(Note 2) Although the error lists are written in hexadecimal, the status to be stored (program error number) is a decimal. Therefore, the decimal program error numbers must be converted to hexadecimal.

[Example] PGST 1 2 Read the error number for program No. 2 to variable 1.



● SYST (Get system status)


Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SYST	Variable number	Prohibited	CP

[Function] Store the system status (top-priority system error number) in the variable specified in operand 1.

(Note 1) If the obtained result is “0,” it means no system error is present.

(Note 2) Since the error lists are written in hexadecimal, they must be converted to decimals.

(Note 3) Relationship of error statuses



* An axis error that generates during operation with a program command will be registered both as a program error and an axis error.

[Example] SYST 1 Read the system error number to variable 1.



1-17 Zone

● WZNA (Wait for zone ON, with AND)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WZNA	Zone number	Axis pattern	CP

[Function] Wait for the zone status of all axes (AND) specified by the axis pattern in operand 2 to become ON (inside zone) with respect to the zone specified in operand 1.

(Note 1) The zone status of axes not yet completing home return will remain OFF (outside zone).

(Note 2) A maximum of four areas can be set as zones for each axis ("Axis-specific parameter Nos. 86 to 97").

(Note 3) Zone output can be specified using "Axis-specific parameter Nos. 88, 91, 94 and 97" irrespective of this command.

[Example 1] WZNA 1 11 If the parameters are set as follows, the program will wait until the zone status of axes 1 and 2 becomes ON (inside the shaded area shown in the diagram below).


[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:

11 (binary) → 3 (decimal)

LET 5 3 Assign 3 to variable 5.

WZNA 1 *5

	Axis 1	Axis 2
“Axis-specific parameter No. 86, Zone 1 max.” (Value is set in units of 0.001 mm)	300000	200000
“Axis-specific parameter No. 87, Zone 1 min.” (Value is set in units of 0.001 mm)	150000	100000





● WZNO (Wait for zone ON, with OR)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WZNO	Zone number	Axis pattern	CP

[Function] Wait for the zone status of any of the axes (OR) specified by the axis pattern in operand 2 to become ON (inside zone) with respect to the zone specified in operand 1.

(Note 1) The zone status of axes not yet completing home return will remain OFF (outside zone).


(Note 2) A maximum of four areas can be set as zones for each axis ("Axis-specific parameter Nos. 86 to 97").

(Note 3) Zone output can be specified using "Axis-specific parameter Nos. 88, 91, 94 and 97" irrespective of this command.

[Example 1] WZNO 1 11 If the parameters are set as follows, the program will wait until the zone status of axes 1 or 2 becomes ON (inside the shaded area shown in the diagram below).

[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:
11 (binary) → 3 (decimal)
LET 5 3 Assign 3 to variable 5.
WZNO 1 *5

	Axis 1	Axis 2
“Axis-specific parameter No. 86, Zone 1 max.” (Value is set in units of 0.001 mm)	300000	200000
“Axis-specific parameter No. 87, Zone 1 min.” (Value is set in units of 0.001 mm)	150000	100000





● WZFA (Wait for zone OFF, with AND)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WZFA	Zone number	Axis pattern	CP

[Function] Wait for the zone status of all axes (AND) specified by the axis pattern in operand 2 to become OFF (outside zone) with respect to the zone specified in operand 1.

(Note 1) The zone status of axes not yet completing home return will remain OFF (outside zone).

(Note 2) A maximum of four areas can be set as zones for each axis ("Axis-specific parameter Nos. 86 to 97").

(Note 3) Zone output can be specified using "Axis-specific parameter Nos. 88, 91, 94 and 97" irrespective of this command.

[Example] WZFA 1 11 If the parameters are set as follows, the program will wait until the zone status of axes 1 and 2 becomes OFF (inside the shaded area shown in the diagram below)


[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:

11 (binary) → 3 (decimal)

LET 5 3 Assign 3 to variable 5.

WZFA 1 *5

	Axis 1	Axis 2
“Axis-specific parameter No. 86, Zone 1 max.” (Value is set in units of 0.001 mm)	300000	200000
“Axis-specific parameter No. 87, Zone 1 min.” (Value is set in units of 0.001 mm)	150000	100000





● WZFO (Wait for zone OFF, with OR)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WZFO	Zone number	Axis pattern	CP

[Function] Wait for the zone status of any of the axes (OR) specified by the axis pattern in operand 2 to become OFF (outside zone) with respect to the zone specified in operand 1.

(Note 1) The zone status of axes not yet completing home return will remain OFF (outside zone).

(Note 2) A maximum of four areas can be set as zones for each axis ("Axis-specific parameter Nos. 86 to 97").

(Note 3) Zone output can be specified using "Axis-specific parameter Nos. 88, 91, 94 and 97" irrespective of this command.

[Example 1] WZFO 1 11 If the parameters are set as follows, the program will wait until the zone status of axes 1 or 2 becomes OFF (inside the shaded area shown in the diagram below).


[Example 2] The axis pattern can be specified indirectly using a variable.
When the command in [Example 1] is rephrased based on indirect specification using a variable:

11 (binary) → 3 (decimal)

LET 5 3 Assign 3 to variable 5.

WZFO 1 *5

	Axis 1	Axis 2	
{	"Axis-specific parameter No. 86, Zone 1 max." 300000	200000	}
	(Value is set in units of 0.001 mm)		
{	"Axis-specific parameter No. 87, Zone 1 min." 150000	100000	}
	(Value is set in units of 0.001 mm)		





1-18 Communication

● OPEN (Open channel)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OPEN	Channel number	Prohibited	CP

[Function] Open the channel specified in operand 1.
The specified channel will be enabled to send/receive hereafter.
Prior to executing this command, a SCHA command must be used to set an end character.

[Example] SCHA 10
 OPEN 1
 Specify 10 (= LF) as the end character.
 Open channel 1.

Note: If "OPEN 1" is executed, the teaching-pendant connector (D-sub, 25-pin) will be disconnected. (This is because channel 1 is shared by the teaching pendant/PC software.)

● CLOS (Close channel)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CLOS	Channel number	Prohibited	CP

[Function] Close the channel specified in operand 1.
The specified channel will be disabled to send/receive hereafter.

[Example] CLOS 1
 Close channel 1.

 LET 1 2
 CLOS *1
 Assign 2 to variable 1.
 Close the content of variable 1 (channel 2).



● READ (Read)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	READ	Channel number	Column number	CC

[Function] Read a character string from the channel specified in operand 1 to the column specified in operand 2. Read will end when the character specified by a SCHA command is received. Either a local or global column may be specified. A return code will be stored in a local variable (factory setting: variable 99) immediately after this command is executed. Whether or not the command has been executed successfully can be checked by checking the return code. If necessary, specify the processing to be performed when the command has been aborted due to an error. Specifying "0" in operand 2 will execute a dummy read (clear the receive buffer and disable receive) (return code: successful completion). The tool versions that support "0" input in operand 2 are shown below. Even if "0" cannot be input from a tool, indirect specification is still available.
(Note) Dummy read (operand 2 = 0) is not supported by channel Nos. 31 to 34 (Ethernet option).

[Example]

SCHA	10		Set LF (= 10) as the end character.
OPEN	1		Open channel 1.
READ	1	2	Read a character string from channel 1 to column 2 until LF is received.
TRAN	1	99	Assign the return code (variable 99) to variable 1.
CLOS	1		Close the channel.
SLCT			The program branches to the processing corresponding to each return code.
			(Note) Using a GOTO command to branch out of or into a SLCT-EDSL syntax is prohibited.
WHEQ	1	0	If the content of variable 1 is "0" (successful completion), [1] will be executed. Specify in [1] the processing to be performed upon successful completion.
:			
[1]			
:			
WHEQ	1	1	If the content of variable 1 is "1" (timeout), [2] will be executed. If necessary, specify the applicable processing in [2].
:			
[2]			
:			
WHEQ	11	2	If the content of variable 1 is "2" (timer cancelled), [3] will be executed. If necessary, specify the applicable processing in [3].
:			
[3]			
:			
OTHE			If the content of variable 1 is not "0," "1" or "2," [4] will be executed. If necessary, specify the applicable error handling in [4].
:			
[4]			
:			
EDSL			If any of the conditions is satisfied and the corresponding command is executed, the processing flow will move here.
			:
			(The remainder is omitted.)
			:

● Return code of the READ command

The return code is stored in a local variable. The variable number can be set by "Other parameter No. 24." The default variable number is "99."

- 0: READ completed successfully (Receive complete)
- 1: READ timeout (the timeout value is set by a TMRD command) (Continue to receive)
- 2: READ cancelled due to timer (the waiting status was cancelled by a TIMC command) (Continue to receive)
- 3: READ SCIF overrun error (Receive disabled)
- 4: READ SCIF receive error (framing error or parity error) (Receive disabled)
- 5: READ factor error (program abort error) (Receive disabled)
(Cannot be recognized by SEL commands)
- 6: READ task ended (program end request, etc.) (Receive disabled)
(Cannot be recognized by SEL commands)
- 7: READ SCIF receive error due to other factor (Receive disabled)
- 8: READ expanded-SIO overrun error (Receive disabled)
- 9: READ expanded-SIO parity error (Receive disabled)
- 10: READ expanded-SIO framing error (Receive disabled)
- 11: READ expanded-SIO buffer overflow error (Receive disabled)
- 12: READ expanded-SIO receive error due to other factor (Receive disabled)



● TMRD (Set READ timeout value)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	TMRD	Timer setting	Prohibited	CP

[Function] Set the timeout to be applied to a READ command.
 The timer setting specified in operand 1 will set the maximum time the program will wait for the character string read to end when a READ command is executed.
 If the end character could not be read before the timer is up during the execution of the READ command, a timeout will occur and the program will move to the next step.
 (Whether or not a timeout has occurred can be checked from the return code that will be stored in a local variable (factory setting: variable 99) immediately after the READ command is executed.
 If necessary, specify the processing to be performed upon timeout.)
 Setting the timer to "0" will allow the READ command to wait infinitely, without timeout, until the end character is read.
 The timer setting is input in seconds (setting range: 0 to 99.00 seconds) including up to two decimal places.

(Note) TMRD is set to "0" in the default condition before TMRD setting is performed.

[Example]

SCHA	10		Set LF (=10) as the end character.
TMRD	30		Set the READ timeout value to 30 seconds.
OPEN	1		Open channel 1.
READ	1	2	Read the character string from channel 1 to column 2 until LF is read.
TRAN	1	99	Assign the return code to variable 1.
CLOS	1		Close the channel.
SLCT			The program branches to the processing corresponding to each return code. (Note) Using a GOTO command to branch out of or into a SLCT-EDSL syntax is prohibited.
WHEQ	1	0	If the content of variable 1 is "0" (successful completion), [1] will be executed. Specify in [1] the processing to be performed upon successful completion.
:			
[1]			
:			
WHEQ	1	1	If the content of variable 1 is "1" (timeout), [2] will be executed. If necessary, specify the applicable processing in [2].
:			
[2]			
:			
WHEQ	11	2	If the content of variable 1 is "2" (timer cancelled), [3] will be executed. If necessary, specify the applicable processing in [3].
:			
[3]			
:			
OTHE			If the content of variable 1 is not "0," "1" or "2," [4] will be executed. If necessary, specify the applicable error handling in [4].
:			
[4]			
:			
EDSL			If any of the conditions is satisfied and the corresponding command is executed, the processing flow will move here.

Read completes successfully within 30 seconds → Variable No. 1 = 0

Timeout occurs → Variable No. 1 = 1

* The return code of READ command may not be limited to 0 or 1. The variable to store the return code can be set in "Other parameter No. 24". Refer to the explanation of READ command for details.



● WRIT (Write)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	WRIT	Channel number	Column number	CP

[Function] Write the character string in the column specified in operand 2 to the channel specified in operand 1.

The operation will end when the character specified by a SCHA command is written.
Either a local or global column can be specified.

[Example]	SCHA	10		Set LF (= 10) as the end character.
	OPEN	1		Open channel 1.
	WRIT	1	2	Write the character string in column 2 to channel 1 until LF is written.
	CLOS	1		Close the channel.



- SCHA (Set end character)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SCHA	Character code	Prohibited	CP

[Function] Set the end character to be used by a READ or WRIT command.
Any character from 0 to 255 (character code used in BASIC, etc.) can be specified.

[Example] Refer to the sections on READ and WRIT commands.



1-19 String Operation

● SCPY (Copy character string)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SCPY	Column number	Column number, character literal	CC

[Function] Copy the character string in the column specified in operand 2 to the column specified in operand 1.
Copy will be performed for the length set by a SLEN command.
If a character literal is specified in operand 2, copy will be performed for the entire length of the literal.

[Example] SCPY 1 'ABC' Copy 'ABC' to column 1.
 SLEN 10 Set the copying length to 10 bytes.
 SCPY 100 200 Copy 10 bytes from column 200 to column 100.



Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SCMP	Column number	Column number, character literal	EQ

[Example]	SCMP	1	'ABC'	600	Flag 600 will turn ON if columns 1 to 3 contain 'ABC.'
	SLEN	5			Set the comparing length to five bytes.
	SCMP	10	30	999	Turn ON flag 999 if five bytes from columns 30 and 10 match.



● SGET (Get character)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SGET	Variable number	Column number, character literal	CP

[Function] Assign one character from the column specified in operand 2 to the variable specified in operand 1.

If a character-string literal is specified in operand 2, the first character will be assigned.

[Example] SGET 1 100
Assign one byte from column 100 to variable 1.

LET 1 3 Assign 3 to variable 1.

LET 2 1 Assign 1 to variable 2.

SCPY 1 'A' Copy 'A' to column 1.

SGET *1 *2 Assign 'A' from the content of variable 2 (column 1) to the
content of variable 1 (variable 3).



● SPUT (Set character)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SPUT	Column number	Data	CP

[Function] Set the data specified in operand 2 in the column specified in operand 1.

[Example]

SPUT	5	10	Set 10 (LF) in column 5.
LET	1	100	Assign 100 to variable 1.
LET	2	50	Assign 50 to variable 2.
SPUT	*1	*2	Set the content of variable 2 (50 ('2')) in the content of variable 1 (column 100).



● STR (Convert character string; decimal)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	STR	Column number	Data	CC

[Function] Copy to the column specified in operand 1 a decimal character string converted from the data specified in operand 2.

The data will be adjusted to the length set by a SLEN command.

If the data exceeds the specified length, it will be cut off at the length set by a SLEN command.

If the entire data has been converted within the length set by a SLEN command, the output will turn ON.

(Note) If the data specified in operand 2 is a 10-digit integer including eight or more valid digits, conversion of the values in the eighth and subsequent digits will not be guaranteed (the values through the seventh digits will be converted properly.)

[Example] SLEN 5.3 Set a length consisting of five integer digits and three decimal digits.

STR 1 123 The following values will be set in columns 1 to 9:

1	2	3	4	5	6	7	8	9
		1	2	3	.	0	0	0

LET 1 10 Assign 10 to variable 1.

LET 102 987.6543 Assign 987.6543 to variable 102.

SLEN 2.3 Set a length consisting of two integer digits and three decimal digits.

STR *1 *102 The following values will be set in columns 10 to 15:

10	11	12	13	14	15
8	7	.	6	5	4

Since the data exceeds the specified length, "9" in the 100's place and "3" in the fourth decimal place will be cut off.



● STRH (Convert character string; hexadecimal)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	STRH	Column number	Data	CC

[Function] Copy to the column specified in operand 1 a hexadecimal character string converted from the data specified in operand 2.

Only the integer part will be adjusted to the length set by a SLEN command.

If the data exceeds the specified length, it will be cut off at the length set by a SLEN command.

If the entire data has been converted within the length set by a SLEN command, the output will turn ON.

(Note) If the data specified in operand 2 is a negative value, eight columns will be required to convert the entire data.

[Example] SLEN 5 Set a format consisting of five integer digits.
 STRH 1 255 The following values will be set in columns 1 to 5:

1	2	3	4	5
			E	F

LET 1 10 Assign 10 to variable 1.
LET 102 987.6543 Assign 987.6543 to variable 102.
SLEN 2.3 Set a length consisting of two integer digits and three
 decimal digits.
STRH *1 *102 The following values will be set in columns 10 and 11:

10	11
D	B

“3” in the SLEN command and “.6543” in variable 102, which are the decimal part, will be ignored.

The integer part is expressed as ‘3DB’ in hexadecimal. Since the length is two digits, however, “3” in the third digit will be cut off.



● VAL (Convert character string data; decimal)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	VAL	Variable number	Column number, character literal	CC

[Function] Convert the decimal data in the column specified in operand 2 to a binary and assign the result to the variable specified in operand 1.

Conversion will be performed for the length set by a SLEN command.

If a character-string literal is specified in operand 2, conversion will be performed for the entire length of the literal.

(Note) Keep the converting length to 18 characters or less.

[Example]

SCPY	10	'1234'	Set '1234' in column 10.
SLEN	4		Set the converting length to four bytes.
VAL	1	10	Assign 1234, which is a binary converted from '1234' in column 10, to variable 1.

LET	1	100	Assign 100 to variable 1.
LET	2	20	Assign 20 to variable 2.
SCPY	20	'1234'	Copy '1234' to column 20.
SCPY	24	'.567'	Copy '.567' to column 24.
SLEN	8		Set the converting length to eight bytes.
VAL	*1	*2	Assign 1234.567, which is a binary converted from '1234.567' in the content of variable 2 (column 20) to the content of variable 1 (variable 100).



● VALH (Convert character string data; hexadecimal)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	VALH	Variable number	Column number, character literal	CC

[Function] Convert the hexadecimal data in the column specified in operand 2 to a binary and assign the result to the variable specified in operand 1.
Conversion will be performed for the length set by a SLEN command.
Only the integer part will be converted, with the decimal part being ignored.
If a character-string literal is specified in operand 2, conversion will be performed for the entire length of the literal.

(Note) Keep the converting length to 8 characters or less.

[Example]

SCPY	10	'1234'	Set '1234' in column 10.
SLEN	4		Set the converting length to four bytes.
VALH	1	10	Assign 4660, which is a binary converted from hexadecimal '1234' in column 10, to variable 1.

LET	1	100	Assign 100 to variable 1.
LET	2	20	Assign 20 to variable 2.
SCPY	20	'ABCD'	Copy 'ABCD' to column 20.
SLEN	4		Set the converting length to four bytes.
VALH	*1	*2	Assign 43981, which is a binary converted from hexadecimal 'ABCD' in the content of variable 2 (column 20) to the content of variable 1 (variable 100).



● SLEN (Set length)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	SLEN	Character string length	Prohibited	CP

[Function] Set the length to be processed by a string command.
This must always be set before using the following commands:

SCMP	Decimal part is invalid.
SCPY	Decimal part is invalid.
ISXX	Decimal part is invalid.
WSXX	Decimal part is invalid.
STRH	Decimal part is invalid.
VAL,		
VALH	Decimal part is invalid.
STR	Decimal part is valid.

[Example] Refer to the examples of the above commands:



1-20 Palletizing-Related

● BGPA (Declare start of palletizing setting)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	BGPA	Palletizing number	Prohibited	CP

Declare the start of a palletizing setting.

Once this command is executed, palletizing setting for the palletizing number specified in operand 1 will be enabled.

(In the case of an ACHZ, AEXT, OFAZ or ATRG command, setting is enabled without declaring BGPA.)

The input range of palletizing number is from 1 to 10.

When the palletizing setting is complete, execute EDPA.

Nested BGPAs are not supported. To declare start of another palletizing setting, execute an EDPA command and then execute a BGPA command again.

If the output field is specified, the output will turn ON after this command is executed.

Palletizing numbers are in the local range. Therefore, a given palletizing setting is valid only within the program in which it is set.

(Note) Using a GOTO command to branch out of or into a BGPA-EDPA syntax is prohibited.

● EDPA (Declare end of palletizing setting)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	EDPA	Prohibited	Prohibited	CP

Declare the end of a palletizing setting.

If a palletizing-setting command (excluding BGPA, ACHZ, ATRG, AEXT and OFAZ) is executed before another BGPA is declared following an execution of this command (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- PAPI (Set palletizing counts)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPI	Count	Count	CP

Set counts in the palletizing-axis directions.

The count specified in operand 1 will apply to the preferential-axis (PX-axis) direction, while the count specified in operand 2 will apply to the PY-axis direction.

If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.

- PAPN (Set palletizing pattern)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPN	Pattern number	Prohibited	CP

Set a palletizing pattern.

The palletizing pattern specified in operand 1 will be set (1 = Pattern 1, 2 = Pattern 2).

If this command is not declared, pattern 1 will be used.

If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- PASE (Declare palletizing axes)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PASE	Axis number	Axis number	CP

Set the two axes to be used in palletizing (PX and PY-axes).

The axis specified in operand 1 will be set as the preferential axis (PX-axis).

The axis specified in operand 2 will be set as the PY-axis.

This command is used in conjunction with PAPT and PAST.

It cannot be used together with a 3-point teaching (PAPS) command. Whichever is set later will be given priority.

It is recommended to use a 3-point teaching (PAPS) command if the palletizing requires high precision.

If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.

- PAPT (Set palletizing pitches)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPT	Pitch	Pitch	CP

Set palletizing pitches.

The value specified in operand 1 will be set as the pitch for the preferential axis (PX-axis), while the value specified in operand 2 will be set as the pitch for the PY-axis.

This command is used in conjunction with PASE and PAST.

If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



● PAST (Set palletizing reference point)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAST	(Position number)	Prohibited	CP

Set the reference point used in palletizing.

If a value is set in operand 1, that position number specified in operand 1 will be used to store the reference point data.

If no value is set in operand 1, the position-number setting for storing reference point data will become invalid.

This command is used in conjunction with PASE and PAPT.

If this command is not set, coordinates (0, 0) are used as the reference point. If this command is set, the set coordinates are used as the reference point in calculating the position coordinates of palletizing points.

Coordinates in both the PX and PY-axis directions must always be set as the reference-point coordinates. If a palletizing movement command such as PMVP or PMVL is executed, however, specification of palletizing Z-axis (PZ-axis) coordinate is optional. If a Z-axis coordinate is specified, movement in the PZ-axis direction will become enabled. Even if PZ-axis coordinate is not specified, operation will still be performed—just that the position will not move in the PZ-axis direction. Note, however, that an error will generate in the following cases: If this command and PZ-axis are set but the PX, PY and PZ-axes are not set as valid axes in the reference point data, an error will generate when position coordinates are calculated. If the palletizing Z-axis is not set and the PX and PY-axes are not set as valid axes in the reference point data, an error will also generate when position coordinates are calculated. “When position coordinates are calculated” means when PAPG (get palletizing calculation data) or any palletizing movement command such as PMVP, PMVL or PACH is executed. If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- PAPS (Set palletizing points) For 3-point teaching

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPS	Position number	Prohibited	CP

Specify the first position number among the three position numbers containing point data, for use in palletizing calculation.

If “n” is set as the position number in operand 1, point n will represent the reference point, point n+1 will represent the end point in the PX-axis direction and point n+2 will represent the end point in the PY-axis direction.

If a PAPS (set palletizing points) command is executed after specifying the axes to be used with a GRP command, the portions applicable to the palletizing axes in the above position data of n, n+1 and n+2 will be used as the palletizing position data. Even if a GRP command is executed in other setting thereafter, no effects will be felt.

If the valid axis pattern of the 3-point teaching data does not match, an error “CB0, Mismatched valid axes and palletizing 3-point teaching data” will generate.

If a palletizing Z-axis (PZ-axis) is already declared, there must be two valid axes excluding the PZ-axis. If a PZ-axis is not declared yet, there must be two or three valid axes. If there are not enough valid axes, an error “CAE, Insufficient valid axes for palletizing 3-point teaching data” will generate. If there are too many valid axes, an error “CAF, Excessive valid axes for palletizing 3-point teaching data” will generate.

This command cannot be used with PASE (set palletizing axes). Whichever is set later will be given priority.

A single PAPS command can substitute PASE, PAPT and PAST.

If this command is executed before BGPA is declared (= while palletizing setting is not enabled), an error, “CB5, BGPA not declared at palletizing setting” will generate.

If the output field is specified, the output will turn ON after this command is executed.



● PSLI (Set zigzag)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PSLI	Offset amount	(Count)	CP

Set a zigzag palletizing.

The value specified in operand 1 will be set as the offset amount for even-numbered rows.

The count specified in operand 2 will be set as the count for even-numbered rows.

(Refer to (3) "Palletizing Setting" – (d) "Zigzag setting" under "How to Use.")

If operand 2 is not specified, the count for even-numbered rows will become the same as the count for odd-numbered rows.

If a setting is performed by 3-point teaching with PAPS (set palletizing points), the PX and PY-axes need not be parallel with the physical axes. In this case, the offset will apply in parallel with the PX-axis. If the offset is a positive value, the absolute value of offset will be applied toward the end-point direction of the PX-axis. If the offset is a negative value, the absolute value will be applied toward the start-point direction.

If this command is executed before a BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- PCHZ (Declare palletizing Z-axis) Only when there are at least three axes.

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PCHZ	(Axis number)	Prohibited	CP

Specify the axis number representing the palletizing Z direction.

The axis number specified in operand 1 will be set as the axis number representing the palletizing Z direction.

If operand 1 is not specified, the specification of palletizing Z-axis that was already declared will become invalid.

If this command is executed before a BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.




- PTRG (Set palletizing arch triggers)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PTRG	Position number	Position number	CP

Set the arch triggers to be used for arch motion along the palletizing points.

(This setting becomes valid when a PACH command is executed.)

Set the palletizing Z-axis (PZ-axis) position data in the point data specified in operand 1 as the palletizing start-point arch trigger, and set the PZ-axis position data in the point data specified in operand 2 as the palletizing end-point arch trigger.



(Refer to "Palletizing Setting" – "Palletizing arch triggers" under "How to Use.")

As for the point data, the PZ-axis data specified by a PCHZ command must be valid.

For an arch-motion operation along the palletizing points, set it so that a horizontal movement will begin when the start-point arch trigger is reached during ascent from the start point, and that the end-point arch trigger will be reached after a horizontal movement is completed during descent.

If this command is executed before a BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- PEXT (Set palletizing composition)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PEXT	(Position number)	Prohibited	CP

Set palletizing composition.

The position number specified in operand 1 will be set for use in composition.

When a palletizing movement command is executed, the data of any valid axes other than the PX, PY (and PZ)-axes in the specified point data will comprise the end-point coordinates of the composite axis.

If operand 1 is not specified, the position number for composition setting that was already declared will become invalid.

If this command is executed before a BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.

- OFPZ (Set palletizing Z-axis offset)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OFPZ	Offset value	Prohibited	CP

Set the offset in the palletizing Z-axis direction.

The value specified in operand 1 will be set as the offset in the palletizing Z-axis direction.

The offset amount is set in mm and the effective resolution is 0.001 mm.

A negative value can also be specified as the offset, as long as the operation range will not be exceeded.

This offset is valid only at the end point of PACH (palletizing-point arch motion) operation.

If this command is executed before a BGPA is declared (= while palletizing setting is not enabled), an error will generate.

If the output field is specified, the output will turn ON after this command is executed.



- ACHZ (Declare arch-motion Z-axis)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ACHZ	Axis number	Prohibited	CP

Specify the axis number representing the arch-motion Z direction.

The axis number specified in operand 1 will be set as the axis number representing the arch-motion Z direction.

If the output field is specified, the output will turn ON after this command is executed.




- ATRG (Set arch triggers)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ATRG	Position number	Position number	CP

Set the arch triggers used for arch motion.

(This setting becomes valid when an ARCH command is executed.)

Set the arch-motion Z-axis position data in the point data specified in operand 1 as the start-point arch trigger, and set the arch-motion Z-axis position data in the point data specified in operand 2 as the end-point arch trigger.



(Refer to “Palletizing Setting” – “Arch triggers” under “How to Use.”)

For an arch-motion operation, set it so that a horizontal movement will begin when the start-point arch trigger is reached during ascent from the start point, and that the end-point arch trigger will be reached after a horizontal movement is completed during descent.

If the output field is specified, the output will turn ON after this command is executed.



- AEXT (Set arch-motion composition)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	AEXT	(Position number)	Prohibited	CP

Set arch-motion composition.

The position number specified in operand 1 will be set for use in composition.

When an arch motion is executed, the data of valid axes in the point data specified in this command, except for the data of valid axes in the arch-motion end-point data as well as the arch-motion Z-axis data, will comprise the end-point coordinates of the composite axis.

If operand 1 is not specified, the position number for composition setting that was already declared will become invalid.

If the output field is specified, the output will turn ON after this command is executed.

- OFAZ (Set arch-motion Z-axis offset)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	OFAZ	Offset value	Prohibited	CP

Set the offset in the arch-motion Z-axis direction.

The value specified in operand 1 will be set as the offset in the arch-motion Z-axis direction.

The offset amount is set in mm and the effective resolution is 0.001 mm.

A negative value can also be specified as the offset, as long as the operation range will not be exceeded.

This offset is valid only at the end point of ARCH (arch motion) operation.

If the output field is specified, the output will turn ON after this command is executed.



1-21 Palletizing Calculation Command

● PTNG (Get palletizing position number)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PTNG	Palletizing number	Variable number	CP

Assign the palletizing position number for the palletizing number specified in operand 1 to the variable specified in operand 2.

If the output field is specified, the output will turn ON after this command is executed.

● PINC (Increment palletizing position number by 1)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PINC	Palletizing number	Prohibited	CC

Increment by 1 the palletizing position number for the palletizing number specified in operand 1.

If the incremented value is considered normal as a palletizing position number calculated under the current palletizing setting, the value will be updated. If not, the value will not be updated.

If the output field is specified, the output will turn ON when the value was successfully incremented, and turn OFF if the increment failed.



- PDEC (Decrement palletizing position number by 1)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PDEC	Palletizing number	Prohibited	CC

Decrement by 1 the palletizing position number for the palletizing number specified in operand 1.
If the decremented value is considered normal as a palletizing position calculated under the current palletizing setting, the value will be updated. If not, the value will not be updated.
If the output field is specified, the output will turn ON when the value was successfully decremented, and turn OFF if the decrement failed.

- PSET (Set palletizing position number directly)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PSET	Palletizing number	Data	CC

Set the value specified in operand 2 as the palletizing position number for the palletizing number specified in operand 1.
If the specified value is considered normal as a palletizing position calculated under the current palletizing setting, the value will be set. If not, the value will not be set.
If the output field is specified, the output will turn ON when the palletizing position number was successfully updated, and turn OFF if the update failed.



- PARG (Get palletizing angle)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PARG	Palletizing number	Axis number	CP

Obtain the palletizing angle.

Calculate the palletizing angle (degrees) from the physical axis specified in operand 2 for the palletizing number specified in operand 1, and store the result in variable 199.

This command need not be executed, if not necessary.

If this command is executed after PAPS (set 3 palletizing points for teaching) is executed, the angle formed by the preferential axis and the specified physical axis will be calculated automatically. If this command is executed before PAPS is executed, or after both PAPS and PASE are executed in this order, an error will generate.

The axes to be used can be specified with a GRP command before PAPS is executed (refer to the detailed explanation of PAPS). If the valid axis pattern of the 3-point teaching data does not match, an error "CB0, Mismatched valid axes and palletizing 3-point teaching data" will generate.

If the number of valid point-data axes (the number of valid axes excluding the PZ-axis, if a palletizing Z-axis (PZ-axis) has already been declared) is less than two, an error "CAE, Insufficient valid axes for palletizing 3-point teaching data" will generate. If the number of valid point-data axes is more than two, an error "CB9, PX/PY-axes indeterminable when obtaining palletizing angle" will generate.

If the axis number specified in operand 2 is neither of the two valid axes in the point data excluding the PZ-axis, an error "CBA, Reference axis and PX/PY-axes mismatch when obtaining palletizing angle" will generate.

If the reference point among the three teaching points is the same as the point data at the PX-axis end point other than the PZ-axis component, an error "Reference point and PX-axis end point identical when obtaining palletizing angle" will generate, and angle calculation will be disabled.

The actual operating direction may have been reversed depending on the mechanism of the rotating axis and the setting of axis-specific parameter No. 6, "Operating-direction reversing selection." To use the value obtained by this command, be sure to confirm the actual operating direction.

If the output field is specified, the output will turn ON after this command is executed.

- PAPG (Get palletizing calculation data)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PAPG	Palletizing number	Position number	CP

Store the position coordinate data of the palletizing points for the palletizing number specified in operand 1, in the position number specified in operand 2.

If the output field is specified, the output will turn ON after this command is executed.



1-22 Palletizing Movement Command

● PMVP (Move to palletizing points via PTP)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PMVP	Palletizing number	(Position number)	PE

Move to the calculated palletizing points via PTP.

The axes will move to the palletizing points specified in operand 1, via PTP.

If the palletizing points are valid only for the PX/PY-axes (when palletizing Z-axis (PZ-axis) is not specified, etc.), movement in directions other than the PX/PY-axis directions will not be performed. If the PZ-axis coordinates of the palletizing points are also valid, movement in the PZ-axis direction will also be performed. However, if a position number is specified in operand 2, the PZ-direction position will move to the height of the specified position number by ignoring the palletizing calculation (only when three or more axes are available). Any data other than PZ-axis data contained in the position number specified in operand 2 will be ignored.

Absence of Z-axis data will be handled as an error.

If palletizing composition is set, any axes other than the PX, PY (and PZ)-axes will also be operated if data is available for such axes.

Executing this command will not increment the palletizing position number by 1.

Before specifying operand 2, a palletizing Z-axis must have been declared (PCHZ) in the palletizing setting.

If palletizing Z-axis has not been declared, an error will generate.



- PMVL (Move to palletizing points via interpolation)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PMVL	Palletizing number	(Position number)	PE

Move to the calculated palletizing points via interpolation.

The axes will move to the palletizing points specified in operand 1, via interpolation.

If the palletizing points are valid only for the PX/PY-axes (when palletizing Z-axis (PZ-axis) is not specified, etc.), movement in directions other than the PX/PY-axis directions will not be performed. If the PZ-axis coordinates of the palletizing points are also valid, movement in the PZ-axis direction will also be performed. However, if a position number is specified in operand 2, the PZ-direction position will move to the height of the specified position number by ignoring the palletizing calculation (only when three or more axes are available). Any data other than PZ-axis data contained in the position number specified in operand 2 will be ignored.

Absence of Z-axis data will be handled as an error.

If palletizing composition is set, any axes other than the PX, PY (and PZ)-axes will also be operated if data is available for such axes.

Executing this command will not increment the palletizing position number by 1.

Before specifying operand 2, a palletizing Z-axis must have been declared (PCHZ) in the palletizing setting.


If palletizing Z-axis has not been declared, an error will generate.

● PACH (Palletizing-point arch motion)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	PACH	Palletizing number	Position number	PE

Perform arch motion from the current point and move to the palletizing points.

- Move to the palletizing points specified in operand 1, via arch motion.
- Movements in the PX/PY-axis directions will begin after rising from the current point to the palletizing start-point arch trigger. After the Z point specified in operand 2 (as the highest point) is passed and movements in the PX/PY-axis directions are complete, the axes will pass near the palletizing end-point arch trigger and reach the calculated palletizing point.
- Palletizing arch triggers must have been set using a PTRG command.



```

PCHZ      3
PTRG      11      13
.
.
PACH      1      12

```

* When the operation is resumed after a pause, depending on the position where the operation is resumed the locus may follow the lines (dotted lines) indicated by asterisks in the diagram for the composite section from ascent to horizontal movement or from horizontal movement to descent. Be careful not to cause interference.

- The PZ-axis coordinate of the end point will become the PZ-axis component of the position coordinates of the palletizing point, if any, plus the palletizing Z-axis offset. If there is no PZ component, the PZ-axis coordinate of the end point will become the PZ-axis coordinate of the start point plus the palletizing Z-axis offset. (Normally the offset is added to all palletizing positions, such as the arch triggers and Z point.)
- An error will generate if the palletizing start-point arch trigger is set below the start point or the palletizing end-point arch trigger is set below the end point. (Note: Up/down has nothing to do with +/- on the coordinate system.)
- The PZ-axis up direction refers to the direction toward the Z point from the start point (the down direction refers to the opposite direction), and has nothing to do with the size of coordinate value. Therefore, be sure to confirm the actual operating direction when using this command.
- The PZ-axis will come down after a rise-process command value is output. Therefore, the operation may follow the locus shown below depending on the settings of palletizing arch-trigger points and Z point:




Fig. 5

In this case, change the palletizing arch triggers and Z point to increase the operation efficiency.


- If palletizing composition is set, axes other than the PX, PY and PZ-axes will also be operated if data is available for such axes. However, the composite axis will start/end operation at positions above the arch triggers.
- Executing this command will not increment the palletizing position number by 1.

ARCH (Arch motion)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	ARCH	Position number	Position number	PE

Perform arch motion from the current point and move to the specified points.

- Move to the points specified in operand 1, via arch motion.
- Movements in directions other than the arch-motion Z-axis direction will begin after rising from the current point to the start-point arch trigger. After the Z point specified in operand 2 (as the highest point) is passed and movements in directions other than the arch-motion Z-axis direction are complete, the axes will pass near the end-point arch trigger and reach the specified point.
- Palletizing arch triggers must be set using an ATRG command.



- * When the operation is resumed after a pause, depending on the position where the operation is resumed the locus may follow the lines (dotted lines) indicated by asterisks in the diagram for the composite section from ascent to horizontal movement or from horizontal movement to descent. Be careful not to cause interference.
- The arch-motion Z-axis coordinate of the end point will become the arch-motion Z-axis component of the point data specified in operand 1, if any, plus the arch-motion Z-axis offset. If there is no arch-motion Z component, the arch-motion Z-axis coordinate of the end point will become the arch-motion Z-axis coordinate of the start point plus the arch-motion Z-axis offset. (Normally the offset is added to all arch-motion positions, such as the arch triggers and Z point.)
- An error will generate if the start-point arch trigger is set below the start point or the end-point arch trigger is set below the end point. (Note: Up/down has nothing to do with +/- on the coordinate system.)
- The arch-motion Z-axis up direction refers to the direction toward the Z point from the start point (the down direction refers to the opposite direction), and has nothing to do with the size of coordinate value. Therefore, be sure to confirm the actual operating direction when using this command.



- The arch-motion Z-axis will come down after a rise-process command value is output. Therefore, the operation may follow the locus in Fig. 5 given in the aforementioned explanation of PACH command, depending on the settings of arch-trigger points and Z point. In this case, change the arch triggers and Z point to increase the operation efficiency.
- As for the arch-trigger end-point data, if there is any valid axis data other than the data of the arch-motion Z-axis, then operation will be started/ended for the applicable axes in the same manner—but above the arch triggers.
- If arch-trigger composition is set, any valid axes other than those set in the end-point data or the arch-motion Z-axis will also be operated as long as data is available for such axes. In this case, operation of the applicable axes will also be started/ended above the arch triggers.



1-23 Building of Pseudo-Ladder Task

● CHPR (Change task level)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Optional	Optional	CHPR	0 or 1	Prohibited	CP

[Function] Specify “1” (User HIGH) if you wish the target task to be processed before other tasks. This command can also be used with non-ladder tasks.
Task level change (0: User NORMAL, 1: User HIGH) is not a required component, but specifying User HIGH will require a TSLP command explained below. (Without TSLP, tasks of the User NORMAL level will not be processed.)

● TPCD (Specify processing to be performed when input condition is not specified)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	TPCD	0 or 1	Prohibited	CP

[Function] Specify the processing to be performed when input condition is not specified.
(0: Execute, 1: Follow the input condition in the last executed step)
In a ladder task, always input “1” (Follow the input condition in the last executed step) in operand 1.
In a non-ladder task, always input “0” (Execute). (The default value is “0.”)



- TSLP (Task sleep)

Extension condition (LD, A, O, AB, OB)	Input condition (I/O, flag)	Command, declaration			Output (Output, flag)
		Command, declaration	Operand 1	Operand 2	
Prohibited	Prohibited	TSLP	Time	Prohibited	CP

[Function] Set the time during which the applicable task will sleep, in order to distribute the processing time to other tasks.
If the task level is set to User HIGH, this command must always be specified.
The applicable task will sleep during the set time.
The time in operand 1 is set in msec.
An appropriate time setting must be examined on the actual system. (Normally approx. 1 to 3 is set.)
(If the ladder statement becomes long, state this command multiple times between steps, as necessary.)
This command can also be used with non-ladder tasks.




3. Key Characteristics of Actuator Control Commands and Points to Note

3.1 Continuous Movement Commands

[PATH, CIR, ARC, PSPL, CIR2, ARC2, ARCD, ARCC, CIRS, ARCS]


- [1] By running a program with continuous movement commands input in a series of continuous program steps, you can allow the actuators to perform operations continuously without stopping between steps.

```
VEL      100
PATH     1      5
ARC2     6      7
PATH     8     12
```




- [2] Continuous movement will not be achieved if an input condition is specified for any continuous movement command.

```
20 VEL      100
    PATH     1      5
    ARC2     6      7
    PATH     8     12
```



Stops momentarily.

- [3] The output field of each command will turn ON as the end position of that command approaches. Only with the last command in a series of continuous movement commands, the output will turn ON upon completion of operation (if there is no input condition).



[Example 1] (POTP = 1)

```
POTP     1
VEL      100
:
:
PATH     1      3      316
ARC2     10     11     319
PATH     21     23     320
:
:
```

Output field	Timing
316	Turn ON as P1 approaches.
317	Turn ON as P2 approaches.
318	Turn ON as P3 approaches.
319	Turn ON as P11 approaches.
320	Turn ON as P21 approaches.
321	Turn ON as P22 approaches.
322	Turn ON when P23 operation is complete.



[Example 2] (POTP = 0)

VEL 100

PATH 1 3 316

ARC2 10 11 319

PATH 21 23 320

Output field	Timing
316	Turn ON as P3 approaches.
319	Turn ON as P11 approaches.
320	Turn ON when P23 operation is complete.

[Example 3] If an input condition is specified, the output will turn ON upon completion of operation in the step before the one in which the input condition is specified.

POTP 1

⋮


20 PATH 1 3 316

ARC2 10 11 319

PATH 21 23 320

Output field	Timing
316	Turn ON as P1 approaches.
317	Turn ON as P2 approaches.
318	Turn ON when P3 operation is complete.
319	Turn ON as P11 approaches.
320	Turn ON as P21 approaches.
321	Turn ON as P22 approaches.
322	Turn ON when P23 operation is complete.

- [4] When executing continuous movement commands sequentially, the controller is calculating approx. 100 positions ahead. This is why the steps are displayed continuously on the PC screen or teaching-pendant screen, regardless of the actual operation. The last step in the continuous operation section executed by continuous movement commands will wait for the applicable operation to complete.



- [5] Do not allow the output fields to duplicate in the continuous operation section executed by continuous movement commands.

Duplicating output fields in the continuous operation section will not achieve the expected result. The output field will turn OFF at the start of processing of each command.

POTP 1

PATH 1 5 317

⋮

PATH 11 15 316

Do not let outputs 317 through 320 to duplicate, as in the example shown at left.

Continuous operation section executed by continuous movement commands

The final output status of duplicate 317 through 320 is indeterminable, because it is affected by the positioning calculation time and the relationship of durations of actual operations.

3.2 PATH/PSPL Commands

When executing a PATH or PSPL command, pay attention to the locus because it will change if the acceleration/deceleration is different between points.


The locus can be fine-tuned by changing the acceleration/deceleration, but different acceleration/deceleration settings between points will prevent smooth transition of speeds when moving from one position to another.

If there is a large difference in deceleration/acceleration between points and the positioning distance is small, the speed may drop. Exercise caution.

3.3 CIR/ARC Commands

The processing by a CIR or ARC command resembles moving along a polygon with a PATH command. A small division angle may cause the speed to drop.

CIR2, ARC2, ARCD and ARCC commands actually perform arc interpolation.



3.4 CIR2/ARC2/ARCD/ARCC Commands

With a CIR2, ARC2, ARCD or ARCC command, the speed can be changed (only in the arc interpolation section) by inputting a speed for the point specified in operand 1. These commands are effective when you must lower the speed partially because the radius is small and the arc locus cannot be maintained inside the allowable range.

The speed and acceleration will take valid values based on the following priorities:

Priority	Speed	Acceleration (deceleration)
1	Setting in the position data specified in operand 1	Setting in the position data specified in operand 1
2	Setting by VEL command	Setting by ACC (DCL) command
3		Default acceleration in all-axis parameter No. 11 (Default deceleration in all-axis parameter No. 12)



4. Palletizing Function

The SEL language used by the X-SEL Controller provides palletizing commands that support palletizing operation. These commands allow simple specification of various palletizing settings and enable arch motion ideal for palletizing.

4.1 How to Use


Use palletizing commands in the following steps:

- (1) Palletizing setting
Set palletizing positions, arch motion, etc., using palletizing setting commands.
- (2) Palletizing calculation
Specify palletizing positions using palletizing calculation commands.
- (3) Palletizing movement
Execute motion using palletizing movement commands.

4.2 Palletizing Setting

Use the palletizing setting commands to set items necessary for palletizing operation. The setting items include the following:

- (1) Palletizing number setting --- Command: BGPA
At the beginning of a palletizing setting, determine a palletizing number using a BGPA command to declare the start of palletizing setting.
At the end, declare the end of palletizing setting using an EDPA command.



A maximum of 10 sets (palletizing Nos. 1 to 10) of palletizing setting can be specified for each program.

(2) Palletizing pattern --- Command: PAPN

Select a pattern indicating the palletizing order.

The two patterns illustrated below are available.

The encircled numbers indicate the order of palletizing and are called "palletizing position numbers."




Fig. 1

PAPN 2

When pattern 2 is selected
(Setting is not necessary if pattern 1 is selected.)

The row from 1 to 3 to be placed first is called the "preferential axis (PX-axis)," while the other direction comprising the palletizing plane is called the "PY-axis."

(3) Palletizing counts --- Command: PAPI

Set the palletizing counts.

PAPI 3 4 Count for preferential axis (PX-axis): 3, Count for PY-axis: 4

(4) Palletizing position setting

Palletizing position setting is performed mainly by method A or B, as explained below. Set the palletizing positions for each palletizing setting based on method A or B.

	Setting method	Commands
A	3-point teaching method Set three position-data points specifying the palletizing positions.	PAPS
B	Method to set palletizing positions in parallel with the actuators Set from the palletizing axes, palletizing reference point and palletizing pitches.	PASE, PAST, PAPT

A. 3-point teaching method

To set the palletizing positions by 3-point teaching, store desired positions in position data fields as three continuous position data and then specify the first position number using a PAPS command.

This method allows you to set the PX-axis and PY-axis as three-dimensional axes not parallel with the actuators and not crossing with each other.

In the example shown below, position data [1], [3] and [10] are stored in three continuous position data fields.

When three points are taught from position No. 11

Position No. 11 [1]: Start point (First palletizing position)

Position No. 12 [3]: Palletizing position corresponding to the end point in the PX-axis direction

Position No. 13 [10]: Palletizing position corresponding to the end point in the PY-axis direction

The encircled numbers indicate palletizing position numbers (palletizing order).

Use a PAPS command to specify the position number corresponding to the start point.




Fig. 1

PAPS

11

The pitches are calculated automatically from the count set for each axis.

In 3-point teaching, you can specify position data for two axes or three axes. If data are specified for three axes, the palletizing plane will become a three-dimensional plane.


B. Method to set palletizing positions in parallel with the actuators

Palletizing reference point: Store the position data of the start point (palletizing position No. 1) in a position data field and specify the applicable position number using a PAST command, as shown below.

Palletizing pitches: Use a PAPT command to specify the pitches in the PX-axis and PY-axis directions.

Palletizing axes: Use a PASE command to specify the two axes, one representing the PX-axis direction and the other representing the PY-axis direction, to be used in palletizing.

(An actuator axis number parallel with the preferential axis (PX-axis) and another perpendicular to the preferential axis)



PAST	100		Teach position data No. 100 as the start point.
PAPT	45	30	The PX-axis direction pitch is 45 mm and the PY-axis direction pitch is 30 mm.
PASE	2	1	Set axis 2 as the preferential axis (PX-axis) and axis 1 as the axis perpendicular to the preferential axis.

(Note) When the above palletizing axes, palletizing pitches and palletizing reference point are used, the PX-axis and PY-axis must be parallel with the actuators and crossing with each other.

Select either method A or B for each palletizing setting.




(5) Zigzag setting --- Command: PSLI

Use a PSLI command to set a zigzag layout as shown below.

Zigzag offset: Offset amount in the preferential-axis direction, which will be applied when even-numbered rows are placed.

“Even-numbered rows” refer to the rows occurring at the even numbers based on the row placed first representing the first row.

Zigzag count: Number in the even-numbered rows. Two in the diagram below.



PSLI 35 2

(6) Arch-motion setting

(a) Arch-motion Z-axis number --- Command: ACHZ

(b) Arch-motion Z-axis offset --- Command: OFAZ

(c) Arch-motion composition --- Command: AEXT

Composition data refers to position data of any additional axis you wish to use in arch-motion operation, other than the valid end-point axes or arch-motion Z-axis. Examples include rotation angle.

Note that operation of the composite axis will start and end above the arch triggers.

In an arch-motion composition setting command, specify a position number storing arch-motion composition data.

(d) Arch triggers --- Command: ATRG

The arch-trigger settings used for arch motion include the items specified below.

In an arch-trigger setting command, specify position numbers storing arch-trigger coordinate data.

(d-1) Start-point arch trigger


Specify when to start moving in other axis direction after the start of arch motion from the start point, as an arch-motion Z-direction coordinate position reached.

Start-point arch trigger = Z1

(d-2) End-point arch trigger

Specify when to end moving in other axis direction during downward arch motion, as an arch-motion Z-direction coordinate position reached.

End-point arch trigger = Z3





- (7) Palletizing arch-motion setting
 - (a) Palletizing Z-direction axis number --- Command: PCHZ
 - (b) Palletizing Z-axis offset --- Command: OFPZ
 - (c) Palletizing composition --- Command: PEXT
Composition data refers to position data of any additional axis you wish to use with palletizing movement commands, other than the PX, PY (and PZ)-axes. Examples include rotation angle. Note that operation of the composite axis will start and end above the palletizing arch triggers. In a palletizing-composition setting command, specify a position number storing palletizing composition data.
 - (d) Palletizing arch triggers --- Command: PTRG
If the end point is a palletizing point, a palletizing arch trigger must be set just like an arch trigger. In a palletizing arch-trigger setting command, specify position numbers storing palletizing arch-trigger coordinate data.
 - (d-1) Palletizing start-point arch trigger
 - (d-2) Palletizing end-point arch trigger

4.3 Palletizing Calculation

The items that can be operated or obtained using palletizing calculation commands are shown below:

- (1) Palletizing position number Commands --- PSET, PINC, PDEC, PTNG
Number showing the ordinal number of a palletizing point.
(In Fig. 1 given in the explanation of palletizing pattern, the encircled numbers are palletizing position numbers.)

Always set this command before executing a palletizing movement command (excluding ARCH)
--- PSET

For example, executing a palletizing movement command by setting 1 as the palletizing position number will move the axes to the start point. Executing a palletizing movement command by setting 2 as the palletizing position number will move the axes to the point immediately next to the start point in the PX-axis direction.

- (2) Palletizing angle Command --- PARG
Angle formed by the physical axis and the palletizing preferential axis (PX-axis) (θ in the figure below).
 θ indicates an angle calculated by ignoring the coordinate in the palletizing Z-axis direction.
In the figure below, θ will become a negative value if axis 1 is used as the reference for angle calculation.




Fig. 4

Executing a "get palletizing angle" command (PARG) following a palletizing setting via 3-point teaching will automatically obtain the palletizing angle.

If the setting by 3-point teaching was done three-dimensionally, a palletizing Z-axis must be specified.

- (3) Palletizing calculation data Command --- PAPG
When a palletizing position number is set, this data refers to the position coordinate data of the palletizing point corresponding to that palletizing position number.
Note that this position coordinate data does not reflect normal offset or palletizing Z-axis offset.



4.4 Palletizing Movement

Palletizing movement commands include those used to move to a palletizing point and one used to move to an end point specified by position data.

(1) Movement commands to palletizing point --- PMVP, PMVL, PACH

Position coordinates of a two-dimensionally or three-dimensionally placed palletizing point are calculated and movement is performed using the calculated point as the end point. (The axes will move to the palletizing point of the palletizing position number specified in the executed command.)


Two actuator axes will be required to comprise a two-dimensional plane. If a vertical axis (PZ-axis) is required, another axis must be set.

PMVP: Move from the current position to a palletizing point via PTP.

PMVL: Move from the current position to a palletizing point via interpolation.

PACH: Move from the current position to a palletizing point via arch motion.

Palletizing arch motion must be set in a palletizing setting.



PCHZ	3	
PTRG	11	13
PACH	1	12




(2) Movement comment based on end point specified by point data --- ARCH

Perform arch motion using an end point specified by position data.

In the case of a linear movement in parallel with an actuator, operation can be performed only with two axes including the applicable axis and the PZ-axis.

Arch motion must be set.



ACHZ	3	
ATRG	13	11
ARCH	10	12




4.5 Program Examples

- (1) Simple program example (two-axis specification) using PAPS (set by 3-point teaching)
The example below specifies movement only and does not cover picking operation.

Step	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				BGPA	1			Start setting palletizing No. 1.
2				PAPI	3	4		Palletizing counts: 3 x 4
3				PAPS	2			Set by 3-point teaching.
4				EDPA				End setting palletizing No. 1.
5								
6				VEL	200			Speed: 200 mm/sec
7				MOVL	1			Move to picking position.
8				PSET	1			Set palletizing position number to 1.
9				TAG	1	1		
10				PMVL	1			Move to palletizing position via interpolation.
11				MOVL	1			Move to picking position via interpolation.
12				PINC	1		600	Increment palletizing position number by 1.
13			600	GOTO	1			Beginning of loop if PINC is successful.
14				EXIT				End

No.	Axis 1	Axis 2	Vel	Acc	Dcl	Remarks
1	10.000	10.000				Picking position
2	70.000	70.000				Reference-point position data
3	148.000	71.000				PX-axis end-point position data
4	69.000	143.000				PY-axis end-point position data

PY-axis end-point coordinates
Position No. 4
(69, 143)



Reference point
Position No. 2
(70, 70)


PX-axis end-point coordinates
Position No. 3
(148, 71)

● Picking position
Position No. 1

- (2) Simple program example (two-axis specification) using PAPS, PAPT and PAST
The example below specifies movement only and does not cover picking operation.

Step	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				BGPA	1			Start setting palletizing No. 1.
2				PAPI	3	4		Palletizing counts: 3 x 4
3				PASE	1	2		PX-axis = Axis 1, PY-axis = Axis 2
4				PAPT	40	25		Pitch: X = 40, Y = 25
5				PAST	2			Position No. 2 as reference point
6				EDPA				End setting palletizing No. 1.
7								
8				VEL	200			Speed: 200 mm/sec
9				MOVL	1			Move to picking position.
10				PSET	1	1		Set palletizing position number to 1.
11				TAG	1			
12				PMVL	1			Move to palletizing position via interpolation.
13				MOVL	1			Move to picking position via interpolation.
14				PINC	1		600	Increment palletizing position number by 1.
15			600	GOTO	1			Beginning of loop if PINC is successful.
16				EXIT				End

No.	Axis 1	Axis 2	Vel	Acc	Dcl	Remarks
1	10.000	10.000				Picking position
2	70.000	70.000				Reference-point position data



- Picking position
Position No. 1



(3) Simple program example using PAPS (set by 3-point teaching)

The example below specifies movement only and does not cover picking operation.


Step	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				BGPA	1			Start setting palletizing No. 1.
2								
3				PAPI	5	7		Palletizing counts: 5 x 7
4				PAPN	1			Palletizing pattern 1
5				PAPS	1			Set by 3-point teaching.
6								Use position No. 1 data.
7				PSLI	20	4		Zigzag offset = 20 mm
8				PCHZ	3			Palletizing Z-axis = Axis 3
9				PTRG	4	4		Set palletizing arch triggers.
10								Use position No. 4 data.
11				OFPZ	10			PZ-axis offset = 10 mm
12								
13								Use position No. 6 data.
14				EDPA				
15								
16								
17								
18								
19								
20	* //////////////////////////////////////							
21								
22				ATRG	4	4		Set arch triggers.
23								Use position No. 4 data.
24				ACHZ	3			Set arch-motion Z-axis.
25								
26				ACC	0.3			Acceleration
27				DCL	0.3			Deceleration
28				VLMX				
29								
30				PSET	1	1		Set palletizing position number to 1.



Step	E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
31				MOVP	8			Move to picking position.
32								
33				TAG	1			Beginning of loop processing
34				PACH	1	9		Palletizing arch motion
35								Z point specified by Position No. 9
36				ARCH	8	9		Arch motion
37								Z point specified by Position No. 9
38				PINC	1		600	Increment palletizing position number by 1.
39			600	GOTO	1			Go to beginning of loop if PINC is successful.
40								
41				EXIT				End of task
42								
43								
44								
45								

No.	Axis 1	Axis 2	Axis 3	Remarks
1	100.000	100.000	30.000	Reference point data
2	260.000	105.000	30.000	PX-axis end-point data
3	95.000	280.000	30.000	PY-axis end-point data
4	*.***	*.***	10.000	Arch-trigger point data
5	*.***	*.***	*.***	(Not used)
6	*.***	*.***	*.***	
7	*.***	*.***	*.***	(Not used)
8	0.000	0.000	30.000	Picking-position point data
9	*.***	*.***	0.000	Z point data
10				

Schematic diagram of placement-point positions based on the above program



- The number shown at the top right of each circle indicates a palletizing position number.
- Count in PX-axis direction = 5, Count in PY-axis direction = 7
- Zigzag offset: 20
- Zigzag count: 4



(4) Simple program example using PASE, PAPT and PAST

The example below specifies movement only and does not cover picking operation.


Step	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				BGPA	1			Start setting palletizing No. 1.
2								
3				PAPI	5	7		Palletizing counts: 5 x 7
4				PAPN	1			Palletizing pattern 1
5				PASE	1	2		PX-axis = Axis 1, PY-axis = Axis 2
6				PAPT	40	30		Pitch (X = 40 mm, Y = 30 mm)
7				PAST	1			Set reference point data.
8								Use position No. 1 data.
9				PSLI	20	4		Zigzag offset = 20 mm
10								Zigzag count = 4
11				PCHZ	3			Palletizing Z-axis = Axis 3
12				PTRG	4	4		Set palletizing arch triggers.
13								Use position No. 4 data.
14				OFPZ	10			PZ-axis offset = 10 mm
15								
16				EDPA				
17								
18	* //////////////////////////////////////							
19				ATRG	4	4		Set arch triggers.
20								Use position No. 4 data.
21				ACHZ	3			Set arch-motion Z-axis.
22								
23				ACC	0.3			Acceleration
24				DCL	0.3			Deceleration
25				VLMX				
26								
27				PSET	1	1		Set palletizing position number.
28				MOVP	8			Move to picking position.
29	* //////////////////////////////////////							
30								



Step	E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
31				TAG	1			Beginning of loop processing
32				PACH	1	9		Palletizing arch motion
33								Z point specified by Position No. 9
34				ARCH	8	9		Arch motion
35								Z point specified by Position No. 9
36				PINC	1		600	Increment palletizing position number by 1.
37			600	GOTO	1			Go to beginning of loop if PINC is successful.
38								
39				EXIT				End of task
40								

No.	Axis 1	Axis 2	Axis 3	Remarks
1	100.000	100.000	30.000	Reference point data
2	*.***	*.***	*.***	(Not used)
3	*.***	*.***	*.***	(Not used)
4	*.***	*.***	10.000	Arch-trigger point data
5	*.***	*.***	*.***	(Not used)
6	*.***	*.***	*.***	(Not used)
7	*.***	*.***	*.***	(Not used)
8	0.000	0.000	30.000	Picking-position point data
9	*.***	*.***	0.000	Z point data
10				

Schematic diagram of placement-point positions based on the above program



- The number shown at the top right of each circle indicates a palletizing position number.
- Count in PX-axis direction = 5, Count in PY-axis direction = 7
- Pitch in PX-axis direction: 40
- Pitch in PY-axis direction: 30
- Zigzag offset: 20
- Zigzag count: 4



5. Pseudo-Ladder Task

With the Tabletop Robot, a pseudo-ladder task function can be used depending on the command and extension condition.

The input format is shown below. Note that this function must be used by expert engineers with a full knowledge of PLC software design.

5.1 Basic Frame

Extension condition E	N	Input condition	Command	Operand 1	Operand2	Output	
		Cnd	Cmnd			Pst	
LD		7001	CHPR	1			Ladder statement field
			TPCD	1			
			TAG	1			
.		.	.	.			
.		.	.	.			
.		.	.	.			
LD		7001	TSLP	1 to 100			Ladder statement field
.		.	.	.			
.		.	.	.			
.		.	.	.			
.		.	.	.			
.		.	.	.			
LD		7001	TSLP	1 to 100			
LD		7001	GOTO	1			
LD		7001	EXIT				

* Virtual input 7001: "Normally ON" contact



5.2 Ladder Statement Field

[1] Extension conditions

LD	LOAD
A	AND
O	OR
AB	AND BLOCK
OB	OR BLOCK


All of the above extension conditions can be used in non-ladder tasks.

[2] Ladder commands

OUTR	Ladder output relay (Operand 1 = Output, flag number)
TIMR	Ladder timer relay (Operand 1 = Local flag number, Operand 2 = Timer setting (sec))


5.3 Points to Note

- This system only processes software ladders using an interpreter. Therefore, the processing time is much longer than that of a dedicated commercial sequencer.
(This system is not suitable for large-scale ladder processing.)
- If an extension condition is not specified for steps in which an input condition is specified, the steps will be treated as LD (LOAD).
- Always specify a “normally ON” contact for those steps that must be processed without fail, such as CHPR, TSLP and GOTO. (LD 7001)
Virtual input 7001: “Normally ON” contact
- The following circuit cannot be expressed. Create an equivalent circuit.





5.4 Program Example



Extension condition	N	Input condition	Command	Operand1	Operand2	Output
E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst
LD		7001	CHPR	1		
			TPCD	1		
			TAG	1		
LD		18				
A	N	19				
O		20				
LD	N	21				
A		22				
LD		23				
A	N	24				
OB						
AB			OUTR	316		
A		25	TIMR	900	0.5	
LD		7001	TSLP	3		
LD		7001	GOTO	1		
LD		7001	EXIT			



Chapter 5 Maintenance and Inspection

1. Inspection Items and Inspection Intervals

Perform the specified maintenance and inspection at the intervals listed below.

The schedule given below assumes that the robot is operated eight hours a day. If the robot is used continuously night and day or operated at higher utilization rates, shorten the inspection intervals accordingly.

	Visual inspection of the exterior	Interior inspection	Greasing
Startup inspection	○		
1 month after operation	○		
6 months after operation	○	○	
1 year after operation	○	○	○
Every 6 months thereafter	○		
Every year	○	○	○

2. Visual Inspection of the Exterior

Visually examine the exterior of the robot to check the following items.

Actuator	Looseness of actuator mounting bolts, etc.
Cables	Damage, loose connector connection
Overall	Noise, vibration

3. Visual Inspection and Cleaning

3.1 Cleaning

- Clean the exterior as needed.
- Wipe off dirt with a soft cloth.
- Do not use strong compressed air on the actuator as this may force dust into the crevices.
- Do not use petroleum-based solvent on plastic parts or painted surfaces.
- If the robot is badly soiled, apply a neutral detergent or alcohol to a soft cloth, and wipe gently.



3.2 Interior Inspection

Turn off the power, remove the screw cover, and visually check the interior.
Check the following items.

Actuator	Looseness of robot mounting bolts, etc.
Guides	Lubrication condition, soiling
Ball screw	Lubrication condition, soiling

Visually inspect the interior to see if there is any dust or foreign matter in the robot. Also check the lubrication. Even if the grease you see around the parts is brown, the lubrication is fine as long as the traveling surface appears shiny. If the grease becomes dirty and dull or if the grease has worn away due to long hours of use, lubricate the parts after cleaning them.

3.3 Internal Cleaning

- Wipe off dirt with a soft cloth.
- Do not use strong compressed air on the actuator as this may force dust into the crevices.
- Do not use petroleum-based solvent, neutral detergent or alcohol.

4. Greasing the Guides

4.1 Applicable Grease

The Tabletop Robot is designed to use lithium grease for lubrication.
The following grease is applied before the robot is shipped.

Idemitsu Kosan	Daphne Eponex Grease No.2
----------------	---------------------------

4.2 How to Apply Grease

Remove the screw cover and apply an appropriate amount of grease on the right and left rails.



Caution: In case the grease got into your eye, immediately go to see the doctor to get an appropriate care. After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease OFF.



5. Greasing the Ball Screw

5.1 Applicable Grease

The Tabletop Robot is designed to use lithium grease for lubrication.
The following grease is applied before the robot is shipped.

Kyodo Yushi	Multemp LRL No. 3
-------------	-------------------

5.2 How to Apply Grease

Remove the screw cover and apply an appropriate amount of grease on the right and left rails.



Caution: In case the grease got into your eye, immediately go to see the doctor to get an appropriate care. After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease OFF.

6. Timing Belt

6.1 Inspecting the Belt

Remove the pulley cover and visually inspect the belt.

Durability of the timing belt is affected significantly by the operating condition, and there is no standard guideline as to when the belt should be replaced. Generally, the belt is designed to withstand several millions of flexing loads. As a practical guideline, replace the timing belt when any of the conditions listed below is observed:

(If the belt needs to be replaced, please contact IAI's Engineering Service Section or Sales Section.)

- The teeth and end faces of the belt have worn significantly.
- The belt has swollen due to deposits of oil, etc.
- Cracks and other damages are found on the teeth or back of the belt.
- The belt has broken.

(If the belt needs to be replaced, please contact IAI's Engineering Service Section or Sales Section.)

6.2 Applicable Belt

The Tabletop Robot uses the following timing belt for its actuators. Should you require replacement of any belt used in your robot, please contact IAI's Engineering Service Section or Sales Section.

Timing belt: S3M; 6-mm wide, 190-mm long (Manufacturer: Bando Chemical Industries)




6.3 Belt Replacement Procedure

- [1] Remove the pulley cover.
(With the gate X-axis actuator, remove the rear panel to access the pulley cover.)
- [2] Hook a wire around the motor shaft.
(With the gate X-axis actuator, guide a wire through the belt replacement hole in the side face of the actuator and then hook the wire around the motor shaft.)
- [3] Pull the end of the wire with a force of 2.4 to 2.6 kgf.
- [4] Affix the motor.
- [5] Check the deflection.

Tension load: $F = 0.12$ to 0.17 kgf

Deflection: $\delta = 1.04$ mm

(Note) When pulling the belt, hold the actuator with hands or otherwise prevent the actuator from moving.





Appendix

⦿ How to Create a Program

1. Position Table

Position table

The Tabletop Robot can store 3,000 positions.

Positions are registered using the PC software or teaching pendant.

(Example with a 3-axis system)

No.	Axis1	Axis2	Axis3	Vel	Acc	Dcl
1	50.000	50.000	0.000			
2	100.000	30.000				
3	125.000	96.000				
4	75.000	102.000				
5	200.000	110.000				
6	150.500	116.000				
	⋮	⋮	⋮	⋮	⋮	⋮
	⋮	⋮	⋮	⋮	⋮	⋮
2994						
2995						
2996						
2997						
2998						
2999						
3000						


- No.: Specify a desired number in each program, and the actuator will move to the corresponding position registered under the number.
- Axis 1 to 3: Enter a desired position for each axis under each position number.
- Vel: Set a speed. The speed set in this field takes precedence over the speed specified directly in a program. In other words, specifying a position number will move the actuator to the applicable position at the speed specified in the Vel field under that position number.
- Acc: Set an acceleration. The acceleration set in this field takes precedence over the acceleration specified directly in a program or set by a parameter.
- Dcl: Set a deceleration. The deceleration set in this field takes precedence over the deceleration specified directly in a program or set by a parameter.



2. Program Format

Program edit screen (PC software)

The Tabletop Robot supports a program consisting of up to 6,000 steps. Programs are edited using the PC software or teaching pendant.



No.	B	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
3					VEL	100			
4					ACC	0.3			
5					TAG	1			
6					EXSR	5			
7					MOVP	610			
8					MOVP	589			
9					TIMW	0.3			
10					EXSR	5			
11					MOVP	601			
12					EXSR	6			
13					TIMW	0.2			
14					MOVP	610			
15					VEL	300			
16					EXSR	1			
17					MOVP	589			

No.: Step number

B: Set a breakpoint. (This field can be accessed during online editing.)
Using the mouse, click the "B" field in the line you want to set a breakpoint for. Once a breakpoint is set, "B" will be shown in the applicable line.
* Breakpoint --- Set a breakpoint in a step at which you want to pause the program run from the PC software.

E: Enter an extended condition (A, O, LD, AB, OB).

N: Specify "N" to indicate negation of the input condition.

Cnd: Enter an input condition.

Cmnd: Enter a SEL command.

Operand 1: Enter operand 1.

Operand 2: Enter operand 2.

Pst: Enter an output (operand 3).

Comment: Enter a comment if necessary (using a maximum of 18 single-byte characters).




3. Positioning to Five Positions


Description

Causes the actuator to move to positions 1 to 5 at a speed of 100 mm/sec following a home return. Only axis 1 is used.

Flowchart



- For the actuator to operate, a home return must have been completed and a speed must be set.
- The actuator moves to the position data coordinates specified by the movement commands.



Application program

No.	B	E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
1					HOME	1			Axis 1 Home Return
2					VEL	100			Set Vel to 100mm/s
3					MOVL	1			Move to Point 1
4					MOVL	2			Move to Point 2
5					MOVL	3			Move to Point 3
6					MOVL	4			Move to Point 4
7					MOVL	5			Move to Point 5
8					EXIT				End Program
9									

Position data

No.	Axis1
1	100.000
2	150.000
3	50.000
4	0.000
5	200.000
6	
7	
8	
9	




4. How to Use TAG and GOTO

Description

Use GOTO and TAG commands if you want to repeat the same operation in the program or jump to desired steps based on certain conditions. A TAG can be defined in a step before or after a GOTO command.


Example of Use 1

Repeats the same operation.



Example of Use 2

Jump to a specified step.






5. Moving Back and Forth between Two Points

Description

Causes the actuator to move back and forth between two points repeatedly.

Flowchart



- The actuator moves back and forth between P1 and P2 indefinitely.
- Axis 1 is used.
- Enter “TAG” in the first step of the repeated operation, and enter “GOTO” in the last step.

Application program

No.	B	E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
1					HOME	1			
2					VEL	100			
3					TAG	1			
4					MOVL	1			
5					MOVL	2			
6					GOTO	1			
7									

Position data

No.	Axis1
1	100.000
2	150.000
3	
4	
5	
6	
7	



6. Path Operation

Description

Causes the actuator to move continuously along given four points without stopping (path movement).


The actuator moves along the path shown to the right, without stopping at P2 or P3.

Unlike in operations using a MOVP or MOVL, the actuator need not be positioned at P2 and P3 and thus the tact time of movement can be reduced.

Assume that the following command is executed when the actuator is stopped at P1:

```
PATH 2 4
```

The actuator will move to P1, continue to move along points near P2 and P3, and finally reach P4. (Increasing the acceleration will bring the passing points closer to the specified positions.)



Assume that the following commands are entered successively:

```
PATH 2 3
```

```
PATH 3 4
```

The actuator will perform the same operation it would under the following command:

```
PATH 2 4
```

The actuator will perform a reverse operation ($P4 \rightarrow P3 \rightarrow P2 \rightarrow P1$) if the following command is entered while the actuator is stopped at P4:

```
PATH 4 1
```




7. Output Control during Path Movement

Description


In a coating operation, etc., output control is sometimes required while the robot is moving. The Tabletop Robot can output signals while moving under a PATH command.

How to Use

Before a PATH command, declare a POTP command to enable signal output during movement. If the output field of the PATH command specifies a given output port or global flag, the output port or flag specified in the output field will turn ON when the actuator, moving via path operation, approaches the position specified in the PATH command.

Example of Use 1

The actuator moves from P1 to P5, as shown to the right, without stopping. It turns ON output port 316 upon approaching P2.



Cmd	Operand 1	Operand 2	Pst
VEL	100		
POTP	1		
PATH	1	1	
PATH	2	2	316
PATH	3	5	

← A declaration command to enable signal output during path movement.

← Port 316 is turned ON at position P2 specified in this step.

Output ports and flags can only be turned ON using a POTP command. To turn OFF the port or flag that was turned ON during path operation, do so in a subsequent program step (using a BTOF command).


Example of Use 2

Output ports 310 to 313 can be turned ON successively at positions P2 to P5.

Cmd	Operand 1	Operand 2	Pst
VEL	100		
POTP	1		
PATH	1	1	
PATH	2	5	316

← A declaration command to enable signal output during path movement.

← Output ports 316 to 319 are turned ON successively at positions P2 to P5 specified in this step.





8. Circular/Arc Operation

Description


Causes the actuator to move along a two-dimensional circle or arc.

How to Use

To specify a circle, specify three passing points. To specify an arc, specify three points as the starting point, passing point and ending point.

Example of Use 1

Circle




- After the actuator has moved to P1, specify "CIR2 2 3."
- Specifying "CIR2 2 3" based on the positions shown to the left will cause the actuator to move along the circle clockwise.

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst
			VEL	100		
			MOV P	1		
			CIR2	2	3	

- To move the actuator counterclockwise, specify "CIR2 3 2."

Example of Use 2

Arc



- After the actuator has moved to P1, specify "ARC2 2 3."

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst
			VEL	100		
			MOV P	1		
			ARC2	2	3	

Reference

Circle and arc commands can be used to specify three-dimensional operations (3-axis actuator system), as well as two-dimensional operations (2-axis actuator system).

CIRS --- Three-dimensional circular movement

ARCS --- Three-dimensional arc movement



9. Home-return Completion Output

Description

Causes the actuator to output a signal confirming completion of home return. (Incremental specification)

The Tabletop Robot outputs an all-axis home-return completion signal to the LED (HPS) on the panel window. This section explains how to output a home-return completion signal via programming using a general-purpose output.

Once a general-purpose output turns ON, the output will remain ON even after the current program ends or other program is started. (There are certain conditions where the output turns OFF, such as an actuation of emergency stop. The ON status of the output can be maintained using I/O parameters (I/O parameter Nos. 70 and 71)).

Example of Use

a. The actuator outputs a home-return completion signal.

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst
			HOME	11		
			BTON	316		

Home return is performed.
General-purpose output turns ON.
(A desired output can be set.)

b. Using the home-return completion signal, cause the actuator not to perform home return again if it has already been performed once.

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst
	N	316	HOME	11		
			BTON	316		

Home return is performed if output 316 is OFF.
Home -return completion signal is output.

c. Use the output field instead of a BTON command.

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst
	N	316	HOME	11		303

The same processing corresponding to the above two steps is performed.




10. Moving an Axis Selectively based on Input and Outputting a Completion Signal

Description

How to move the actuator selectively based on input and output a processing completion signal

Flowchart



Example of Use

The actuator waits until input port 16 turns ON, upon which it will move to P1.

The actuator waits until input port 17 turns ON, upon which it will move to P2.

316 is used to issue a signal indicating completion of movement to P1, while 317 is used to issue a signal indicating completion of movement to P2.

Application program

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			VEL	100			Set Vel to 100mm/s
			WTON	16			Wait on Input 16
			MOVP	1			Move to Point 1
			BTON	316			Turn on Output 316
			WTON	17			Wait on Input 17
			BTOF	316			Turn off Outpt 316
			MOVP	2			Move to Point 2
			BTON	317			Turn on Output 317
			EXIT				End Program



11. Changing the Moving Speed

Description

Change the moving speed of the actuator.

How to Use

With the Tabletop Robot, the speed can be set using the following two methods:

- a: Use a VEL command in the application program.
- b: Use a speed set in the position data table.

Example of Use

Application program

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst
			MOYP	1		
			VEL	300		
			MOYP	2		
			MOYP	3		
			VEL	50		
			MOYP	4		

Position data

No.	Axis1	Vel	Acc	Dec
1	100.000	100		
2	200.000	200		
3	300.000			
4	400.000			

Moving speeds in the above program

100-mm position --- Move at 100 mm/sec.

200-mm position --- Move at 200 mm/sec.

300-mm position --- Move at 300 mm/sec.

400-mm position --- Move at 50 mm/sec.

As shown above, if a speed is specified for a given position in the position data table, the setting in the position data table takes precedence over the speed specified for the same position in the application program. In general, speeds are set using a VEL in the application program.

VEL in the position data table and PATH command

It is possible to change the actuator speed without stopping the actuator, by using a PATH command and VEL in the position data table. (Refer to the next page.)




12. Changing the Speed during Movement

Description

Use a PATH command to change the actuator speed while the actuator is moving. This command is useful in a dispensing operation where the coating amount changes during operation.

Example of Use

The actuator moves at 50 mm/sec in section a, 20 mm/sec in section b and 50 mm/sec in section c, without stopping. (Path operation)



Position data

No.	Axis1	Vel	Acc	Dec
1	0.000	50		
2	100.000	50		
3	200.000	20		
4	300.000	50		

Application program

"PATH 1 4" is the only movement command needed to implement this operation.

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst
			PATH	1	4	

Reference

It is also possible to use a CHVL (speed change) command to change the actuator speed from other program. (In the multitasking mode)



13. Local/Global Classification of Variables and Flags


Description

The internal variables and flags used in SEL commands are classified into local and global variables/flags.

The shared data range used by all programs is called the global range, while the data range used only by each program is called the local range. To adjust the timings of multiple programs in the multitasking mode or to allow variables to reference one another, the global range must be used.

Example of Use

Handshake between programs



As shown in the above example, global flags can be used to perform operations requiring handshake between two programs, such as executing “MOVL 1” in program A, waiting for the actuator to move to the specified position and then executing “MOVL 2” in program B, waiting for the actuator to move to the specified position and then executing “MOVL 3” in program A, and so on.

The variables and flags in the global range are retained until the power is turned off.

The variables and flags in the local range are cleared (to “0” in the case of variables, or turned OFF in the case of flags) when the program is started.



14. How to Use Subroutines

Description

If the same processing is performed multiple times in one program, the applicable operation is defined in a separate group of steps so that these steps can be called every time the operation is required. These steps are called a subroutine. Subroutines are used to shorten and simplify the program steps. Up to 99 subroutines can be used in a single program, and a maximum of 15 subroutine calls can be nested.

How to Use

Declare/call a subroutine using the following commands:

EXSR: Call a subroutine.

BGSR: Declare the start of a subroutine (declaration of the start of a group of steps).

EDSR: Declare the end of a subroutine (declaration of the end of a group of steps).

Example of Use

Cmd	Operand 1
VEL	100
MOVL	1
BTON	316
WTON	20
BTOF	316
MOVL	2
BTON	316
WTON	20
BTOF	316
MOVL	3
BTON	316
WTON	20
BTOF	316
EXIT	

The steps that perform the same operation are defined in a single location.

Cmd	Operand 1
VEL	100
MOVL	1
EXSR	1
MOVL	2
EXSR	1
MOVL	3
EXSR	1
EXIT	
BGSR	1
BTON	316
WTON	20
BTOF	316
EDSR	

Subroutine

Note

Jumping from within a subroutine to a TAG outside the subroutine using a GOTO command is prohibited.



15. Pausing the Operation

Description

Use a declaration command HOLD to pause the moving axis via an external input.


How to Use

By declaring a HOLD command in the program, the moving axis can be paused (decelerated to a stop) via interruption.

While the HOLD input is ON, the axis is paused (decelerated to a stop) against all movement commands in the program.

Example of Use

HOLD 20 Declaration of pause when general-purpose input 20 turns ON



Application

In addition to an input port, a global flag can also be specified in operand 1 of the HOLD command. You can use a global flag to pause the axis from other program.

It is also possible to select the input signal pattern and stopping pattern using operand 2.

- 0 = Contact a (The axis decelerates to a stop) ⇒ Same as when operand 2 is not specified.
- 1 = Contact b (The axis decelerates to a stop)
- 2 = Contact b (The axis decelerates to a stop, after which the servo turns OFF ⇒ The drive power does not turn OFF)

E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
			HOLD	20	2		Input 20 Servo Off

Note

If the actuator is paused during home return, it will repeat the home return sequence from the beginning after the pause input turns OFF.



16. Aborting the Operation 1 (CANC)

Description

Use a declaration command CANC to cause the moving axis to decelerate to a stop and cancel the remaining operation.

How to Use

While the CANC input is ON, operations of all movement commands in the program are aborted.

Example of Use

CANC command

CANC 20 Abort movement commands when input port 20 turns ON. (Declaration)

:

MOVP 1


MOVP 2

:

WTON 21

:

- * Declare a CANC in a step before the movement command you want to abort.
- * While the CANC input is ON, operation commands are cancelled successively, while non-operation commands (I/O processing, calculation processing, etc.) are executed successively.



Note

Using a CANC may cause a situation where the currently executed step in the program can no longer be identified. To prevent this situation, it is recommended that an input wait step be created using a WTON command.

Application

The input signal pattern can be selected using operand 2 of the CANC command.

0 = Contact a (The axis decelerates to a stop) ⇒ Same as when operand 2 is not specified.

1 = Contact b (The axis decelerates to a stop)

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			CANC	20	2		Cancel Input 20




17. Aborting the Operation 2 (STOP)

Description

Causes the moving axis to decelerate to a stop and cancel the remaining operation. (STOP)

How to Use

Use a STOP command to abort the operation from other program. (In the multitasking mode)
Specify the axis to abort using the axis pattern.



Example of Use 1

STOP command

Main program

```
EXPG  n      Aborting program starts.
:
MOVL  1
MOVL  2
:
```

Abort control program

```
WTON  20      Wait for the abort input to turn ON.
STOP  11      Abort axes 1 and 2.
```

If "STOP 11" is executed during "MOVL 1," "MOVL 1" will be cancelled and the actuator operation will continue from "MOVL 2."

Example of Use 2

Main program

```
EXPG  n      Aborting program starts.
:
MOVP  1
MOVP  2
:
```

Abort control program

```
WTON  20      Wait for the abort input to turn ON.
STOP  10      Abort axis 2.
```

Executing "STOP 10" during "MOVP 1" will only cancel the operation of axis 2 under "MOVP 1." Both axes 1 and 2 will operate under "MOVP 2."

Note

During a CP operation (interpolation operation) initiated by a MOVL, etc., executing a STOP command will cancel the operations of all axes regardless of the specified axis pattern.



18. Moving to a Specified Position Number


Description

Read an external BCD code input as a position number and cause the actuator to move to the corresponding position.

Example of Use

Use an INB command to read a BCD code from an input port as a position number. Up to three digits can be specified as a position number.

Flowchart



Input assignments

Port	Description
28	Start input
16	Position specification 1
17	Position specification 2
18	Position specification 4
19	Position specification 8
20	Position specification 10
21	Position specification 20
22	Position specification 40
23	Position specification 80
24	Position specification 100
25	Position specification 200
26	Position specification 400
27	Position specification 800

Output

303 Completion of movement

Application program

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			HOME	11			Home Return
			VEL	100			Velocity Setting
			TAG	1			Jump Marker
			WTON	28			Wait on Input 28
			INB	16	3		Ready Position No.
			BTOF	303			Pos End Signal OFF
			MOVL	*99			Move to position #
			BTON	303			Pos End Signal ON
			GOTO	1			Jump to TAG 1



19. Conditional Jump



Description

Select the destination to jump to under a GOTO command, by using an external input, output or internal flag as a condition.

The actuator waits for multiple inputs and performs processing appropriate for the input that turned ON.

Example of Use 1

If input 10 is ON, the actuator will jump to “TAG 1.” If input 10 is OFF, the actuator will perform the next processing.





“GOTO 1” is executed if input 16 is ON.

* If input 16 is ON, the actuator will skip processing a and perform processing b.
If input 16 is OFF, the actuator will perform processing a and then perform processing b.

Example of Use 2

The actuator waits for input port 16 or 17 to turn ON. If input 16 turns ON, the actuator will perform processing a. If input 17 turns ON, the actuator will perform processing b.



— No input
- - - Input 16 turns ON
- - - Input 17 turns ON

If inputs 16 and 17 both turn ON, the actuator will perform processing a.



20. Waiting for Multiple Inputs

Description


Causes the actuator to wait for multiple inputs and proceed to the next processing when any of these inputs turns ON.

Point

With a WTON command, the actuator cannot proceed to the next processing until the specified input turns ON. In other words, the actuator cannot wait for multiple inputs.

Example of Use

Monitor inputs 19 and 20. When either input turns ON (19 "OR" 20), the actuator will move to the next step.



Program a

E	N	Cnd	Cmnd	Operand 1
			TAG	1
		19		
0		20	GOTO	2
			GOTO	1
			TAG	2

Next processing

Program b

E	N	Cnd	Cmnd	Operand 1
			TAG	1
	N	19		
A	N	20	GOTO	1

Next processing

* The same processing is performed in both programs a and b.

As shown in the sample, it is possible to cause the actuator to wait for input without using a WTON command. This function also supports operations where multiple input conditions must be combined.




21. How to Use Offset

Description

If you want to move (offset) all teaching points by several millimeters because the actuator has not been installed in the correct position exactly, etc., an offset can be specified for position data using an OFST command.

It is also possible to pitch-feed the actuator using an OFST command. (Refer to 23, “Constant pitch Feed Operation.”)

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			VEL	100			
			MOV	1			Move to Point A
			OFST	1	80		Axis 1 80mm Offset
			MOV	1			Move to Point B



Note

Once an offset is set, all movement commands will be adjusted based on the offset. To cancel the offset, execute an OFST command again with “0” mm specified as the offset amount. The offset will not be reflected in different programs (even in the multitasking mode). To apply an offset to all programs, the offset must be specified in each program.



22. Executing an Operation n Times

Description

Causes the actuator to execute a specific operation n times.

Example of Use

The actuator moves back and forth between P1 and P2 10 times repeatedly, and then ends the program.

Use a CPEQ command to compare the number of times the operation has actually been repeated, against "10."

Home return is assumed to have been completed.

Application program

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			VEL	100			Velocity Setting
			LET	1	0		Initialize Counter
			TAG	1			Jump Marker
			MOVP	1			Move to Point 1
			MOVP	2			Move to Point 2
			ADD	1	1		Add 1 to Counter
			CPEQ	1	10	900	Stop at 10 cycles
	N	900	GOTO	1			Loop if not 10 cyc
			EXIT				End Program

Reference

The same operation can also be performed using a DWEQ command.




23. Constant-pitch Feed Operation

Description

Feed the actuator by a specified pitch n times from a reference position.
The pitch and number of feeds are specified by variables beforehand.

Flowchart




Example of Use

Use an OFST command to pitch-feed the actuator.
A counter variable is used to count the number of times the actuator has been fed.
The X-axis is pitch-fed in the positive direction.

Point

An OFST command applies only to movement commands.
Executing an OFST command alone will not move the axis.



Application program

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
			LET	1	4		Move number, n=4
			LET	100	80		80mm Pitch Variabl
			LET	2	0		Clear Counter_2
			LET	101	0		Clear Offset Var.
			HOME	1			Home Axis 1
			VEL	100			Velocity Setting
			TAG	1			Jump Marker 1
			WTON	1			Wait on Strt Input
			MOVP	1			Move to Point 1
			ADD	101	*100		Add pitch to Ofst
			OFST	1	*101		X-axis Offset
			ADD	2	1		Add 1 to Counter_2
			CPGT	2	*1	900	Post when 4 cycles
	N	900	GOTO	1			Loop if not done
			EXIT				End Program

Reference

Pitch feed can also be implemented using MVPI/MVLI commands.



24. Jogging

Description

Move the slider forward or backward while an input is ON or OFF.

In addition to an input, an output or global flag can be used to implement jogging.

If the specified input does not meet the condition when the command is executed, the slider will not perform jogging but proceed to the next step instead.

Once a soft limit is reached, the slider will stop and the next command step will become effective regardless of the input status.


How to Use

- Explanation of commands

JFWN	1	20	Axis 1 moves forward while input 20 is ON.
JFWF	1	21	Axis 1 moves forward while input 21 is OFF.
JBWN	10	22	Axis 2 moves backward while input 22 is ON.
JBWF	10	23	Axis 2 moves backward while input 23 is OFF.

Example of Use 1

- Stop the axis movement when a sensor input is received.



:			
VEL	50		Specify low speed.
JFWF	1	20	Move until a sensor input (20) turns ON.
EXIT			Program ends.

Example of Use 2

- Perform jogging as normally done from the teaching pendant (operation of 2 axes).

Application program

E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst
			TAG	1		
			JFWN	1	20	
			JBWN	1	21	
			JFWN	10	22	
			JBWN	10	23	
	N	24	GOTO	1		
			EXIT			

Note

HOLD, STOP and CANC commands remain effective during jogging.



25. Switching Programs

Description

Switch from one program to another via programming by using an EXPG or ABPG command.

Example of Use 1

Start program 2 when the processing under program 1 is completed, and end program 1.

Program 1	Program 2
:	:
EXPG 2	:
EXIT	

Example of Use 2

Start a different program externally and end the current program.

Program 1	Program 2
ABPG 2	ABPG 1
:	:

If program 2 is started while program 1 is running, program 1 will be aborted.
If program 1 is started while program 2 is running, program 2 will be aborted.

Application

Specifying a program number in operand 2 will allow all programs from the one corresponding to the program number specified in operand 1 to one corresponding to the program number specified in operand 2 to be started (EXPG) or aborted (ABPG) simultaneously.

Note

- The Tabletop Robot supports multitasking. By starting different programs successively while the robot is running a given program, a total of up to 16 programs can be run simultaneously. To use programs different from the 16 programs currently running, close unnecessary programs and then switch to the desired programs.
- If a program is aborted via an ABPG command and the program was executing a movement command, the actuator will immediately decelerate to a stop.



26. Aborting a Program

Description

Abort the program currently running.

In the multitasking mode, execute an ABPG command (abort other program) from other program.

Note

* If the aborted program was executing a movement command, the actuator will immediately decelerate to a stop.

Example of Use

Main program (Prg. 1)

EXPG n Abort control program starts.

WTON 10

MOVP 1

BTON 303

⋮
⋮

Abort control program (Prg. n)

WTON 20 Wait for the abort input to turn ON.

ABPG 1 Abort Prg 1.

EXIT Program ends.

* If an ABPG is executed while the actuator is moving via a MOVP command, the actuator will immediately decelerate to a stop and the program will end.



◎ How to Use Internal DIOs

1. Internal DIs and Dedicated Functions

Internal DI Nos. 001 to 006, 014 and 015 can be assigned as dedicated function ports (software reset input, etc.) by parameter settings. (They are not assigned to dedicated functions when the robot is shipped from the factory.)

To implement a dedicated function, assign it to an internal DI via a parameter and then turn ON/OFF the internal DI. Note that internal DIs cannot be controlled from the I/O connector. A dedicated function can be implemented by turning ON/OFF the internal DO corresponding to the internal DI assigned to that function.

Correspondence of DI port numbers and DO port numbers is shown below.

DO port No.	DI port No.	Dedicated function	Parameter No.
308	001	Software reset	IO parameter No. 031
309	002	Servo ON	IO parameter No. 032
310	003	Auto program start	IO parameter No. 033
311	004	Software interlock	IO parameter No. 034
312	005	Pause reset	IO parameter No. 035
313	006	Pause	IO parameter No. 036
314	014	Drive-source cutoff input	IO parameter No. 044
315	015	Home return, etc.	IO parameter No. 045

For example, executing the following SEL program will turn ON input port No. 1:

```
BTON 308
TIMW 1
EXIT
```

If DI No. 001 is set as a software reset input, a software reset will be implemented (the robot will restart). For details on the dedicated functions, refer to the parameter list.

Note: The parameters are normally set to the above DI and DO port numbers before shipment. Note that even when the input port number assigned to a given input function selection *** is changed by setting "Physical input port number for input function selection ***" accordingly, the functions where the ON/OFF statuses of output port Nos. 308 to 315 are reflected in input port Nos. 1 to 6, 14 and 15 will be maintained, as shown in the table above. However, the dedicated functions will be disabled. For example, setting "Input function selection 001" and "Physical input port number for input function selection 001" to "1 (soft reset)" and "16," respectively, and then turning output port No. 308 ON will turn input port No. 1 ON, but soft reset will not be executed. For details, refer to 2.3.2, "Standard Interface (Main Application Version 0.19 or Later)."



2. Showing User SEL Program Data on the 7-segment LED Display


The 7-segment LED display in the panel window on the front panel normally shows information received from the system. This 7-segment LED display can also be set to show data according to the SEL programs created by the user. (In this mode, the LED display shows user program data and system information alternately.)

Internal DO Nos. 332, 333, 337 to 346 are used to show user program data on the 7-segment display.

Port No.	Function
332	7-segment user display digit specification
333	7-segment user display digit specification
334	For future expansion
335	For future expansion
336	For future expansion
337	7-segment display refresh
338	7-segment user/system alternate display
339	7-segment user display specification
340	DT0 (7-segment user display bit)
341	DT1 (7-segment user display bit)
342	DT2 (7-segment user display bit)
343	DT3 (7-segment user display bit)
344	DT4 (7-segment user display bit)
345	DT5 (7-segment user display bit)
346	DT6 (7-segment user display bit)
347	

DO Nos. 332 and 333 are used to specify the segment digit to be operated.

Port ON/OFF statuses and specified digits (0: OFF, 1: ON)



Note: The parameters are normally set to the above port numbers before shipment.




DO No. 339 is used to switch between user program data display and system information display. If DO No. 339 is set to "1," user SEL program data is shown. If DO No. 339 is set to "0," normal system information is shown. Set DO No. 338 to "1." If DO No. 339 is set to "1," user program data and system information are alternated every second.

Note: If DO No. 338 is set to "0"

Only user program data is shown, and the 1-second alternate display is not implemented. If an error of operation-cancellation level or higher has occurred, the applicable system information (error code) will be shown.

If an error of message level or lower has occurred, user program data will be shown continuously and the applicable system information (error code) will not be shown. Since the user has no way of knowing the occurrence of message-level or lower errors, set DO No. 338 to "0."

DO Nos. 340 to 346 correspond to the individual 7-segment display bits.



Data is shown on the 7-segment LED display at an ON edge of DO No. 337 (after a switching sequence of "0," "1" and "0").

(The 7-segment pattern set by DO Nos. 340 to 346 is shown in the digit specified by DO Nos. 332 and 333.)

Note: The parameters are normally set to the above port numbers before shipment.



How to Use

- [1] Set a display mode using DO Nos. 338 and 339.
- [2] Set the digit to show (refresh) data in, using DO Nos. 332 and 333.
- [3] Set a 7-segment display pattern using DO Nos. 340 to 346.
- [4] Turn DO Nos. 337 (refresh) OFF, ON and then OFF. (Data will be refreshed at an ON edge.)

To display data in a different digit, repeat steps (2) to (4).

The display will continue to show user program data even after the display SEL program ends. To end the user program display mode, turn DO No. 339 OFF.

Sample program

No	E	N	Cnd	Cmd	Operand 1	Operand 2	Pst	Comment
1				LET	99	3		
2				OUT	338	339		Alternate display of user program data and system information
3				BTOF	337			
4			* Set data in digit 1.					
5				LET	99	0		
6				OUT	332	333		Specify digit 1.
7				LET	99	3		3 = Display data "1"
8				OUT	340	346		7-segment pattern 1
9				BTON	337			Refresh ON
10				BTOF	337			Refresh OFF
11			* Set data in digit 2.					
12				LET	99	1		
13				OUT	332	333		Specify digit 2.
14				LET	99	118		118 = Display data "2"
15				OUT	340	346		7-segment pattern 2
16				BTON	337			Refresh ON
17				BTOF	337			Refresh OFF
18			* Set data in digit 3.					
19				LET	99	2		
20				OUT	332	333		Specify digit 3.
21				LET	99	103		103 = Display data "3"
22				OUT	340	346		7-segment pattern 3
23				BTON	337			Refresh ON
24				BTOF	337			Refresh OFF
25			* Set data in digit 4.					
26				LET	99	3		
27				OUT	332	333		Specify digit 4.
28				LET	99	75		75 = Display data "4"
29				OUT	340	346		7-segment pattern 4
30				BTON	337			Refresh ON
31				BTOF	337			Refresh OFF
32								
33				EXIT				

Note: The parameters are normally set to the above port numbers before shipment.



◎ List of Parameters

If you have any question regarding changing the parameters, please contact IAI's Sales Engineering Section. After changing a parameter, record the new and old parameter settings.

If you have purchased the PC software, we recommend that you back up the parameters immediately after the controller is delivered and when the system incorporating the controller is started. Since a number of customizing settings use parameters, you should back up the parameters regularly as you back up the programs.

To make the new parameters effective, write them to the flash ROM and then execute a software reset or reconnect the power.

The lists below are examples of default values displayed on the PC software. The default parameter settings vary depending on the operating condition and actuators used.

The values in the "Input range" column represent input limitations on the teaching pendant or in PC software. For the actual settings, enter the values defined in the "Remarks" column.

Values other than those defined in the "Remarks" column are for future expansion, even when they are inside the input range.

Therefore, do not enter values other than those defined in the "Remarks" column.



1. I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	I/O port assignment type	0	Reference only		0: Fixed assignment
2	Input port start number with fixed standard I/O1 assignments	000	-1 to 599		0 + (Multiple of 8) (Invalid if a negative value is set) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
3	Output port start number with fixed standard I/O1 assignments	300	-1 to 599		300 + (Multiple of 8) (Invalid if a negative value is set) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
4	Input port start number with fixed expanded I/O2 assignments	32	-1 to 599		0 + (Multiple of 8) (Invalid if a negative value is set) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
5	Output port start number with fixed expanded I/O2 assignments	316	-1 to 599		300 + (Multiple of 8) (Invalid if a negative value is set) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
6	Input port start number with fixed expanded I/O1 assignments (Network I/F module)	-1	-1 to 599		0 + (Multiple of 8) (Invalid if a negative value is set)
7	Output port start number with fixed expanded I/O1 assignments (Network I/F module)	-1	-1 to 599		300 + (Multiple of 8) (Invalid if a negative value is set)
8	For future expansion	-1	-1 to 599		
9	For future expansion	-1	-1 to 599		
10	Standard I/O1 error monitor	1	0 to 5		0: Do not monitor 1: Monitor 2: Monitor (Do not monitor errors relating to 24-V I/O power source) 3: Monitor (Monitor only errors relating to 24-V I/O power source) * Some exceptions apply.
11	Expanded I/O2 error monitor	1	0 to 5		0: Do not monitor 1: Monitor 2: Monitor (Do not monitor errors relating to 24-V I/O power source) 3: Monitor (Monitor only errors relating to 24-V I/O power source) * Some exceptions apply.
12	Expanded I/O1 error monitor (Network I/F module)	1	0 to 5		0: Do not monitor 1: Monitor * Some exceptions apply.
13	For future expansion	1	0 to 5		
14	Number of ports using network-I/F-module remote input	0	0 to 240		Refer to the operation manual for each network I/F card (CC-Link, DeviceNet, etc.).
15	Number of ports using network-I/F-module remote input	0	0 to 240		Refer to the operation manual for each network I/F card (CC-Link, DeviceNet, etc.).
16	(For future expansion = Change prohibited)	0	0 to 256		Multiple of 8
17	(For future expansion = Change prohibited)	0	0 to 256		Multiple of 8
18 to 19	(For expansion)	0			
20	Input filtering periods	2	1 to 9	msec	Input signal is recognized when the status is held for twice the period set by this parameter.
21	Register input filtering periods	2	1 to 9	msec	Input signal is recognized when the status is held for twice the period set by this parameter.
22	For future expansion	2000	Reference only	msec	



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
23	For future expansion	0H	Reference only		
24	For future expansion	0	Reference only		
25 to 29	(For expansion)	0			
30	Input function selection 000	1	0 to 5		1: Program start signal (ON edge) (007 to 013: BCD-specified program number) * If this parameter is used as a program start signal, turn ON the signal for at least 100 msec so that the program will start without fail.
31	Input function selection 001	0	0 to 5		0: General-purpose input 1: Software reset signal (1 second ON) If continued operation is specified as the action upon emergency stop, enable the software reset signal (to provide a means of canceling the operation). * The condition of output port No. 308 (internal DIO) is input to input port No. 001 (internal DIO).
32	Input function selection 002	0	0 to 5		0: General-purpose input 1: Servo ON ON edge: Equivalent to the all-valid-axis servo ON command, OFF edge: Equivalent to the all-valid-axis servo OFF command (A minimum interval of 1.5 seconds is required) (Must be executed in non-operating condition) * The condition of output port No. 309 (internal DIO) is input to input port No. 002 (internal DIO).
33	Input function selection 003	1	0 to 5		0: General-purpose input 1: General-purpose input (Start the auto-start program upon power-ON reset/software reset in the AUTO mode) 2: Auto-start program start signal (ON edge: Start, OFF edge: Abort all operations/programs (excluding the I/O processing program at operation/program abort)) * If this parameter is used as an auto-start program start signal, turn ON the signal for at least 100 msec so that the program will start without fail. * The condition of output port No. 310 (internal DIO) is input to input port No. 003 (internal DIO).
34	Input function selection 004	0	0 to 5		0: General-purpose input 1: All servo axis soft interlock (OFF level) (Valid for all commands other than the servo OFF command) (Operation is held upon interlock actuation during automatic operation; operation is terminated upon interlock in non-AUTO mode) * The condition of output port No. 311 (internal DIO) is input to input port No. 004 (internal DIO).
35	Input function selection 005	0	0 to 5		0: General-purpose input, 1: Operation-pause reset signal (ON edge) * The condition of output port No. 312 (internal DIO) is input to input port No. 005 (internal DIO).
36	Input function selection 006	0	0 to 5		0: General-purpose input 1: Operation-pause reset signal (OFF level) (Valid only during automatic operation) * Cancel pause when an operation-pause reset signal is received. * The condition of output port No. 313 (internal DIO) is input to input port No. 006 (internal DIO).



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
37	Input function selection 007	1	0 to 5		0: General-purpose input 1: Program number specified for program start (least significant bit) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
38	Input function selection 008	1	0 to 5		0: General-purpose input 1: Program number specified for program start * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
39	Input function selection 009	1	0 to 5		0: General-purpose input 1: Program number specified for program start * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
40	Input function selection 010	1	0 to 5		0: General-purpose input 1: Program number specified for program start * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
41	Input function selection 011	1	0 to 5		0: General-purpose input 1: Program number specified for program start * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
42	Input function selection 012	1	0 to 5		0: General-purpose input 1: Program number specified for program start * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
43	Input function selection 013	1	0 to 5		0: General-purpose input 1: Program number specified for program start 2: Error reset (On edge) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
44	Input function selection 014	0	0 to 5		0: General-purpose input (Cancel cutoff when the drive-source cutoff factor is removed) 1: Drive-source cutoff reset input (ON edge) (Valid when the factor has been removed) * The condition of output port No. 314 (internal DIO) is input to input port No. 014 (internal DIO).
45	Input function selection 015	0	0 to 5		0: General-purpose input 1: Home return of all valid axes (ON edge) (Servo ON must be executed first = I/O parameter No. 32, Axis-specific parameter No. 13) 2: Home return of all valid incremental axes (ON edge) (Main application version 0.16 or later) (Servo ON must be executed first = I/O parameter No. 32, Axis-specific parameter No. 13) * The condition of output port No. 315 (internal DIO) is input to input port No. 015 (internal DIO).
46	Output function selection 300	1	0 to 20		0: General-purpose output 1: Output error of operation-cancellation level or higher (ON) 2: Output error of operation-cancellation level or higher (OFF) 3: Output error of operation - cancellation level or higher + emergency stop (ON) 4: Output error of operation - cancellation level or higher + emergency stop (OFF) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
47	Output function selection 301	1	0 to 20		0: General-purpose output 1: READY output (PIO trigger program can be run) 2: READY output (PIO trigger program operation permitted AND error of operation-cancellation level or higher not present) 3: READY output (PIO trigger program operation permitted AND error of cold-start level or higher not present) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
48	Output function selection 302	1	0 to 20		0: General-purpose output 1: Emergency-stop output (ON) 2: Emergency-stop output (OFF) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
49	Output function selection 303	2	0 to 5		0: General-purpose output 1: AUTO mode output 2: Output during automatic operation (Other parameter No. 12) * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
50	Output function selection 304	2	0 to 5		0: General-purpose output 1: Output if all valid axes are at their homes (= 0) 2: Output if all valid axes completed home return (coordinates have been confirmed). 3: Output if all valid axes are at their home preset coordinates * Keep the default value if the main application version is 0.18 or earlier. (Change prohibited)
51	Output function selection 305	0	0 to 5		0: General-purpose output 1: For future expansion 2: Output when axis-1 servo is ON (System monitor task output) 3: For future expansion
52	Output function selection 306	0	0 to 5		0: General-purpose output 1: For future expansion 2: Output when axis-2 servo is ON (System monitor task output) 3: For future expansion
53	Output function selection 307	0	0 to 5		0: General-purpose output 1: For future expansion 2: Output when axis-3 servo is ON (System monitor task output) 3: For future expansion
54	Output function selection 308	0	0 to 5		0: General-purpose output * The condition of output port No. 308 (internal DIO) is input to input port No. 001 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
55	Output function selection 309	0	0 to 5		0: General-purpose output * The condition of output port No. 309 (internal DIO) is input to input port No. 002 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
56	Output function selection 310	0	0 to 5		0: General-purpose output * The condition of output port No. 310 (internal DIO) is input to input port No. 003 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
57	Output function selection 311	0	0 to 5		0: General-purpose output * The condition of output port No. 311 (internal DIO) is input to input port No. 004 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
58	Output function selection 312	0	0 to 5		0: General-purpose output * The condition of output port No. 312 (internal DIO) is input to input port No. 005 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
59	Output function selection 313	0	0 to 5		0: General-purpose output * The condition of output port No. 313 (internal DIO) is input to input port No. 006 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
60	Output function selection 314	0	0 to 5		0: General-purpose output * The condition of output port No. 314 (internal DIO) is input to input port No. 014 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
61	Output function selection 315	0	0 to 5		0: General-purpose output * The condition of output port No. 315 (internal DIO) is input to input port No. 015 (internal DIO). (The parameters are normally set to the above port numbers before shipment.)
62	Physical input port number for axis-1 brake forced release	0	0 to 299		Forcibly unlock the brake when the applicable port is ON (be aware of a falling load). * Invalid if "0" is set (Invalid if input port No. 0 is specified) * The synchro slave axis will follow the synchro master axis.
63	Physical input port number for axis-2 brake forced release	0	0 to 299		Forcibly unlock the brake when the applicable port is ON (be aware of a falling load). * Invalid if "0" is set (Invalid if input port No. 0 is specified) * The synchro slave axis will follow the synchro master axis.
64	Physical input port number for axis-3 brake forced release	0	0 to 299		Forcibly unlock the brake when the applicable port is ON (be aware of a falling load). * Invalid if "0" is set (Invalid if input port No. 0 is specified) * The synchro slave axis will follow the synchro master axis.
65	Physical input port number for axis-4 brake forced release	0	0 to 299		Forcibly unlock the brake when the applicable port is ON (be aware of a falling load). * Invalid if "0" is set (Invalid if input port No. 0 is specified) * The synchro slave axis will follow the synchro master axis.
66 to 69	(For expansion)	0			
70	Unaffected general-purpose output area number (MIN) when all operations/programs are aborted	300	0 to 599		* Important: Outputs in this area must be operated under the responsibility of user programs including the "I/O processing program at operation/program abort." Outputs outside this area will be forcibly turned OFF. (Invalid if "0" is set)
71	Unaffected general-purpose output area number (MAX) when all operations/programs are aborted	315	0 to 599		



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
72	Unaffected general-purpose output area number (MIN) when all operations are paused (servo-axis soft interlock + output-port soft interlock)	300	0 to 599		* Important: Outputs in this area must be operated (including recovery) under the responsibility of user programs including the "I/O processing program at all operations pause." Outputs outside this area will be forcibly turned OFF, reflecting/holding the results of operations performed while all operation pause is effective (only during automatic operation). (Invalid if "0" is set)
73	Unaffected general-purpose output area number (MAX) when all operations are paused (servo-axis soft interlock + output-port soft interlock)	599	0 to 599		
74	Number of TP user output ports used (hand, etc.)	0	0 to 8		Referenced by TP. (Invalid if "0" is set) (Valid with TP application version 1.05 or later)
75	TP user output port start number (hand, etc.)	0	0 to 599		Referenced by TP. (Valid with TP application version 1.05 or later)
76	AUTO mode physical output port number	0	0 to 599		(Invalid if "0" is set)
77	Input port number permitted to receive PC/TP servo movement command	0	0 to 299		* Important: Invalid once operation is started. (Invalid if "0" is set)
78	Axis pattern permitted to receive PC/TP servo movement command	0	0B to 11111111B		
79	For future expansion	0	Reference only		
80	(PC/TP SIO usage)	1	1 to 1		Switching of DIP switches
81	(PC/TP SIO station code)	153	153 to 153		Fixed to 153 (99H).
82	(PC/TP SIO reservation)	0			
83	(PC/TP SIO reservation)	0			
84	(PC/TP SIO reservation)	0			
85	(PC/TP SIO reservation)	0			
86	(PC/TP SIO reservation)	0			
87	(PC/TP SIO reservation)	0			
88	(PC/TP SIO reservation)	0			
89	(PC/TP SIO reservation)	0			
90	Usage of SIO channel 1 opened to user (AUTO mode)	0	0 to 9		0: Open SEL program 1: Open SEL program (Connect PC/TP when both devices are closed = Used exclusively by the manufacturer) 2: IAI protocol B (Slave)
91	Station code of SIO channel 1 opened to user	153	0 to 255		Valid only with IAI protocol.
92	Baud rate type of SIO channel 1 opened to user	0	0 to 2		0: 9.6 1: 19.2 2: 38.4 kbps
93	Data length of SIO channel 1 opened to user	8	7 to 8		
94	Stop bit length of SIO channel 1 opened to user	1	1 to 2		
95	Parity type of SIO channel 1 opened to user	0	0 to 2		0: None 1: Odd 2: Even
96	Receive operation type of SIO channel 1 opened to user	0	0 to 1		0: Forcibly enable receive after send 1: Do not forcibly enable receive at send



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
97	IAI-protocol minimum response delay for SIO channel 1 opened to user	0	0 to 999	msec	Valid only with IAI protocol.
98 to 99	Reservation of SIO channel 1 opened to user	0			
100	SIO for future expansion	0	Reference only		
101	SIO for future expansion	0	Reference only		
102	SIO for future expansion	0	Reference only		
103	SIO for future expansion	0	Reference only		
104	SIO for future expansion	0	Reference only		
105	SIO for future expansion	0	Reference only		
106	SIO for future expansion	0	Reference only		
107	SIO for future expansion	0	Reference only		
108	SIO for future expansion	0	Reference only		
109	SIO for future expansion	0	Reference only		
110	SIO for future expansion	0	Reference only		
111	SIO for future expansion	0	Reference only		
112	SIO for future expansion	0	Reference only		
113	SIO for future expansion	0	Reference only		
114	SIO for future expansion	0	Reference only		
115	SIO for future expansion	0	Reference only		
116 to 119	(For expansion)	0			

PC: PC software
TP: Teaching pendant



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
120	Network attribute 1	1	0H to FFFFFFFFH		Bits 0 to 3: CC-Link remote register area H/L byte swap selection (0: Do not swap, 1: Swap) * The number of used ports and number of occupied stations in I/O parameter Nos. 14 and 15 must match.
121	Network attribute 2	0	0H to FFFFFFFFH		
122	Network attribute 3	0	0H to FFFFFFFFH		
123	Network attribute 4	0	0H to FFFFFFFFH		Bits 0 to 3: Ethernet TCP/IP message communication Selection whether to permit 0.0.0.0 (IP address of connection destination can be ignored) as IP address of connection destination on server (0: Do not permit 1: Permit (<u>not recommended</u>)) * Note: Number of clients that can be connected simultaneously to one server port channel = 1
124	Network attribute 5	0	0H to FFFFFFFFH		Ethernet TCP/IP message communication attribute Ethernet client/server type (0: Not in use 1: Client (Automatic assignment of own port number) 2: Client (Specification of own port number) → This setting is <u>not recommended</u> because of device limitations, such as an error generation when the port is opened for approx. 10 minutes after disablement of close response check due to a power failure at the connection destination, etc.) 3: Server (Specification of own port number) * Note: Number of clients that can be connected simultaneously to one server port channel = 1 Bits 0 to 3: IAI protocol B/TCP (MANU mode) * PC software can be connected only in the case of a client. Bits 4 to 7: IAI protocol B/TCP (AUTO mode) * PC software can be connected only in the case of a client. Bits 8 to 11: Channel 31 opened to user Bits 12 to 15: Channel 32 opened to user Bits 16 to 19: Channel 33 opened to user Bits 20 to 23: Channel 34 opened to user * If the parameter settings for own port number, client/server type, IP address of connection destination and port number of connection destination do not match completely between the IAI protocol B/TCP MANU and AUTO modes, the connection will be cut off when the MANU/AUTO mode is switched.
125	Network attribute 6	1E32H	0H to FFFFFFFFH		Bits 0 to 7: Module-initialization check timer setting when Ethernet is used (100 msec) Bits 8 to 15: Module-initialization check timer setting when Ethernet is not used (100 msec) Bits 16 to 23: Increment of "PC/TP reconnection delay at software reset" when Ethernet is used (sec)
126	Network attribute 7	7D007D0H	0H to FFFFFFFFH		Ethernet TCP/IP message communication attribute Bits 0 to 15: Min timeout value (msec) Bits 16 to 31: Mout timeout value (msec)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
127	Network attribute 8	5050214H	0H to FFFFFFFFH		Ethernet TCP/IP message communication attribute Bits 0 to 7: CONNECT_TIMEOUT (Change is prohibited) (Setting of "0" is prohibited) (sec) Bits 8 to 15: Connection retry interval (IAI protocol B/TCP) (sec) Bits 16 to 23: Send timeout value (sec) Bits 24 to 31: IAI protocol B-SIO non-communication check timer setting (sec) (IAI protocol B/TCP connection trigger)
128	Network attribute 9	0	0H to FFFFFFFFH		Ethernet TCP/IP message communication attribute Bits 0 to 15: SEL server open timeout value (sec) (No timeout check when "0" is set)
129	Network attribute 10	0	0H to FFFFFFFFH		Ethernet operation requirement Bits 0 to 3: Modbus/TCP (Remote I/O) 0: Not in use 1: Use (Disable EXCEPTION status) 2: Use (Enable EXCEPTION status (upper two digits of error number)) * Refer to the explanation of error levels in the operation manual and perform processing appropriate for each error level. Bits 4 to 7: TCP/IP message communication (0: Not in use, 1: Use) Bits 8 to 31: Reserved (Operation requirement)
130	Own MAC address (H)	0H	Reference only (HEX)		Only lower two bytes are valid.
131	Own MAC address (L)	0H	Reference only (HEX)		
132	Own IP address (H)	192	1 to 255		*Setting of "0" and "127" is prohibited.
133	Own IP address (MH)	168	0 to 255		
134	Own IP address (ML)	0	0 to 255		
135	Own IP address (L)	1	1 to 254		*Setting of "0" and "255" is prohibited.
136	Subnet mask (H)	255	0 to 255		
137	Subnet mask (MH)	255	0 to 255		
138	Subnet mask (ML)	255	0 to 255		
139	Subnet mask (L)	0	0 to 255		
140	Default gateway (H)	0	0 to 255		
141	Default gateway (MH)	0	0 to 255		
142	Default gateway (ML)	0	0 to 255		
143	Default gateway (L)	0	0 to 255		
144	IAI protocol B/TCP: Own port number (MANU mode)	64511	1025 to 65535		*Important note: Always set a unique number for each port number. (Duplication of port numbers is permitted only in the IAI protocol B/TCP MANU/AUTO modes.)
145	Channel 31 opened to user (TCP/IP): Own port number	64512	1025 to 65535		
146	Channel 32 opened to user (TCP/IP): Own port number	64513	1025 to 65535		
147	Channel 33 opened to user (TCP/IP): Own port number	64514	1025 to 65535		
148	Channel 34 opened to user (TCP/IP): Own port number	64515	1025 to 65535		
149	IAI protocol B/TCP: IP address of connection destination (MANU mode) (H)	192	0 to 255		*Setting of "0" and "127" is prohibited.



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
150	IAI protocol B/TCP: IP address of connection destination (MANU mode) (MH)	168	0 to 255		
151	IAI protocol B/TCP: IP address of connection destination (MANU mode) (ML)	0	0 to 255		
152	IAI protocol B/TCP: IP address of connection destination (MANU mode) (L)	100	0 to 254		* Setting of "0" and "255" is prohibited.
153	IAI protocol B/TCP: Port number of connection destination (MANU mode)	64611	0 to 65535		* "0" can be set in the case of a server. 0 = Port number of connection destination is ignored (only the IP address is checked) * "0" cannot be set in the case of a client.
154	IAI protocol B/TCP: IP address of connection destination (AUTO mode) (H)	192	0 to 255		* Setting of "0" and "127" is prohibited.
155	IAI protocol B/TCP: IP address of connection destination (AUTO mode) (MH)	168	0 to 255		
156	IAI protocol B/TCP: IP address of connection destination (AUTO mode) (ML)	0	0 to 255		
157	IAI protocol B/TCP: IP address of connection destination (AUTO mode) (L)	100	0 to 254		* Setting of "0" and "255" is prohibited.
158	IAI protocol B/TCP: Port number of connection destination (AUTO mode)	64611	0 to 65535		* "0" can be set in the case of a server. 0 = Port number of connection destination is ignored (only the IP address is checked) * "0" cannot be set in the case of a client.
159	IAI protocol B/TCP: Own port number (AUTO mode)	64516	1025 to 65535		* Important note: Always set a unique number for each port number. (Duplication of port numbers is permitted only in the IAI protocol B/TCP MANU/AUTO modes.)
160 to 169	(For network expansion)	0			
170 to 282	(For expansion)	0			
283	Physical input port number for input function selection 000	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 000 will be specified to input port No. 0.) (Main application version 0.19 or later)
284	Physical input port number for input function selection 001	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 001 will be specified to input port No. 1.) (Main application version 0.19 or later)
285	Physical input port number for input function selection 002	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 002 will be specified to input port No. 2.) (Main application version 0.19 or later)
286	Physical input port number for input function selection 003	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 003 will be specified to input port No. 3.) (Main application version 0.19 or later)
287	Physical input port number for input function selection 004	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 004 will be specified to input port No. 4.) (Main application version 0.19 or later)
288	Physical input port number for input function selection 005	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 005 will be specified to input port No. 5.) (Main application version 0.19 or later)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
289	Physical input port number for input function selection 006	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 006 will be specified to input port No. 6.) (Main application version 0.19 or later)
290	Physical input port number for input function selection 007	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 007 will be specified to input port No. 7.) * If "start program number" is specified for input function selection 007, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
291	Physical input port number for input function selection 008	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 008 will be specified to input port No. 8.) * If "start program number" is specified for input function selection 008, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
292	Physical input port number for input function selection 009	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 009 will be specified to input port No. 9.) * If "start program number" is specified for input function selection 009, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
293	Physical input port number for input function selection 010	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 010 will be specified to input port No. 10.) * If "start program number" is specified for input function selection 010, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
294	Physical input port number for input function selection 011	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 011 will be specified to input port No. 11.) * If "start program number" is specified for input function selection 011, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
295	Physical input port number for input function selection 012	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 012 will be specified to input port No. 12.) * If "start program number" is specified for input function selection 012, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
296	Physical input port number for input function selection 013	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 013 will be specified to input port No. 13.) * If "start program number" is specified for input function selection 013, specify the next larger input port number immediately adjacent to the LSB side of the start program number. (Main application version 0.19 or later)
297	Physical input port number for input function selection 014	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 014 will be specified to input port No. 14.) (Main application version 0.19 or later)
298	Physical input port number for input function selection 015	-1	-1 to 299		* Invalid if a negative value is set. (Input function selection 015 will be specified to input port No. 15.) (Main application version 0.19 or later)
299	Physical output port number for output function selection 300	0	0 to 599		* Invalid if "0" is set. (Output function selection 300 will be specified to output port No. 300.) (Main application version 0.19 or later)
300	Physical output port number for output function selection 301	0	0 to 599		* Invalid if "0" is set. (Output function selection 301 will be specified to output port No. 301.) (Main application version 0.19 or later)
301	Physical output port number for output function selection 302	0	0 to 599		* Invalid if "0" is set. (Output function selection 302 will be specified to output port No. 302.) (Main application version 0.19 or later)
302	Physical output port number for output function selection 303	0	0 to 599		* Invalid if "0" is set. (Output function selection 303 will be specified to output port No. 303.) (Main application version 0.19 or later)
303	Physical output port number for output function selection 304	0	0 to 599		* Invalid if "0" is set. (Output function selection 304 will be specified to output port No. 304.) (Main application version 0.19 or later)
304	Physical output port number for output function selection 305	0	0 to 599		* Invalid if "0" is set. (Output function selection 305 will be specified to output port No. 305.) (Main application version 0.19 or later)
305	Physical output port number for output function selection 306	0	0 to 599		* Invalid if "0" is set. (Output function selection 306 will be specified to output port No. 306.) (Main application version 0.19 or later)
306	Physical output port number for output function selection 307	0	0 to 599		* Invalid if "0" is set. (Output function selection 307 will be specified to output port No. 307.) (Main application version 0.19 or later)
307	Physical output port number for output function selection 308	0	0 to 599		* Invalid if "0" is set. (Output function selection 308 will be specified to output port No. 308.) (Main application version 0.19 or later)
308	Physical output port number for output function selection 309	0	0 to 599		* Invalid if "0" is set. (Output function selection 309 will be specified to output port No. 309.) (Main application version 0.19 or later)
309	Physical output port number for output function selection 310	0	0 to 599		* Invalid if "0" is set. (Output function selection 310 will be specified to output port No. 310.) (Main application version 0.19 or later)
310	Physical output port number for output function selection 311	0	0 to 599		* Invalid if "0" is set. (Output function selection 311 will be specified to output port No. 311.) (Main application version 0.19 or later)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
311	Physical output port number for output function selection 312	0	0 to 599		* Invalid if "0" is set. (Output function selection 312 will be specified to output port No. 312.) (Main application version 0.19 or later)
312	Physical output port number for output function selection 313	0	0 to 599		* Invalid if "0" is set. (Output function selection 313 will be specified to output port No. 313.) (Main application version 0.19 or later)
313	Physical output port number for output function selection 314	0	0 to 599		* Invalid if "0" is set. (Output function selection 314 will be specified to output port No. 314.) (Main application version 0.19 or later)
314	Physical output port number for output function selection 315	0	0 to 599		* Invalid if "0" is set. (Output function selection 315 will be specified to output port No. 315.) (Main application version 0.19 or later)
315	Physical output port number for output function selection 300 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 300 (area 2).) (Main application version 0.19 or later)
316	Physical output port number for output function selection 301 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 301 (area 2).) (Main application version 0.19 or later)
317	Physical output port number for output function selection 302 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 302 (area 2).) (Main application version 0.19 or later)
318	Physical output port number for output function selection 303 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 303 (area 2).) (Main application version 0.19 or later)
319	Physical output port number for output function selection 304 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 304 (area 2).) (Main application version 0.19 or later)
320	Physical output port number for output function selection 305 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 305 (area 2).) (Main application version 0.19 or later)
321	Physical output port number for output function selection 306 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 306 (area 2).) (Main application version 0.19 or later)
322	Physical output port number for output function selection 307 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 307 (area 2).) (Main application version 0.19 or later)
323	Physical output port number for output function selection 308 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 308 (area 2).) (Main application version 0.19 or later)
324	Physical output port number for output function selection 309 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 309 (area 2).) (Main application version 0.19 or later)
325	Physical output port number for output function selection 310 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 310 (area 2).) (Main application version 0.19 or later)
326	Physical output port number for output function selection 311 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 311 (area 2).) (Main application version 0.19 or later)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
327	Physical output port number for output function selection 312 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 312 (area 2).) (Main application version 0.19 or later)
328	Physical output port number for output function selection 313 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 313 (area 2).) (Main application version 0.19 or later)
329	Physical output port number for output function selection 314 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 314 (area 2).) (Main application version 0.19 or later)
330	Physical output port number for output function selection 315 (area 2)	0	0 to 599		* Invalid if "0" is set. (No output port will be specified for output function selection 315 (area 2).) (Main application version 0.19 or later)
331	Output function selection 300 (area 2)	0	0 to 20		0: General-purpose output 1: Error output of operation-cancellation level or higher (ON) 2: Error output of operation-cancellation level or higher (OFF) 3: Error output of operation-cancellation level or higher + Emergency stop output (ON) 4: Error output of operation-cancellation level or higher + Emergency stop output (OFF) (Main application version 0.19 or later)
332	Output function selection 301 (area 2)	0	0 to 20		0: General-purpose output 1: READY output (PIO trigger program operation permitted) 2: READY output (PIO trigger program operation permitted AND error output of operation-cancellation level or higher not present) 3: READY output (PIO trigger program operation permitted AND error output of cold-start level or higher not present) (Main application version 0.19 or later)
333	Output function selection 302 (area 2)	0	0 to 20		0: General-purpose output 1: Emergency stop output (ON) 2: Emergency stop output (OFF) (Main application version 0.19 or later)
334	Output function selection 303 (area 2)	0	0 to 5		0: General-purpose output 1: AUTO mode output 2: Output during automatic operation (other parameter No. 12) (Main application version 0.19 or later)
335	Output function selection 304 (area 2)	0	0 to 5		0: General-purpose output 1: Output if all valid axes are at their homes (= 0) 2: Output if all valid axes completed home return (coordinates have been confirmed) 3: Output if all valid axes are at their home preset coordinates
336	Output function selection 305 (area 2)	0	0 to 5		0: General-purpose output 2: Output when the axis 1 servo is ON (system monitor task output) 3: Reserved by the system (Main application version 0.19 or later)
337	Output function selection 306 (area 2)	0	0 to 5		0: General-purpose output 2: Output when the axis 2 servo is ON (system monitor task output) 3: Reserved by the system (Main application version 0.19 or later)
338	Output function selection 307 (area 2)	0	0 to 5		0: General-purpose output 2: Output when the axis 3 servo is ON (system monitor task output) 3: Reserved by the system (Main application version 0.19 or later)



I/O Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
339	Output function selection 308 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
340	Output function selection 309 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
341	Output function selection 310 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
342	Output function selection 311 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
343	Output function selection 312 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
344	Output function selection 313 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
345	Output function selection 314 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
346	Output function selection 315 (area 2)	0	0 to 5		0: General-purpose output (Main application version 0.19 or later)
347 to 400	(For future expansion)	0			



2. Parameters Common to All Axes

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Effective axis pattern	0000B	00B to 11111111B		
2	Default override	100	1 to 100		Used if not specified in program. (Invalid for SIO operation)
3 to 8	(For expansion)	0			
9	Deadman-switch enabling physical axis pattern	11111111B	00B to 11111111B		Not affected by a BASE command. (Always specify 11111111 if all axes are used. If not, the servo may be turned off only for the specified axes without cutting off the drive source (7-segment LED display does not show "DSF").) * In the case of an optional (custom) specification, the optional (custom) specification is given priority over the deadman-switch enabling physical axes, drive-source cutoff specification, servo OFF specification, 7-segment display specification, etc.
10	(For expansion)	0			
11	Default acceleration	20	1 to 200	0.01 G	Used if not specified in position data, program or SIO message, etc.
12	Default deceleration	20	1 to 200	0.01 G	Used if not specified in position data, program or SIO message, etc.
13	Default speed	30	1 to 250	mm/s	Used if not specified in SIO message or position data, when movement is to be continued, etc.
14	Valid selection when operation point data deceleration is 0	0	0 to 5		0: "Deceleration = Acceleration" when the deceleration in the operation point data is "0" 1: "Deceleration = 0" when the deceleration in the operation point data is "0"
15	Maximum jog speed when home return is incomplete	30	1 to 250	mm/s	
16 to 19	(For expansion)	0	~		
20	Maximum operating speed check timing	1	0 to 1		0: Check at input 1: Check at operation * If "Check at operation" is selected, the distribution speed (CP) of specified speed or the specified speed (PTP) will be compared against the maximum operating speed of each axis and clamped at the allowable speed. Accordingly, the system can achieve its maximum performance in accordance with the operation command. However, complete check cannot be performed at input (since the command/operation start position is indeterminable). In the case of CP, the distribution speed will vary depending on the operation start position. Therefore, specifying CP at an unspecified position (first point movement, etc.) will cause the speed to fluctuate depending on where the operation is started.
21	Maximum operating speed for input value check	300	1 to 9999	mm/s	If "Input" is selected as the maximum speed check timing, this parameter will be used to check for input error.
22	Maximum acceleration	100	1 to 999	0.01 G	
23	Maximum deceleration	100	1 to 999	0.01 G	
24	Minimum emergency deceleration	30	1 to 300	0.01 G	
25	(Acceleration/deceleration at home return (old))	30	1 to 300	0.01 G	(Invalid)
26	Acceleration/deceleration specification type	0	0 to 5		0: T system, 1: P, M system
27	Master axis type	0	0 to 5		0: T system, 1: P system



Parameters Common to All Axes

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
28	Selection of inching → jog auto-switching prohibition	0	0 to 5		0: Execute auto-switching (Continuous button ON timer), 1: Prohibited * Referenced by the PC/TP. (Handy terminal automatic switching function is not available.)
29	All-axis setting bit pattern 1	0	0H to FFFFFFFH		Bits 0 to 3: Selection of use of last PC/TP inching distance (0: Do not use, 1: Use) * Referenced by the PC/TP (Excluding ANSI-compatible TP) (PC software version 2.0.0.42 or later or TP application version 1.09 or later). Bits 4 to 7: Overrun (servo) error level (0: Operation-cancellation level, 1: Cold-start level, 2: Operation-cancellation level at reset, thereafter cold-start level) Bits 8 to 11: "Actual-position soft limit over (servo)" error level (0: Operation-cancellation level, 1: Cold-start level, 2: Operation-cancellation level at reset, thereafter cold-start level)
30	Default division angle	150	0 to 1200	0.1 degree	("0" can be input in PC software version 1.1.1.0 or later or TP application version 1.06 or later)
31	Default division distance	0	0 to 10000	mm	("0" can be input in PC software version 1.1.1.0 or later or TP application version 1.06 or later)
32	Arch-trigger start-point check type	0	0 to 5		0: Check operation amount and actual position, 1: Check operation amount only
33	Safety speed in manual mode	250	1 to 250	mm/s	* This parameter is treated as a value equivalent to or below the minimum value set in "Axis-specific parameter No. 29, VLMX speed" for all valid axes.
34 to 50	(For expansion)	0	~		

PC: PC software
TP: Teaching pendant



3. Axis-Specific Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Axis operation type	0	0 to 1		0: Linear movement axis, 1: Rotational movement axis (Angle control)
2 to 5	(For expansion)	0	~		
6	Coordinate/physical-operation direction selection	1	0 to 1		0: Motor CCW → Positive direction on the coordinate system 1: Motor CCW → Negative direction on the coordinate system
7	Soft limit +	50000	-99999999 to 99999999	0.001 mm	Fixed to 359.999 degrees internally in the index mode. Invalid in the infinite-stroke mode.
8	Soft limit –	0	-99999999 to 99999999	0.001 mm	Fixed to 0 degree internally in the index mode. Invalid in the infinite-stroke mode.
9	Soft-limit actual position margin	2000	0 to 9999	0.001 mm	Actual position margin in the positioning boundary critical zone in the infinite-stroke mode
10	Home-return method	0	0 to 5		0: Search phase Z after end search 1: Current position 0 home (This parameter can be specified only with an incremental encoder. Pay attention to contact.), 2: Current position = Preset home (This parameter can be specified only with an incremental encoder. Pay attention to contact.)
11	Home-return end-search direction selection	0	0 to 1		0: Negative end of the coordinate system 1: Positive end of the coordinate system
12	Home preset value	0	-99999999 to 99999999	0.001 mm	(Refer to axis-specific parameter No. 76)
13	SIO/PIO home-return order	0	0 to 16		Executed from the smallest one.
14	For future expansion (Change prohibited)	0	Reference only		
15	For future expansion (Change prohibited)	0	Reference only		
16	For future expansion (Change prohibited)	0	Reference only		
17	For future expansion (Change prohibited)	10	Reference only	mm/sec	
18	For future expansion (Change prohibited)	100	Reference only	mm/sec	
19	End search speed at home return	20	1 to 100	mm/sec	
20	Phase-Z search speed at home return	3	1 to 10	mm/sec	Exercise caution, since limitations apply depending on the read/encoder pulse count.
21	Offset travel distance at home return	2500	-99999999 to 99999999	0.001 mm	Offset travel distance from the ideal phase-Z position (Positive value = Applied in the direction of moving away from the end) (Refer to axis-specific parameter No. 76)
22	Error check tolerance for phase-Z position at home return	0	0 to 99999999	0.001 mm	Minimum allowable actual distance of "End (mechanical or LS) – Phase Z," in the case of a rotary encoder
23	Phase-Z count per encoder revolution	1	1 to 8		Only "1" can be set, in the case of an absolute encoder.
24	Push stop check time at home return	1500	1 to 5000	msec	Used to check the push motion during home return.
25	Push stop check time at positioning	500	1 to 5000	msec	Used to check the push motion during PUSH command operation.
26	(Phase-Z evacuation distance at absolute home return (old))	1000	0 to 99999	0.001 mm	Evacuation distance from the actual phase-Z position (Positive value = Applied in the direction of moving away from the end) (Phase-shift prevention margin) (Refer to axis-specific parameter No. 76)
27	Maximum motor speed	5000	Reference only	rpm, mm/sec	Rpm value in the case of a rotary encoder (Change prohibited)
28	Maximum operating speed of each axis	300	1 to 9999	mm/s	
29	VLMX speed	300	1 to 9999	mm/s	During VLMX operation, the maximum operating speed of each axis or VLMX speed, whichever is lower, is used as the maximum speed of the applicable axis.
30	Servo ON check time	20	0 to 5000	msec	Brake equipped: Time after receiving a servo-ON start response until start of brake unlocking Brake not equipped: Time after receiving a servo ON start response until transition to an operation-enabled status



Axis-Specific Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
31	Offset travel speed at home return	3	1 to 500	mm/sec	
32	Actual distance between phase Z and end	0	-1 to 99999	0.001 mm	Absolute distance from the end (mechanical or LS). Obtained automatically if the distance is a negative value. When multiple actuators are combined, it is recommended to write the flash ROM after automatic acquisition. (Refer to axis-specific parameter No. 76)
33	Ideal distance between phase Z and end	0	0 to 99999	0.001 mm	Absolute distance from the end (mechanical or LS). (Refer to axis-specific parameter No. 76)
34	Brake equipment specification	0	0 to 1		0: Not equipped, 1: Equipped
35	Brake unlock check time	10	0 to 3000	msec	Time after receiving a brake-unlock start response until transition to an operation-enabled status
36	Brake lock check time	10	0 to 1000	msec	Time after receiving a brake-lock start response until start of servo OFF
37	Change prohibited	0	0 to 1		0: Rotary encoder
38	Encoder ABS/INC type	0	0 to 1		0: INC, 1: ABS
39	Change prohibited	1	0 to 1		
40	Pole-sense initial tryout direction selection (For future expansion = Change prohibited)	0	0 to 1		0: Negative end of the coordinate system 1: Positive end of the coordinate system
41	Pole sense speed (For future expansion = Change prohibited)	25	1 to 100	DRVVR	
42	Encoder resolution	800	0 to 99999999	Pulse/rev, 0.001 μ m/pulse	Pulses (before division)/rev, in the case of a rotary encoder
43	Encoder division ratio	0	-7 to 7		Pulses are multiplied by ("n"th power of 1/2).
44	Length measurement correction	0	-99999999 to 99999999	0.001 mm/1M	Valid only for linear movement axes. (Coordinates other than the encoder reference Z point will change proportionally.)
45 to 46	(For expansion)	0			
47	Screw lead	6000	1 to 99999999	0.001 mm	Valid only for linear movement axes.
48 to 49	(For expansion)	0			
50	Gear ratio numerator	1	1 to 99999999		
51	Gear ratio denominator	1	1 to 99999999		
52	(For expansion)	0			
53	Setting bit pattern 1 of each axis	0	0H to FFFFFFFFH		
54	Travel distance for push stop detection at home return	20	1 to 99999	0.001 mm	Used to check the push motion during home return.
55	Travel distance for push stop detection at positioning	30	1 to 99999	0.001 mm	Used to check the push motion during PUSH command operation.
56	Push-abort deviation ratio at home return	5000	1 to 99999		Deviation is compared against "Steady-state deviation of push speed + Push-speed pulse speed x Abort deviation ratio."
57	Push-abort deviation ratio at positioning	5000	1 to 99999		Deviation is compared against "Steady-state deviation of push speed + Push-speed pulse speed x Abort deviation ratio."
58	Positioning band	100	1 to 9999	0.001 mm	
59	Allowable deviation error ratio (Maximum speed pulse ratio)	300	1 to 9999		Deviation is compared against "Steady-state deviation of maximum operating speed of each axis + Pulse speed of maximum operating speed of each axis x Allowable deviation error ratio."
60	Position gain	45	1 to 9999	/s	



Axis-Specific Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
61	FF gain	0	0 to 500	%	
62	Synchro FB gain	77	0 to 1000		
63	Stop special output range	0	0 to 9999	Pulse	Invalid if "0" is set.
64	Stop special output value	0	0 to 999	DRVVR	
65	Mating synchro-axis number	0	0 to 8		Must be input for both axes. (Of the axis pair, the axis with the smaller axis number becomes the master axis. Both axes must have the same resolution characteristics. Commands cannot be issued to the slave axis.) (Invalid if "0" is set)
66	Mode selection for rotational movement axis	0	0 to 5		0: Normal, 1: Index mode
67	Short-cut control selection for rotational movement axis	0	0 to 5		0: Do not select, 1: Select (Valid only in the index mode AND when an incremental encoder is used)
68	Mode selection for linear movement axis	0	0 to 5		0: Normal, 1: Infinite-stroke mode (Note: Positioning boundary applies. This setting can be specified only when an incremental encoder is used.)
69	(For expansion)	0	~		
70	DRVVR value at maximum motor speed	32767	Reference only	DRVVR	For adjustment by the manufacturer
71	DRVVR value at 3x motor torque	32767	Reference only	DRVVR	For adjustment by the manufacturer
72	DRVVR + offset	1	Reference only	DRVVR	For adjustment by the manufacturer
73	DRVVR - offset	0	Reference only	DRVVR	For adjustment by the manufacturer
74	DRVVR MAX	32436	Reference only	DRVVR	For adjustment by the manufacturer
75	DRVVR MIN	-32435	Reference only	DRVVR	For adjustment by the manufacturer
76	Home-adjustment parameter set selection	1	Reference only		(Change prohibited) 0: P21 = Phase-Z evacuation distance at incremental home return P12 = Ideal phase-Z position coordinate 1: P33 = Automatically loaded even when "0"; set to "actual distance" when P33 = "0" P21 = Offset travel distance at home return P12 = Coordinates after offset travel at home return P26 is invalid. (For simplification of adjustment)
77	Synchro S pulse	3	0 to 99999	Pulse	
78	Maximum takeoff command amount	0	-3000 to 3000	0.001 mm	Maximum lift command amount before brake unlock (Input with sign) (Suppression of momentary drop upon servo ON when a heavy object is placed) * Important: Input using the same sign as the rising coordinate direction. (0.100 mm to 0.500 mm in absolute value as a guideline) * The servo-ON check time (axis-specific parameter No. 30) must also be extended (approx. 1000 to 1500 msec) to provide a sufficient time for rise-direction torque to follow. (This setting is valid only when a brake is equipped.)
79	Actual takeoff check distance	5	0 to 3000	0.001 mm	Absolute value input
80	Maximum forced-feed range	0	0 to 9999	0.001 mm	For reduction of settling time. (Invalid range if "0" is set) (Approx. 1.000 mm as a guideline)
81	Minimum forced-feed range	200	0 to 9999	0.001 mm	
82	Medium forced-feed range	600	0 to 9999	0.001 mm	
83	Absolute synchro slave-axis initialization cancellation	0	0 to 5		Valid only with a synchro slave axis.
84	Maximum synchronization correction speed of synchro slave axis	5	0 to 100	mm/sec	Maximum travel speed for synchronization position correction of slave axis. Valid only with a synchro slave axis. * Note: Not limited by the safety speed.
85	Home-return acceleration/ deceleration	15	1 to 300	0.01 G	
86	Zone 1 MAX	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.



Axis-Specific Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
87	Zone 1 MIN	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
88	Zone 1 output number	0	0 to 899		Physical output port or global flag (Output is invalid if "0" is input; multiple specification is invalid) ("0" can be input in PC software version 1.0.0.0 or later or TP application version 1.06 or later)
89	Zone 2 MAX	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
90	Zone 2 MIN	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
91	Zone 2 output number	0	0 to 899		Physical output port or global flag (Output is invalid if "0" is input; multiple specification is invalid) ("0" can be input in PC software version 1.0.0.0 or later or TP application version 1.06 or later)
92	Zone 3 MAX	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
93	Zone 3 MIN	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
94	Zone 3 output number	0	0 to 899		Physical output port or global flag (Output is invalid if "0" is input; multiple specification is invalid) ("0" can be input in PC software version 1.0.0.0 or later or TP application version 1.06 or later)
95	Zone 4 MAX	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
96	Zone 4 MIN	0	-99999999 to 99999999	0.001 mm	Valid only when MAX > MIN. * Must be inside the range for at least 3 msec.
97	Zone 4 output number	0	0 to 899		Physical output port or global flag (Output is invalid if "0" is input; multiple specification is invalid) ("0" can be input in PC software version 1.0.0.0 or later or TP application version 1.06 or later)
98 to 120	(For expansion)	0	~		

PC: PC software
TP: Teaching pendant



4. Driver Card Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Type (upper) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
2	Type (middle) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
3	Type (lower) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
4	Manufacturing data 4 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
5	Manufacturing data 5 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
6	Manufacturing data 6 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
7	Manufacturing data 7 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
8	Board type (Function information)	30	Reference only		For adjustment by the manufacturer
9	Function information 01 (hard): Encoder support information (upper word)	0000H	Reference only	Encoder ID bit pattern	For adjustment by the manufacturer
10	Function information 02 (hard): Encoder support information (lower word)	0001H	Reference only	Encoder ID bit pattern	
11	Function information 03 (hard): Hardware support information word 0	0004H	Reference only		Bit 0: Brake support specification bit (1: Supported, 0: Not supported) Bit 1: For future expansion Bit 2: Motor capacity specification bit (1: □42/□56 motor, 0: □20/□28 motor)
12	Function information 04 (hard): For future expansion	0000H	Reference only		For adjustment by the manufacturer
13	Function information 05 (hard): For future expansion	0000H	Reference only		For adjustment by the manufacturer
14	Function information 06 (hard): For future expansion	0000H	Reference only		For adjustment by the manufacturer
15	Function information 07 (soft): Motor support information (upper word)	0000H	Reference only	Motor ID bit pattern	For adjustment by the manufacturer
16	Function information 08 (soft): Motor support information (lower word)	FFFFH	Reference only	Motor ID bit pattern	
17	Function information 09 (soft): Encoder support information (upper word)	0000H	Reference only	Encoder ID bit pattern	For adjustment by the manufacturer
18	Function information 10 (soft): Encoder support information (lower word)	0001H	Reference only	Encoder ID bit pattern	
19	Function information 11 (soft): Software support information word 0 (For future expansion = Change prohibited)	0000H	Reference only		Bit 0: For future expansion
20	Function information 12 (soft): Software version information	0000H	Reference only		
21	Function information 13 (soft): For future expansion	0000H	Reference only		For adjustment by the manufacturer
22	Function information 14 (soft): System log control word	0000H	Reference only		Bits 0 to 4: For future expansion
23	Configuration information 01: Configured capacity (rated motor output)	0011H	Reference only		



Driver Card Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
24	Configuration information 02: Configured voltage (motor voltage)	0018H	Reference only		
25	Configuration information 03: Motor/encoder configuration information	0500H	Reference only	Motor/encoder ID bit number	
26	Configuration information 04: For future expansion	0000H	Reference only		For adjustment by the manufacturer
27	Configuration information 05: Encoder resolution (upper word)	0000H	Reference only		
28	Configuration information 06: Encoder resolution (lower word)	0320H	Reference only		
29	Configuration information 07: Motor/encoder characteristics word	0004H	Reference only		Bit 0: Change prohibited (0: Rotary) Bit 1: Change prohibited (0: Incremental) Bit 2: Change prohibited (1: Magnetic sensor equipped) Bit 3: Brake equipment bit (1: Equipped, 0: Not equipped)
30	Configuration information 08: For future expansion	0000H	Reference only		For adjustment by the manufacturer
31	Configuration information 09: Control characteristics word	0000H	Reference only		For adjustment by the manufacturer
32	Configuration information 10: Push torque limit at home return	40	0 to 150	%	
33	Configuration information 11: Push torque limit at positioning	70	0 to 70	%	
34	Configuration information 12: Control characteristics word 2	300H	0000 to FFFF		Bits 0 to 7: For future expansion Bit 8: Initial moving direction in excitation-phase signal detection operation (0: CW, 1: CCW) Bit 9: Stop mode selection (0: Full servo mode, 1: Complete stop mode) * In the case of coating or other application where operation focus is given to the locus, select "0" (full servo mode). (In this case, the complete stop function is disabled.) In all other applications, "1" (complete stop mode) is normally selected.
35	Configuration information 13: For future expansion	0H	Reference only		
36	Configuration information 14: For future expansion	0H	Reference only		
37	Configuration information 15: For future expansion	0H	Reference only		For adjustment by the manufacturer
38	For future expansion	0H	Reference only		
39	For future expansion	0H	Reference only		
40	For future expansion	0H	Reference only		
41	For future expansion	0H	Reference only		
42	Torque filter time constant	0H	0 to 2500		
43	For future expansion	0H	Reference only		
44	Speed-loop proportional gain time constant (upper word)	0H	0000H to 0000H		For pulse motor
45	Speed loop proportional gain (lower word)	12CH	0000H to 7530H		For pulse motor
46	Speed loop integral gain (upper word)	0H	0000H to 0004H		For pulse motor
47	Speed loop integral gain (lower word)	11F9H	0000H to FFFFH		For pulse motor
48	Excitation-phase fixed mode parameter	0H	Reference only		For pulse motor (Percentage of rated motor current)



Driver Card Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
49	For future expansion	0H	Reference only		
50	For future expansion	0H	Reference only		
51	For future expansion	0H	Reference only		
52	For future expansion	0H	Reference only		
53	For future expansion	0H	Reference only		
54	For future expansion	0H	Reference only		
55	For future expansion	0H	Reference only		
56	For future expansion	0H	Reference only		
57	For future expansion	0H	Reference only		
58	For future expansion	0H	Reference only		
59	For future expansion	0H	Reference only		
60	For future expansion	0H	Reference only		
61	For future expansion	0H	Reference only		
62	For future expansion	0H	Reference only		
63	For future expansion	0H	Reference only		
64	For future expansion	0H	Reference only		
65	For future expansion	0H	Reference only		
66	For future expansion	0H	Reference only		
67	For future expansion	0H	Reference only		
68	For future expansion	0H	Reference only		
69	For future expansion	0H	Reference only		
70	For future expansion	0H	Reference only		
71	For future expansion	0H	Reference only		
72	For future expansion	0H	Reference only		
73	For future expansion	0H	Reference only		
74	For future expansion	0H	Reference only		
75	For future expansion	0H	Reference only		
76	For future expansion	0H	Reference only		
77	For future expansion	0H	Reference only		
78	For future expansion	0H	Reference only		
79	For future expansion	0H	Reference only		
80	For future expansion	0H	Reference only		
81	For future expansion	0H	Reference only		
82	For future expansion	0H	Reference only		
83	For future expansion	0H	Reference only		
84	For future expansion	0H	Reference only		
85	For future expansion	0H	Reference only		
86	For future expansion	0H	Reference only		
87	For future expansion	0H	Reference only		
88	For future expansion	0H	Reference only		
89	For future expansion	0H	Reference only		
90	For future expansion	0H	Reference only		
91	For future expansion	0H	Reference only		
92	For future expansion	0H	Reference only		
93	For future expansion	0H	Reference only		
94	For future expansion	0H	Reference only		
95	For future expansion	0H	Reference only		
96	For future expansion	0H	Reference only		
97	For future expansion	0H	Reference only		



Driver Card Parameters

98	Overrun error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
99	FPGA detection error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
100	Speed-command underrun-count error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
101	For future expansion (Query information)	0H	Reference only		For adjustment by the manufacturer
102	Overload error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
103	Overspeed error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
104	Overcurrent error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
105	Overheat error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
106	Encoder error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
107	CPU error counter (Query information)	0H	Reference only		For adjustment by the manufacturer
108	Phase-U current sense adjustment value (Query information)	0H	Reference only		For adjustment by the manufacturer
109	Phase-W current sense adjustment value (Query information)	0H	Reference only		For adjustment by the manufacturer
110	For future expansion (Query information)	0H	Reference only		For adjustment by the manufacturer
111	For future expansion (Query information)	0H	Reference only		For adjustment by the manufacturer
112	For future expansion (Query information)	0H	Reference only		For adjustment by the manufacturer



5. Encoder Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Type (upper) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
2	Type (middle) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
3	Type (lower) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
4	Manufacturing data 4 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
5	Manufacturing data 5 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
6	Manufacturing data 6 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
7	Manufacturing data 7 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
8	Board type (Function information)	0	Reference only		For adjustment by the manufacturer
9	Function information 01: Configured capacity (rated motor output)	0000H	Reference only	W	For adjustment by the manufacturer
10	Function information 02: Configured voltage (motor voltage)	0000H	Reference only	V	For adjustment by the manufacturer
11	Function information 03: Motor/encoder configuration information	0000H	Reference only	Motor/encoder ID bit number	For adjustment by the manufacturer
12	Function information 04: Encoder resolution (upper word)	0000H	Reference only		For adjustment by the manufacturer
13	Function information 05: Encoder resolution (lower word)	0000H	Reference only		For adjustment by the manufacturer
14	Function information 06: Motor/encoder characteristics word	0000H	Reference only		For adjustment by the manufacturer
15	Function information 07: Motor/encoder control word 1 (Also applicable to nX-E)	0000H	Reference only	0.1 N (Kelvin = Temperature scale)	For adjustment by the manufacturer
16	Function information 08: Motor/encoder control word 2 (Also applicable to nX-E)	0000H	Reference only		For adjustment by the manufacturer
17	Function information 09: Motor/encoder control word 3 (Also applicable to nX-E)	0000H	Reference only		For adjustment by the manufacturer
18	Function information 10: Motor/encoder control word 4 (Also applicable to nX-E)	0000H	Reference only		For adjustment by the manufacturer
19	Function information 11: (For future expansion)	0000H	Reference only		For adjustment by the manufacturer
20	Function information 12: (For future expansion)	0000H	Reference only		For adjustment by the manufacturer
21	Function information 13: (For future expansion)	0000H	Reference only		For adjustment by the manufacturer
22	Function information 14: (For future expansion)	0000H	Reference only		For adjustment by the manufacturer
23 to 30	Card parameter (by board type)	0000H	Reference only		For adjustment by the manufacturer



6. I/O-Slot Card Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Type (upper) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
2	Type (middle) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
3	Type (lower) (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
4	Manufacturing data 4 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
5	Manufacturing data 5 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
6	Manufacturing data 6 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
7	Manufacturing data 7 (Manufacturing information)	Space	Reference only		For adjustment by the manufacturer
8	Board type (Function information)	0	Reference only		For adjustment by the manufacturer
9	Function information 01 (by board type)	0000H	Reference only		For adjustment by the manufacturer
10	Function information 02 (by board type)	0000H	Reference only		For adjustment by the manufacturer
11	Function information 03 (by board type)	0000H	Reference only		For adjustment by the manufacturer
12	Function information 04 (by board type)	0000H	Reference only		For adjustment by the manufacturer
13	Function information 05 (by board type)	0000H	Reference only		For adjustment by the manufacturer
14	Function information 06 (by board type)	0000H	Reference only		For adjustment by the manufacturer
15	Function information 07 (by board type)	0000H	Reference only		For adjustment by the manufacturer
16	Function information 08 (by board type)	0000H	Reference only		For adjustment by the manufacturer
17	Function information 09 (by board type)	0000H	Reference only		For adjustment by the manufacturer
18	Function information 10 (by board type)	0000H	Reference only		For adjustment by the manufacturer
19	Function information 11 (by board type)	0000H	Reference only		For adjustment by the manufacturer
20	Function information 12 (by board type)	0000H	Reference only		For adjustment by the manufacturer
21	Function information 13 (by board type)	0000H	Reference only		For adjustment by the manufacturer
22	Function information 14 (by board type)	0000H	Reference only		For adjustment by the manufacturer
23 to 112	Card parameter (by board type)	0000H	Reference only		For adjustment by the manufacturer



7. Other Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
1	Auto-start program number	0	0 to 64		(Invalid if "0" is set)
2	I/O processing program number at operation/program abort	0	0 to 64		The start trigger is determined from the "I/O processing program start type at operation/program abort." (Note: This program will be started before confirming an abort of other programs.) (Invalid if "0" is set) * If the setting is valid, the number of user program tasks that can be used will decrease by 1. Other programs cannot be started from this program.
3	I/O processing program number at all operation pause	0	0 to 64		This program will be started when an all-operation-pause command is issued due to an all-operation-pause factor. (Only when a program is running) (Invalid if "0" is set) * If the setting is valid, the number of user program tasks that can be used will decrease by 1.
4	Program abort type at error	0	0 to 5		0: Cancel only the program in which an error of operation-cancellation level or higher has generated. (If the error requires the drive source to be cut off, all programs other than the "I/O processing program at operation/program abort" will be cancelled.) 1: Cancel all programs other than the "I/O processing program at operation/program abort" when an error of operation-cancellation level or higher has generated.
5	I/O processing program start type at operation/program abort	0	0 to 5		0: When all-operation-cancellation factor has generated (Only when a program is running) 1: When all-operation-cancellation factor has generated (Always) 2: All-operation-cancellation factor + Error of operation-cancellation level or higher ("Other parameter No. 4 = 0" is considered) (Only when a program is running) 3: All-operation-cancellation factor + Error of operation-cancellation level or higher ("Other parameter No. 4 = 0" is considered) (Always)
6	PC/TP reconnection delay at software reset	11000	1 to 99999	msec	* The setting will become effective after the controller, PC software or TP is shut down and restarted.
7 to 8	(For expansion)	0			
9	Deadman-switch recovery type	0	0 to 2		0: Abort operations/programs 2: Operation continued (Only during automatic operation. * In the PC software version is 1.0.0.5 or later or TP application version is 1.01 or later, operation commands from the PC software/TP will be aborted on the PC software/TP side.)

PC: PC software

TP: Teaching pendant



Other Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
10	Emergency-stop recovery type	0	0 to 4		0: Abort operations/programs 1: Recovery after reset 2: Operation continued (Only during automatic operation. * If the PC software version is 1.0.0.5 or later or TP application version is 1.01 or later, operation commands from the PC software/TP will be aborted on the PC software/TP side.) 3: Abort operations/programs (Software reset when the emergency stop is reset. The home-return completion status of incremental-encoder axes will be reset (EG approximation swap).) 4: Abort operations/programs (Error reset (only with an error of operation-cancellation level or lower) and auto-start program start (only if AUTO mode AND I/O parameter No. 33 = 1 AND I/O parameter No. 44 ≠ 1 AND all-operation-cancellation factor is not present) when the emergency stop is reset). There must be a minimum interval of 1 second after an emergency stop is actuated before it is reset. The home-return completion status of incremental-encoder axes will be retained.)
11	For future expansion	0	Reference only		
12	Automatic operation recognition type	0	0 to 3		0: Program is running AND all-operation-cancellation factor is not present 1: [Program is running OR in AUTO mode] AND all-operation-cancellation factor is not present
13 to 19	(For expansion)	0			
20	System-memory backup battery installation function type	0	0 to 2		0: Not installed (SEL global data/error lists cannot be recovered from the flash ROM) 1: For future expansion (Setting prohibited) 2: For future expansion (Setting prohibited) * If "0" is set, the SEL global data and error lists will not be retained after the power is turned off. However, the error lists will be retained after a software reset. (Main application version 0.10 or later) * After the power is turned on with the system-memory backup battery not installed, the point data can be copied from the flash memory.

PC: PC software
TP: Teaching pendant



Other Parameters

No	Parameter name	Default value (Reference)	Input range	Unit	Remarks
21	Manual mode type	0	0 to 5		0: Always enable edit and SIO/PIO start (Initial condition after connection = With safety speed) 1: Select edit and start (with password) (EU, etc.) 2: Always enable edit and SIO/PIO start (Initial condition after connection = Without safety speed (cancellation)) (PC software version 1.1.0.7 or later and TP application version 1.06 or later) * Referenced by the PC/TP.
22	Control use region	0	0 to 99		0: J, 1: E, 2: EU
23	PSIZ command function type	0	0 to 5		0: Maximum number of point data areas 1: Number of point data used
24	Local variable number for storing SEL communication command return code	99	1 to 99 1001 to 1099		
25 to 29	(For expansion)	0			
30	Option Password 00	0H	0H to FFFFFFFFH		HOME command option (Change prohibited) * Change is prohibited unless instructed by the manufacturer.
31	Option Password 01	0H	0H to FFFFFFFFH		Reserved (Change prohibited) * Change is prohibited unless instructed by the manufacturer.
32	Option Password 02	0H	0H to FFFFFFFFH		Reserved (Change prohibited) * Change is prohibited unless instructed by the manufacturer.
33 to 35	(For expansion)	0H	0H to FFFFFFFFH		
36	PC/TP data protect setting (Program)	0H	0H to FFFFFFFFH		Bits 0 to 3: Protect type (0: Read/write, 1: Read only, 2: No read/write) Bits 4 to 7: Protect release method (0: Special operation) Bits 8 to 11: Protect range maximum number (1's place, BCD) Bits 12 to 15: Protect range maximum number (10's place, BCD) Bits 16 to 19: Protect range minimum number (1's place, BCD) Bits 20 to 23: Protect range minimum number (10's place, BCD) * Referenced by the PC/TP (PC software version 2.0.0.42 or later and TP application version 1.09 or later)
37	PC/TP data protect setting (Position)	0H	0H to FFFFFFFFH		Bits 0 to 3: Protect type (0: Read/write, 1: Read only, 2: No read/write) Bits 4 to 7: Protect release method (0: Special operation) Bits 8 to 11: Protect range maximum number (10's place, BCD) Bits 12 to 15: Protect range maximum number (100's place, BCD) Bits 16 to 19: Protect range maximum number (1000's place, BCD) Bits 20 to 23: Protect range minimum number (10's place, BCD) Bits 24 to 27: Protect range minimum number (1000's place, BCD) * The value in the 1's place is considered "0" for both the protect range maximum/minimum numbers. * Referenced by the PC/TP (PC software version 2.0.0.42 or later and TP application version 1.09 or later)

PC: PC software

TP: Teaching pendant



Other Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
38	PC/TP data protect setting (Symbol, parameter)	0H	0H to FFFFFFFFH		Bits 0 to 3: Protect type (Parameter) (0: Read/write, 1: Read only, 2: No read/write) Bits 4 to 7: Protect release method (Parameter) (0: Special operation) Bits 8 to 11: Protect type (Symbol) (0: Read/write, 1: Read only, 2: No read/write) Bits 12 to 15: Protect release method (Symbol) (0: Special operation) * Referenced by the PC/TP (PC software version 2.0.0.42 or later and TP application version 1.09 or later)
39	(For future expansion)	0H	0H to FFFFFFFFH		
40	EEPROM information check type	3H	Reference only		For adjustment by the manufacture
41	Hardware information check type	E0H	Reference only		For adjustment by the manufacture
42	Hardware test type	7H	Reference only		For adjustment by the manufacture
43	Special monitor type	0H	0H to FFFFFFFFH		Change strictly prohibited unless specified by the manufacturer.
44	(For expansion)	0			
45	Special start condition setting	0	0H to FFFFFFFFH		Bits 0 to 3: Enable start from PC/TP in AUTO mode = Used exclusively by the manufacturer (0: Do not enable, 1: Enable) Bits 4 to 7: PIO program start (Input port 000) Single start selection (0: Normal, 1: Single start) * When single start is selected, the next PIO program start (input port 000) will not be accepted as long as a program with the same program number as the one started by the last PIO program start (input port 000) is running. Bits 8 to 11: Permission of auto program start when all-operation-cancellation factor is present (0: Do not permit, 1: Permit) Bits 12 to 15: Permission of ON edge acceptance for PIO program start (input port 000) when all-operation-cancellation factor is present (0: Do not permit, 1: Permit) * This parameter specifies an ON-edge acceptance condition. If the starting condition is not satisfied, an "Error No. A1E: Start condition non-satisfaction error" will generate.

PC: PC software
TP: Teaching pendant



Other Parameters

No.	Parameter name	Default value (Reference)	Input range	Unit	Remarks
46	Other setting bit pattern 1	2001H	0H to FFFFFFFH		<p>Bits 0 to 3: Variable-value format type in response message to real-number/variable query (0: Big endian with four upper/lower binary-converted bytes reversed, 1: Big endian)</p> <p>Bits 4 to 7: Decimal-place rounding selection for real-number → integer-variable assignment in LET/TRAN commands (Main application version 0.53 or later) (0: Do not round, 1: Round)</p> <p>Bits 8 to 11: For future expansion * May be affected by hardware compatibility. * Change strictly prohibited unless specified by the manufacturer.</p> <p>Bits 12 to 15: Selection of processing to be performed when subroutine first step input condition is not specified when TPCD command = 1 (0: Do not execute, 1: Execute, 2: Error)</p> <p>Bits 16 to 19: Selection of effective period for CHVL command speed (0: Effective only while the current main packet is active, 1: Effective during continuous handling of packets) * If "1" is selected, the speed specified by the CHVL command will be retained during the subsequent operations executed by continuous movement commands such as PATH (commands that require input of continuous program steps). Also take note of the following limitations:</p> <ul style="list-style-type: none"> • If the speed specified by the CHVL command is greater than the actual speed of the command operation immediately before, the actual speed of the last command operation will apply. • If the CHVL command is executed during a series of continuous movement commands and the command execution timing coincides with the connection of a position movement packet, the current speed may change to the specified speed in two stages. • The connection speed of each position movement packet may increase in proportion to the deceleration. (Example: The packet connection speed may increase by 9.8 mm/sec at a deceleration of 1.0 G or by 4.9 mm/sec at a deceleration of 0.5 G.) <p>For other items that require attention, refer to Notes in the CHVL command section of the operation manual.</p>
47 to 50	(For expansion)	0			



8. Manual Operation Types

The selectable operation types will vary depending on the setting of the “Manual operation type” parameter (Other parameter No. 21).

(1) PC software

[1] Setting = 0 (Always enable edit and SIO/PIO start)

Operation type	Password	Functions				
		Edit	Safety speed	Jog, move, continuous move	SIO program start	PIO program start
With safety speed	Not required.	○	○	○	○	○
Without safety speed	Not required.	○		○	○	○

[2] Setting = 1 (Select edit and start (with password))

Operation type	Password	Functions				
		Edit	Safety speed	Jog, move, continuous move	SIO program start	PIO program start
Edit and jog	Not required.	○	○	○		
SIO start and jog (safety speed)	1817 (*1)		○	○	○	
SIO start and jog	1818 (*1)			○	○	
SIO/PIO start and jog	1819 (*1)			○	○	○

(*1) PC software version 0.0.6.0 or later (“0000” in versions 0.0.0.0 through 0.0.5.x)

(2) Teaching pendant

[1] Setting = 0 (Always enable edit and SIO/PIO start)

Safety-speed enable selection	Password	Functions				
		Edit	Safety speed	Jog, move, continuous move	SIO program start	PIO program start
Enable	Not required.	○	○	○	○	○
Disable	Not required.	○		○	○	○

[2] Setting = 1 (Select edit and start (with password))

Safety-speed enable selection	Password	Functions				
		Edit	Safety speed	Jog, move, continuous move	SIO program start	PIO program start
Enable	Not required.	○	○	○	○	(*3)
Disable	1818 (*1)	○		○	○	(*3)

*2

PIO start prohibition selection	Password	Functions				
		Edit	Safety speed	Jog, move, continuous move	SIO program start	PIO program start
Prohibit	Not required.	○	(*4)	○	○	
Enable	1819 (*1)	○	(*4)	○	○	○

*2

(*1) Teaching pendant application version 0.02 or later (not supported by version 0.01 or earlier)

(*2) PIO program start is enabled only in modes other than the edit mode.

(*3) In accordance with the “PIO start prohibition selection” setting.

(*4) In accordance with the “Safety-speed enable” setting.



9. Use Examples of Key Parameters

You can assign functions in addition to those available under the factory settings or change the factory-set functions, by changing the parameter values.
Before changing a parameter, be sure to read the corresponding section in the List of Parameters.

Description	Action	Parameter setting	Manipulation/operation
Want to prevent errors relating to the standard I/O board and field network board (DeviceNet, CC-Link, etc.). (Want to perform trial operation when wiring is not yet done, etc.)	I/O error monitor can be disabled to prevent errors from occurring.	Set "0" in the I/O parameter corresponding to the I/O board whose error monitor you want to disable. Standard I/O1: I/O parameter No. 10 = 0 Expanded I/O2: I/O parameter No. 11 = 0 Field network: I/O parameter No. 12 = 0	Set "0" in I/O parameter Nos. 10 and 11 to disable error monitor for the standard I/O board. Note: To operate a disabled I/O board, be sure to revert the parameter setting to "1."
Want to retain output status while emergency-stop signal is input or the safety gate is open.	Minimum and maximum port numbers indicating the output ports you wish to retain can be set.	I/O parameter No. 70 = Output port number MIN I/O parameter No. 71 = Output port number MAX Setting example) To retain output ports from port Nos. 316 through 331, set as follows: I/O parameter No. 70 = 316 I/O parameter No. 71 = 331	← The status of output port Nos. 316 through 331 will be retained while emergency-stop signal is input or the safety gate is open. Note: The parameters are normally set to the above output port numbers before shipment.
Want to start programs while emergency-stop signal is input or the safety gate is open. Programs to be started are I/O processing or calculation programs that do not command actuator operation (PIO processing programs).	A PIO processing program to start can be set. Set in the applicable parameters a desired PIO processing program as well as minimum and maximum port numbers indicating the output ports at which the program will be processed.	Other parameter No. 2 = PIO processing program number I/O parameter No. 70 = Output port number MIN I/O parameter No. 71 = Output port number MAX Setting example) To start program No. 5 that involves processing at output port Nos. 316 through 331, set as follows: Other parameter No. 2 = 5 I/O parameter No. 70 = 316 I/O parameter No. 71 = 331	← Program No. 5 will start while emergency-stop signal is input or the safety gate is open. Output port Nos. 316 through 331 can be used for processing. Note: The parameters are normally set to the above output port numbers before shipment.



Description	Action	Parameter setting	Manipulation/operation												
Want to automatically execute restart (software reset) after the emergency stop is reset, and start the auto-start program.	The emergency-stop recovery type can be set to "Abort operations/programs (Software reset when the emergency stop is reset)."	Other parameter No. 10 = 3 I/O parameter No. 33 = 1	After the emergency-stop button is released, the system will automatically execute restart (software reset) and start the auto-start program.												
Want to automatically execute error reset after the emergency stop is reset, and start the auto-start program.	The emergency-stop recovery type can be set to "Abort operations/programs (Error reset and auto program start when the emergency stop is reset)."	Other parameter No. 10 = 4 I/O parameter No. 33 = 1 I/O parameter No. 44 ≠ 1	After the emergency-stop button is released, the system will automatically execute error reset and start the auto-start program.												
Want to output signal when the actuator enters a specified area (zone).	<p>A desired actuator zone can be set for each axis. A desired output port to turn ON when the axis enters the zone can be set for each axis. A maximum of four zones can be set (zones 1 to 4).</p> <p>Max. value of zone 1: Axis-specific parameter No. 86</p> <p>Min. value of zone 1: Axis-specific parameter No. 87</p> <p>Zone 1 output port number: Axis-specific parameter No. 88</p> <p>Max. value of zone 2: Axis-specific parameter No. 89</p> <p>Min. value of zone 2: Axis-specific parameter No. 90</p> <p>Zone 2 output port number: Axis-specific parameter No. 91</p> <p>Max. value of zone 3: Axis-specific parameter No. 92</p> <p>Min. value of zone 3: Axis-specific parameter No. 93</p> <p>Zone 3 output port number: Axis-specific parameter No. 94</p> <p>Max. value of zone 4: Axis-specific parameter No. 95</p> <p>Min. value of zone 4: Axis-specific parameter No. 96</p> <p>Zone 4 output port number: Axis-specific parameter No. 97</p>	<p>Setting example) Set the area illustrated below as zone 1:</p> <p>Axis 1: Output port No. 316 will turn ON when the axis enters the area between 150 and 200 mm.</p> <p>Axis 2: Output port No. 317 will turn ON when the axis enters the area between 75 and 125 mm.</p> <div><table><thead><tr><th></th><th>Axis 1</th><th>Axis 2</th></tr></thead><tbody><tr><td>Axis-specific parameter No. 86</td><td>200000</td><td>125000 *</td></tr><tr><td>Axis-specific parameter No. 87</td><td>150000</td><td>75000 *</td></tr><tr><td>Axis-specific parameter No. 88</td><td>316</td><td>317</td></tr></tbody></table></div>		Axis 1	Axis 2	Axis-specific parameter No. 86	200000	125000 *	Axis-specific parameter No. 87	150000	75000 *	Axis-specific parameter No. 88	316	317	<div><p>: Output port No. 316 turns ON.</p><p>: Output port No. 317 turns ON.</p></div> <div>Note: Before shipment, the parameters are normally set so that the above output port numbers can be used.</div>
	Axis 1	Axis 2													
Axis-specific parameter No. 86	200000	125000 *													
Axis-specific parameter No. 87	150000	75000 *													
Axis-specific parameter No. 88	316	317													

Before changing a parameter, be sure to read the corresponding section in the List of Parameters.



◎ Error Level Control

Error level	System error assignment source	Error No. (HEX)	Display (7-segment display, etc.)	Error list (Application only)	Error LED output (MAIN only)	Program run (Application only) Other parameter No. 4 = 0	Error reset (Application only) Other parameter No. 4 = 1	Remarks
Secret level	MAIN application	800 to 88F						Special error level provided for maintenance purposes
	MAIN core	890 to 8AF		○				
	PC	8B0 to 8DF						
	TP	8E0 to 8FF						
Message level	MAIN application							Status display, input error, etc.
	MAIN core							
	PC							
	PC (Update tool)							
	TP							
	MAIN application	200 to 24F						
	MAIN core							
	PC	250 to 29F						
	PC (Update tool)	2A0 to 2CF						
	TP	2D0 to 2FF						
	MAIN application	900 to 93F						
	MAIN core							
	PC	940 to 97F						
	PC (Update tool)	980 to 9AF						
	TP	9B0 to 9BF						
	MAIN application	9C0 to 9FF						
Operation-cancellation level	MAIN application	A00 to A6F						Errors affecting operation. The system will attempt to reset minor errors below this level using an auto-reset function via external active command (SIO/PIO) (application only).
	MAIN core	A70 to A9F						
	PC	AA0 to ACF						
	TP	AD0 to AFF						
	MAIN application							
	MAIN core							
	PC							
	PC (Update tool)							
	TP							
	MAIN application	400 to 4CF						
	MAIN core							
	PC	4D0 to 4DF						
	PC (Update tool)	4E0 to 4EF						
	TP	4F0 to 4FF						



Error level	System error assignment source	Error No. (HEX)	Display (7-segment display, etc.)	Error list (Application only)	Error LED output (MAIN only)	Program run (Application only)		Error reset (Application only)	Remarks
						Other parameter No. 4 = 0	Other parameter No. 4 = 1		
Operation-cancellation level	MAIN application	B00 to B9F	○	○		The program in which the error generated will be cancelled. (Except for axis errors, a cancellation factor is present only for the moment the error occurs.) * However, in the case of an error requiring servo OFF or all-axis servo OFF, all programs other than the "I/O processing program at operation/program abort" will be cancelled.	All programs other than the "I/O processing program at operation/program abort" will be cancelled. (Except for axis errors, a cancellation factor is present only for the moment the error occurs.)	Enabled.	Errors affecting operation. The system will attempt to reset minor errors below this level using an auto-reset function via external active command (SIO/PIO) (application only).
	MAIN core	BA0 to BBF							
	PC	BC0 to BDF							
	TP	BE0 to BFF							
	MAIN application	C00 to CCF							
	MAIN core	CD0 to CDF							
	PC	CE0 to CFF							
	TP	CF0 to CFF							
	MAIN application								
	MAIN core								
Cold-start level	PC (Update tool)		○	○	(Core only)	The program in which the error generated will be cancelled. * However, in the case of an error requiring drive-source cutoff, servo OFF or all-axis servo OFF (initialization error, power error, etc.), all programs other than the "I/O processing program at operation/program abort" will be cancelled.	All programs other than the "I/O processing program at operation/program abort" will be cancelled.	Not enabled.	The controller power must be reconnected (MAIN only). (The CPU and OS will run properly.)
	MAIN application	600 to 6CF							
	MAIN core	---							
	PC	6D0 to 6DF							
	TP	6E0 to 6FF							
	MAIN application	D00 to D8F							
	MAIN core	D90 to DAF							
	PC	DB0 to DCF							
	TP	DD0 to DFF							
	MAIN application	E00 to E8F							
System-down level	MAIN core	E90 to EBF							
	PC	EC0 to EDF							
	TP	EE0 to EFF							
	MAIN application						All programs will be cancelled.	Not enabled.	The controller power must be reconnected (MAIN only). (The CPU and OS will not run.)
	MAIN core								
	PC								
	TP								
	MAIN application	FF0 to FBF							
	MAIN core	FC0 to FCF							
	PC	FD0 to FDF							
	TP	FE0 to FEF							

Note) Secret-level errors are not actual errors. Internal statuses are registered in an error list as secret-level errors, when deemed necessary, in order to facilitate error analysis.

PC: PC software TP: Teaching pendant



◎ Error List (MAIN application) (In the panel window, the three digits after “E” indicate an error number.)

Error No.	Error name	Description, action, etc.
207	Update file name error (IAI protocol)	The name of the update program file selected in the update mode is invalid. Select the correct file and repeat the update procedure from the beginning.
20E	Motorola S byte count error	The update program file is invalid. Check the file.
20F	Update target specification error (Received by the application)	The application's system received an update target specification command. To update the program, restart the controller and repeat the update procedure from the beginning.
630	Update system code error (Detected by the application)	The update system code is invalid.
631	Update unit code error (Detected by the application)	The update unit code is invalid.
632	Update device number error (Detected by the application)	The update device number is invalid.
685	I/O function selection physical port number error	The I/O port number setting specified for a given I/O function selection is invalid. Check the settings of I/O parameter Nos. 62 to 65, 76, 77, 283 to 330, etc.
801	SCIF overrun status (IAI protocol reception)	Communication failure. Check for noise, connected equipment and communication setting.
802	SCIF receive ER status (IAI protocol reception)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting. This error will also occur when establishing communication with the PC/TP wrongly connected to SIO-CH1 being opened to the user.
803	Receive timeout status (IAI protocol reception)	The transfer interval after the first received byte is too long. Possible causes include disconnected communication cable and error in the connected equipment.
804	SCIF overrun status (SEL reception)	Communication failure. Check for noise, connected equipment and communication setting.
805	SCIF receive ER status (SEL reception)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting.
806	SCIF receive ER status due to other factor (SEL reception)	Communication failure. Take the same action specified for error No. 804 or 805.
807	Drive-source cutoff relay ER status	The motor-drive power ON status remains ON even when the drive source is cut off. The drive-source cut-off relay contacts may have been melted.
808	Power OFF status during slave parameter write	The power was turned off while writing slave parameters. (This error can be detected only when a backup battery is used.)
809	Power OFF status during data write to flash ROM	The power was turned off while writing data to the flash ROM. (This error can be detected only when a backup battery is used.)
80A	Expanded-SIO overrun status (SEL reception)	Communication failure. Check for noise, connected equipment and communication setting.
80B	Expanded-SIO parity ER status (SEL reception)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting.
80C	Expanded-SIO framing ER status (SEL reception)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting.
80D	Expanded-SIO receive ER status due to other factor (SEL reception)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting.
80E	Expanded-SIO receive buffer overflow status (SEL reception)	Communication failure. Take the same action specified for error No. 80A, 80B or 80C.
80F	Ethernet control status 1	The receive buffer overflowed. Excessive data was received from outside.
810	Ethernet control status 2	Ethernet control information (for analysis)
811	Maintenance information 1	Ethernet control information (for analysis)
812	Maintenance information 2	Maintenance information (for analysis)



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
813	Maintenance information 3	Maintenance information (for analysis)
814	Maintenance information 4	Maintenance information (for analysis)
815	Maintenance information 5	Maintenance information (for analysis)
900	Blank step shortage error	There are not enough blank steps to save step data. Provide enough blank steps needed to save step data.
901	Step number error	The step number is invalid.
902	Symbol-definition table number error	The symbol-definition table number is invalid.
903	Point number error	The point number is invalid.
904	Variable number error	The variable number is invalid.
905	Flag number error	The flag number is invalid.
906	I/O port/flag number error	The I/O port/flag number is invalid.
910	Command error (IAI protocol HT reception)	The command ID is not supported or invalid. (For future expansion)
911	Message conversion error (IAI protocol HT reception)	The transmitted message does not match the message format or contains invalid data. (For future expansion)
912	PC/TP servo-movement command acceptance-enable input OFF error	Any axis movement command issued to the axis specified in I/O parameter No. 78 from the PC/TP will not be accepted while the input port specified in I/O parameter No. 77 is OFF. (Important: The acceptance-enable input port will become invalid once the operation is started.)
A01	System-memory backup battery voltage-low warning	The voltage of the system-memory backup battery is low. Replace the battery. (Above the minimum data-backup voltage)
A02	Abnormal system-memory backup battery voltage	The voltage of the system-memory backup battery is low. Replace the battery. (Below the minimum data-backup voltage)
A03	Absolute-data backup battery voltage-low warning (Driver analysis)	The voltage of the absolute-data backup battery is low. Check the battery connection or replace the battery.
A04	System mode error at core update	An update command was received when the system was not in the core update mode. Before updating the core, confirm that a chip resistance for setting core update mode is provided on the board. (For maintenance)
A05	Motorola S record format error	The update program file is invalid. Check the file.
A06	Motorola S checksum error	The update program file is invalid. Check the file.
A07	Motorola S load address error	The update program file is invalid. Check the file.
A08	Motorola S write address over error	The update program file is invalid. Check the file.
A09	Flash-ROM timing limit over error (Write)	Error writing the flash ROM
A0A	Flash-ROM timing limit over error (Erase)	Error erasing the flash ROM
A0B	Flash-ROM verify error	Error erasing/writing the flash ROM



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
A0C	Flash-ROM ACK timeout	Error erasing/writing the flash ROM
A0D	Head sector number specification error	Error erasing the flash ROM
A0E	Sector count specification error	Error erasing the flash ROM
A0F	Write-destination offset address error (Odd-numbered address)	Error writing the flash ROM
A10	Write-source data buffer address error (Odd-numbered address)	Error writing the flash ROM
A11	Invalid core-code sector block ID error	The core program already written to the flash ROM is invalid.
A12	Core-code sector block ID erase count over	The number of times the flash ROM can be erased was exceeded.
A13	Flash-ROM write request error when erase is incomplete	When updating, a flash-ROM write command was received before a flash-ROM erase command. Check the update program file and perform update again.
A14	Busy-status reset timeout error at EEPROM write	A busy-status reset timeout occurred after executing EEPROM write.
A15	EEPROM write request error due to no-EEPROM in target	An EEPROM write request was received for a driver or other unit with CPU not equipped with EEPROM.
A16	EEPROM read request error due to no-EEPROM in target	An EEPROM read request was received for a driver or other unit with CPU not equipped with EEPROM.
A17	Message checksum error (IAI protocol reception)	The checksum in the received message is invalid.
A18	Message header error (IAI protocol reception)	The header in the received message is invalid. Invalid header position (message is 9 bytes or less) is suspected, among other reasons.
A19	Message station number error (IAI protocol reception)	The station number in the received message is invalid.
A1A	Message ID error (IAI protocol reception)	The ID in the received message is invalid.
A1C	Message conversion error	The transmitted message does not match the message format or contains invalid data. Check the transmitted message.
A1D	Start mode error	A start not permitted in the current mode (MANU/AUTO) was attempted.
A1E	Start condition non-satisfaction error	Start was attempted when the start condition was not satisfied, such as when an all-operation-cancellation factor (see the 7-segment display: Drive-source cutoff, mode switching, error, auto-start switch OFF edge, deadman switch, safety gate, emergency stop, etc.) was present or the flash ROM was being written.
A1F	Axis duplication error (SIO · PIO)	The applicable axis is currently in use.
A20	Servo-control-right acquisition error (SIO · PIO)	The servo control right is not available.
A21	Servo-control-right duplicate-acquisition error (SIO · PIO)	The servo control right has already been acquired.
A22	Servo-control-right non-acquisition error (SIO · PIO)	An attempt to retain the servo control right has failed.
A23	Absolute-data backup battery voltage-low warning (Main analysis)	The voltage of the absolute-data backup battery is low. Check the battery connection or replace the battery.
A25	Step count specification error	The specified number of steps is invalid.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
A26	Program count specification error	The specified number of programs is invalid.
A27	Program non-registration error	The applicable program is not registered.
A28	Reorganization disable error during program run	A program-area reorganization operation was attempted while a program was running. End all active programs first.
A29	Active-program edit disable error	An edit operation was attempted to a program currently not running. End the applicable program first.
A2A	Program inactive error	The specified program is not running.
A2B	Program-run command refusal error in AUTO mode	Programs cannot be run from the TP/PC software connector in the AUTO mode.
A2C	Program number error	The program number is invalid.
A2D	Inactive program resumption error	A resumption request was received for a program currently not running.
A2E	Inactive program pause error	A pause request was received for a program currently not running.
A2F	Breakpoint error	The step number specified as a breakpoint is invalid.
A30	Breakpoint setting-count specification error	The number of breakpoints to be set exceeds the limit value.
A31	Parameter change value error	The value of parameter changed is invalid.
A32	Parameter type error	The parameter type is invalid.
A33	Parameter number error	The parameter number is invalid.
A34	Card-parameter buffer read error	Error reading the card-parameter buffer
A35	Card-parameter buffer write error	Error writing the card-parameter buffer
A36	Parameter change refusal error during operation	Parameters cannot be changed during operation (program is running, servo is in use, etc.).
A37	Card manufacturing/function information change refusal error	The card manufacturing/function information cannot be changed.
A38	Parameter change refusal error during servo ON	An attempt was made to change a parameter whose change is not permitted while the servo is ON.
A39	Non-acquired card parameter change error	An attempt was made to change a parameter for a card not recognized at reset.
A3A	Device number error	The device number is invalid.
A3C	Memory initialization type specification error	The specified memory initialization type is invalid.
A3D	Unit type error	The unit type is invalid.
A3E	SEL write data type specification error	The specified SEL write data type is invalid.
A3F	Flash-ROM write refusal error during program run	The flash ROM cannot be written while a program is running.
A40	Data change refusal error during flash ROM write	Data cannot be changed while the flash ROM is being written.
A41	Duplicate flash-ROM write commands refusal error	Another flash-ROM write command was received while the flash ROM was being written.
A42	Direct monitor prohibition error during flash ROM write	Direct monitor is prohibited while the flash ROM is being written.
A43	P0/P3-area direct monitor prohibition error	Direct monitor in the P0/P3 areas is prohibited.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
A44	Point-data count specification error	The specified number of point data is invalid.
A45	Symbol-record count specification error	The specified number of symbol records is invalid.
A46	Variable-data count specification error	The specified number of variable data is invalid.
A48	Error-detail query type 1 error	Error-detail query type 1 is invalid.
A49	Error-detail query type 2 error	Error-detail query type 2 is invalid.
A4A	Monitoring data type error	The data type for monitoring data query is invalid.
A4B	Monitoring-record count specification error	The specified number of records for monitoring data query is invalid.
A4C	Monitoring-operation special command register busy error	The driver special command ACK generated a timeout during monitoring operation.
A4E	Parameter register busy error at issuance of slave command	The driver special command ACK generated a timeout at issuance of a slave command.
A4F	Software reset refusal error during operation	Software reset (SIO) is prohibited during operation (program is running, servo is in use, etc.).
A50	Drive-source recovery request refusal error	The drive-source cutoff factor (error, deadman switch, safety gate, emergency stop, etc.) has not been removed.
A51	Operation-pause reset request refusal error	The all-operation-pause factor (drive-source cutoff, operation-pause signal, deadman switch, safety gate, emergency stop, etc.) has not been removed.
A53	Refusal error due to servo ON	A processing not permitted during servo ON was attempted.
A54	Refusal error due to unsupported function	The function is not supported.
A55	Refusal error due to exclusive manufacturer function	A processing not opened to users other than the manufacturer was attempted.
A56	Refusal error due to invalid data	The data is invalid.
A57	Program start duplication error	An attempt was made to start a program currently running.
A58	BCD error warning	The BCD value being read may be invalid, or the value being written (variable 99) may be a negative value, among other reasons.
A59	IN/OUT command port flag error warning	The number of I/O ports (flags) may have exceeded 32, among other reasons. Check the I/O port (flag) specifications.
A5B	Character-string → value conversion error warning	The specified number of converting characters is invalid or characters that cannot be converted to value are included.
A5C	Copying-character count error warning with SCPY command	The specified number of copying characters is invalid.
A5D	SCIF open error in non-AUTO mode	The channel was opened in a non-AUTO mode. In the MANU mode, the PC/TP connection must be forcibly disconnected before opening the serial channel opened to the user. Exercise caution.
A5E	I/O-port/flag count specification error	The specified number of I/O ports/flags is invalid.
A5F	Fieldbus error (LERROR-ON)	A LERROR-ON was detected.
A60	Fieldbus error (LERROR-BLINK)	A LERROR-BLINK was detected.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
A61	Fieldbus error (HERROR-ON)	A HERROR-ON was detected.
A62	Fieldbus error (HERROR-BLINK)	A HERROR-BLINK was detected.
A63	Fieldbus not ready	Fieldbus ready cannot be confirmed.
A64	SCIF overrun error (SIO bridge)	Communication failure. Check for noise, connected equipment and communication setting.
A65	SCIF receive error (SIO bridge)	Communication failure. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting.
A66	SCI overrun error (SIO bridge)	Communication failure. Check for noise, circuit failure and slave card.
A67	SCI framing error (SIO bridge)	Communication failure. Check for noise, shorting, circuit failure and slave card.
A68	SCI parity error (SIO bridge)	Communication failure. Check for noise, shorting, circuit failure and slave card.
A69	Data change refusal error during operation	An attempt was made to change data whose change is prohibited during operation (program is running, servo is in use, etc.).
A6A	Software reset refusal error during write	Software reset is prohibited while data is being written to the flash ROM or slave parameters are being written.
A6B	Fieldbus error (FBRs link error)	A FBRs link error was detected.
A6C	PC/TP start command refusal error in AUTO mode	Starting from the PC software/TP connector is prohibited in the AUTO mode.
A6D	P0/P3/FROM-area direct write prohibition error	Direct write to the P0/P3/FROM areas is prohibited.
A6E	Refusal error during write	A processing not permitted while data is being written to the flash ROM or slave parameters are being written was attempted.
A6F	Driver monitor type mismatch error	The monitor type supported by the standard DIO board or based on the capacity of FROM on the main CPU board does not match the monitor type on the PC software side (selected on the monitor screen).



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
B00	SCHA setting error	The setting of SCHA command is invalid.
B01	TPCD setting error	The setting of TPCD command is invalid.
B02	SLEN setting error	The setting of SLEN command is invalid.
B03	Home-return method error	The setting of "Axis-specific parameter No. 10, Home-return method" is invalid. (Not incremental encoder AND current position 0 home is specified, etc.)
B04	1-shot-pulse output excessive simultaneous use error	The number of BTPN and BTPF timers operating in one program simultaneously exceeds the upper limit (16).
B05	Estimate-stroke over error at home return	The operation at home return exceeded the estimate stroke. The home sensor or creep sensor may be faulty, among other reasons.
B06	Expanded-SIO in-use error	An attempt was made to open a channel already opened by other task.
B07	Expanded-SIO unopen error	An attempt was made to use a channel not opened by own task.
B08	Expanded-SIO duplicate WRIT execution error	WRIT commands were executed simultaneously by multiple tasks for the same channel.
B09	Expanded-SIO RS485 WRIT/READ simultaneous execution error	WRIT and READ commands were executed simultaneously in the RS485 mode.
B0A	Expanded-SIO unassigned-channel use error	An attempt was made to use a channel not assigned properly. Check I/O parameter Nos. 100 to 111 and the statuses of I/O slots.
B10	Phase-Z search timeout error	Phase Z cannot be detected. Check for operation restriction, wiring, encoder, motor, etc.
B11	Home-sensor pull-out timeout error	Pull-out from the home sensor cannot be confirmed. Check for operation restriction, wiring, motor, home sensor, etc.
B12	Storage variable number error for SEL command return code	The variable number specified for storing SEL command's return code is invalid. Check "Other parameter No. 24, Local variable number for storing READ command return code," etc.
B13	Backup SRAM data checksum error	The backup SRAM data has been destroyed. Check the battery.
B14	Flash-ROM, 8-Mbit version unsupported function error	An attempt was made to use a function not supported in the flash-ROM, 8-Mbit board environment. (HT connection specification, etc.)
B15	Input-port debug filter type error	The setting of input-port debug filter type is invalid.
B16	SEL operand specification error	The operand specification of SEL command is invalid.
B17	Parameter register busy error at issuance of slave command	The driver special command ACK generated a timeout at issuance of a slave command.
B18	Device number error	The device number is invalid.
B19	Unit type error	The unit type is invalid
B1A	Absolute reset specification error	The specification for absolute reset using an optional function, etc., is invalid. (Two or more axes are specified simultaneously, non-absolute-encoder axis is specified, etc.)
B1B	Ethernet non-closed socket open error	An attempt was made to open a socket without closing it first.
B1C	Ethernet in-use-by-other-task error	An attempt was made to open a channel already opened by other task.
B1D	Ethernet non-open error	An attempt was made to use a channel not opened by own task.
B1E	Ethernet multiple WRIT execution error	WRIT commands were executed simultaneously by multiple tasks for the same channel.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
B1F	Ethernet job busy error	An attempt was made to start a new process when the Ethernet mailbox control job was busy.
B20	Ethernet non-initialization device use error	An attempt was made to use the Ethernet system when Ethernet device initialization was not yet complete. Check I/O parameter Nos. 123 to 159, 14, 15, etc., depending on the purpose of use.
B21	Ethernet IP address error	An error will generate under the following conditions during normal use. When IP address (H) (first octet) through IP address (L) (fourth octet) are given as IP_H, IP_MH, IP_ML and IP_L, the error conditions are described as follows: IP_H ≤ 0 or IP_H = 127 or IP_H > 255 or IP_MH < 0 or IP_MH > 255 or IP_ML < 0 or IP_ML > 255 or IP_L ≤ 0 or IP_L ≥ 255 Check I/O parameter Nos. 132 to 135, 149 to 152, and 154 to 157, the IP address of connection destination specified by an IPCN command in an integer variable, or the like.
B22	Ethernet port number error	An error will generate if own port number < 1025, or own port number > 65535, or own port number duplication, or connection-destination port number for client ≤ 0, or connection-destination port number for client > 65535, or connection-destination port number for server < 0, or connection-destination port number for server > 65535 is satisfied. Check I/O parameter Nos. 144 to 148, 159, 153, and 158, the port number of connection destination specified by an IPCN command in an integer variable, or the like.
C02	Executable program count over error	Execution requests were received for programs exceeding the number that can be executed simultaneously.
C03	Non-registered program specification error	The specified program is not registered.
C04	Program entry point non-detection error	A request was made to execute a program number for which no program steps are registered.
C05	Program first-step BGSR error	The program specified for execution starts with BGSR.
C06	Executable step non-detection error	The program specified for execution does not contain executable program steps.
C07	Subroutine non-definition error	The subroutine specified for call is not defined.
C08	Subroutine duplicate-definition error	The same subroutine number is defined at multiple locations.
C0A	Tag duplicate-definition error	The same tag number is defined at multiple locations.
C0B	Tag non-definition error	The tag specified as the jump destination of a GOTO statement is not defined.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C0C	DW/IF/IS/SL pair-end mismatch error	The branching command syntax is invalid. Correspondence with the last appearing branching command is invalid when EDIF, EDDO or EDSL is used. Check the correspondence between IF/IS command and EDIF, DO command and EDDO or SLCT command and EDSL.
C0D	DW/IF/IS/SL no pair-end error	EDIF, EDDO or EDSL is not found. Check the correspondence between IF/IS command and EDIF, DO command and EDDO or SLCT command and EDSL.
C0E	BGSR no pair-end error	There is no EDSR for BGSR, or no BGSR for EDSR. Check the correspondence between BGSR and EDSR.
C0F	DO/IF/IS over-nesting error	The number of nests in a DO or IF/IS command exceeds the limit value. Check for excessive nesting or branching out of or into the syntax using a GOTO command.
C10	SLCT over-nesting error	The number of nests in a SLCT command exceeds the limit value. Check for excessive nesting or branching out of or into the syntax using a GOTO command.
C11	Subroutine over-nesting error	The number of nests in a subroutine exceeds the limit value. Check for excessive nesting or branching out of or into the syntax using a GOTO command.
C12	DO/IF/IS under-nesting error	The EDIF or EDDO position is invalid. Check the correspondence between IF/IS command and EDIF or DO command and EDDO, or branching out of or into the syntax using a GOTO command.
C13	SLCT under-nesting error	The EDSL position is invalid. Check the correspondence between SLCT and EDSR, or branching out of or into the syntax using a GOTO command.
C14	Subroutine under-nesting error	The EDSR position is invalid. Check the correspondence between BGSR and EDSR, or branching out of or into the syntax using a GOTO command.
C15	SLCT next-step command code error	The program step next to SLCT must be WHEQ, WHNE, WHGT, WHGE, WHLT, WHLE, WSEQ, WSNE, OTHE or EDSL.
C16	Create stack failed	Initialization of the input-condition-status storage stuck has failed.
C17	Expansion-condition code error	Input program step error. The expansion condition code is invalid.
C18	Expansion-condition LD simultaneous processing over error	The number of LDs processed simultaneously exceeds the limit value.
C19	Expansion-condition LD shortage error 1	There is not enough LD when expansion condition A or O is used.
C1A	Expansion-condition LD shortage error 2	There is not enough LD when expansion condition AB or OB is used.
C1C	Unused-LD detection error	An attempt was made to execute a command based on multiple LD condition that has been saved, without using it in expansion condition AB or OB.
C1F	Input-condition CND shortage error	The necessary input condition is not found when an expansion condition is used.
C21	Input-condition use error with input-condition prohibited command	Input-condition prohibited commands prohibit the use of input conditions.
C22	Invalid command position error with input-condition prohibited command	A command for which input condition is prohibited cannot be included in an input condition nest.
C23	Invalid operand error	Program step error. The necessary operand data is invalid.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C24	Operand type error	Program step error. The operand data type is invalid.
C25	Actuator control declaration error	The setting of actuator control declaration command is invalid.
C26	Timer setting-range over error	The timer setting is invalid.
C27	Timeout setting-range over error during wait	The timeout setting is invalid.
C28	Tick count setting-range error	The Tick count setting is invalid.
C29	DIV command divisor 0 error	"0" was specified as the divisor in the DIV command.
C2A	SQR command range error	The operand value in the SQR command is invalid. Input a value larger than "0" as data in a SQR command.
C2B	BCD display digit range error	The specified number of BCD display digits is invalid. Specify a value between 1 and 8.
C2C	Program number error	The program number is invalid.
C2D	Step number error	The step number is invalid.
C2E	Blank step shortage error	There are not enough blank steps to save step data. Provide enough blank steps needed to save step data.
C2F	Axis number error	The axis number is invalid.
C30	Axis pattern error	The axis pattern is invalid.
C32	Operating-axis addition error during command execution	An operating axis for point data was added during continuous point movement or push-motion movement calculation.
C33	Base axis number error	The base axis number is invalid.
C34	Zone number error	The zone number is invalid.
C35	Point number error	The point number is invalid.
C36	I/O port/flag number error	The I/O port/flag number is invalid.
C37	Flag number error	The flag number is invalid.
C38	Tag number error	The tag number is invalid.
C39	Subroutine number error	The subroutine number is invalid.
C3A	User-open communication channel number error	The channel number of the communication channel opened to the user is invalid.
C3B	Parameter number error	The parameter number is invalid.
C3C	Variable number error	The variable number is invalid.
C3D	String number error	The string number is invalid.
C3E	String-variable data count specification error	The specified number of string variables exceeds the area, etc.
C40	String-variable delimiter non-detection error	Delimiter cannot be detected in the string variable.
C41	String-variable copy size over error	The copy size of string variable is too large.
C42	Character count non-detection error during string processing	The character-string length is not defined in string processing. Execute a string processing command after defining the length with a SLEN command.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C43	Character-string length error during string processing	The character-string length used in string processing is invalid. Check the value of character-string length defined by a SLEN command.
C45	Symbol definition table number error	The symbol definition table number is invalid.
C46	Blank area shortage error with source-symbol storage table	There is not enough area to store the source symbols. Check the number of times source symbol can be used.
C47	Symbol search error	Definitions are not found for the symbols used in the program steps.
C48	SIO-message continuous conversion error	The transmitted SIO message does not match the message format or contains invalid data. Check the transmitted message.
C49	SEL-SIO in-use error	The SIO is being used by other interpreter task.
C4A	SCIF unopen error	Serial channel 1 opened to the user is not opened in the target task. Open the channel using an OPEN command first.
C4B	Delimiter non-definition error	An end character is not defined. Set an end character using a SCHA command first.
C4E	SIO1 invalid usage OPEN error	The usage of serial channel opened to the user does not match the parameter. Check "I/O parameter No. 90, Usage of SIO channel opened to user."
C4F	SEL program/source symbol checksum error	The flash ROM data has been destroyed.
C50	Symbol definition table checksum error	The flash ROM data has been destroyed.
C51	Point data checksum error	The flash ROM data has been destroyed.
C52	Backup SRAM data destruction error	The backup SRAM data has been destroyed. Check the battery.
C53	Invalid flash-ROM SEL global data/error list error	The SEL global data/error lists in the flash ROM are invalid.
C54	Flash-ROM SEL global data/error list duplication error	The SEL global data/error lists in the flash ROM are duplicated.
C55	Flash-ROM erase count over error for SEL global data/error lists	The number of time the flash ROM containing SEL global data/error lists can be erased was exceeded.
C56	Timing limit over error (Flash ROM erase)	Error erasing the flash ROM
C57	Flash-ROM verify error (Flash ROM erase)	Error erasing the flash ROM
C58	Flash-ROM ACK timeout error (Flash ROM erase)	Error erasing the flash ROM
C59	Head sector number specification error (Flash ROM erase)	Error erasing the flash ROM
C5A	Sector count specification error (Flash ROM erase)	Error erasing the flash ROM
C5B	Timing limit over error (Flash ROM write)	Error writing the flash ROM
C5C	Flash-ROM verify error (Flash ROM write)	Error writing the flash ROM
C5D	Flash-ROM ACK timeout error (Flash ROM write)	Error writing the flash ROM
C5E	Write-destination offset address error (Flash ROM write)	Error writing the flash ROM



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C5F	Write-source data buffer address error (Flash ROM write)	Error writing the flash ROM
C60	No SEL global data/error list write area error	There is no area to write the erased SEL global data/error lists.
C61	SEL-data flash-ROM erase count over error	The number of times the flash ROM containing SEL data can be erased was exceeded.
C62	Operation command error at servo OFF	An attempt was made to execute an operation command when the servo was OFF.
C63	Servo operation condition error	The servo is not in an operation-enabled condition.
C64	Invalid servo acceleration/deceleration error	The internal servo acceleration/deceleration is invalid.
C65	Servo ON/OFF logic error	The servo ON/OFF logic between the main and driver is invalid.
C66	Axis duplication error	An attempt was made to acquire the control right to an axis already in use.
C67	Servo-control-right acquisition error	There is no space in the servo user management area.
C68	Servo-control-right duplicate-acquisition error	The servo control right has already been acquired.
C69	Servo-control-right non-acquisition error	A user who doesn't have the servo control right attempted to retain the control right.
C6A	Push-motion flag logic error	The internal logic for push-motion processing is invalid.
C6B	Deviation overflow error	The command cannot be followed. Check for operation restriction, wiring, encoder, motor, etc.
C6C	Movement error during absolute data acquisition	Axis movement was detected while acquiring absolute encoder data after the power was turned on. The power may have been turned or a software reset executed while the actuator was moving due to external force such as reactive force of a self-supported cable or while the installation location was vibrating. Or, a software reset may have been executed. Absolute coordinates cannot be confirmed in this condition.
C6D	Maximum installable axes over error	The specified number of axes exceeded the number of installable axes as a result of axis shift with a base command.
C6E	Servo-OFF axis use error	An attempt was made to use an axis whose servo is OFF.
C6F	Home-return incomplete error	Home return has not completed yet.
C70	Absolute coordinate non-confirmation error	Absolute coordinates have not been confirmed. The power must be reconnected.
C71	Synchro slave-axis command error	A command was issued to the synchro slave axis.
C72	Overrun error	The overrun sensor was actuated.
C73	Target-locus soft limit over error	The target position or movement locus exceeds a soft limit.
C74	Actual-position soft limit over error	The actual position exceeds a soft limit by the "soft limit/actual position margin" or more.
C75	Motion-data-packet generation logic error	The motion-data-packet generation logic is invalid.
C76	Movement-point count over error	Too many packets are generated simultaneously.
C77	Handling-packet overflow error	The servo handling packets overflowed.
C78	Motion-data-packet overflow error	The servo motion data packets overflowed.
C79	Pole sense operation error	Operation is disabled in the pole sense mode.
C7A	Servo unsupported function error	An attempt was made to use an unsupported function.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C7B	Odd-pulse slide error	Internal servo calculation error
C7C	Odd-pulse processing logic error	Internal servo calculation error
C7D	Packet pulse shortage error	Internal servo calculation error
C7E	Quadratic equation solution error	An error was detected while calculating a quadratic equation solution.
C7F	No valid specified axis error	No valid axes are specified.
C80	Servo-packet calculation logic error	Internal servo calculation error
C81	Operation-amount logic during servo ON	Servo processing logic error
C82	Servo direct command type error	Servo processing logic error
C83	Servo calculation method type error	The servo calculation method type is invalid.
C84	In-use axis servo OFF error	The servo of an axis currently in use (being processed) was turned off.
C85	Non-installed driver error	Driver is not installed for the applicable axis.
C86	Driver servo ready OFF error	The ready signal for the driver of the applicable axis is OFF.
C87	SEL unsupported function error	An attempt was made to use a function not supported by SEL.
C88	Speed specification error	The specified speed is invalid.
C89	Acceleration/deceleration specification error	The specified acceleration/deceleration is invalid.
C8B	Circle/arc calculation logic error	The arc calculation logic is invalid.
C8D	Circle/arc calculation error	Position data that cannot be used in arc movement was specified. Check the position data.
C8E	Point deletion error during command execution	The final point data was deleted while continuous point movement was being calculated.
C8F	Axis operation type error	The axis operation type is invalid. Check "Axis-specific parameter No. 1, Axis operation type" and perform operation appropriate for the operation type specified.
C90	Spline calculation logic error	The spline processing logic is invalid.
C91	Push-motion axis multiple specification error	Two or more push-motion axes were specified.
C92	Push-motion approach distance/speed specification error	The specified push-motion approach distance/speed is invalid.
C93	System output operation error	The user attempted a system output operation (through the port specified by I/O parameter for output function selection or the zone output port specified by axis-specific parameter).
C94	PIO program number error	The PIO-specified program number is invalid.
C95	AUTO program number error	The setting of "Other parameter No. 1, Auto-start program number" is invalid.
C96	Start error from operation-abort program	Programs cannot be started from the "I/O processing program at operation/program abort." (Applicable only to main application version 0.33 or earlier.)
C97	Program number error for I/O processing program at operation/program abort	The setting of "Other parameter No. 2, I/O processing program number at operation/program abort" is invalid.
C98	Program number error for I/O processing program at operation pause	The setting of "Other parameter No. 3, I/O processing program number at all operation pause" is invalid.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
C99	Home sensor non-detection error	The home sensor cannot be detected. Check the wiring and sensor.
C9A	Creep sensor non-detection error	The creep sensor cannot be detected. Check the wiring and sensor.
C9B	Phase Z non-detection error	Phase Z cannot be detected. Check the wiring and encoder.
C9C	Defective phase-Z position error	The phase-Z position is defective. Normal wear and tear of the mechanical ends and home sensor may also be a reason. Readjustment is necessary.
C9D	Card parameter write error	Error writing card parameters
C9E	Servo calculation overflow error	Internal servo calculation error
CA1	Abnormal absolute-data backup battery voltage (Driver analysis)	Check the connection of the absolute-data backup battery/replace the battery and/or check the encoder cable connection, and then perform an absolute reset.
CA2	Abnormal absolute-data backup battery voltage (Main analysis)	Check the connection of the absolute-data backup battery/replace the battery and/or check the encoder cable connection, and then perform an absolute reset.
CA3	Slave setting data out-of-range error	The data set to the slave is outside the allowable range.
CA4	Slave error response	An error response was returned from the slave.
CA5	Stop deviation overflow error	Movement may have occurred during stopping due to external force or operation may have been restricted during deceleration. This error may also generate when jog operation is restricted (due to contact with an obstacle, contact with a mechanical end before home return, etc.) or when wiring error, faulty encoder or faulty motor is detected during deceleration.
CA6	Palletizing number error	The specified palletizing number is invalid.
CA7	Setting error of even-numbered row count for palletizing zigzag	The set even-numbered row count for palletizing zigzag is invalid.
CA8	Setting error of palletizing pitches	The set palletizing pitches are abnormal.
CA9	Setting error of placement points in palletizing-axis directions	The set X/Y-axis direction counts for palletizing are invalid.
CAA	Palletizing PASE/PAPS non-declaration error	Neither PASE nor PAPS palletizing-setting command is set. Set either command.
CAB	Palletizing position number error	The specified palletizing position number is invalid.
CAC	Palletizing position number setting over	The specified palletizing position number exceeds the position number range calculated for the current palletizing setting.
CAD	Palletizing PX/PY/PZ-axis duplication error	Any two of the specified PX, PY and PZ-axes for palletizing are the same axis.
CAE	Insufficient valid axes for palletizing 3-point teaching data	There are not enough valid axes in the point data for palletizing 3-point teaching. Axes to comprise the palletizing PX/PY planes cannot be specified.
CAF	Excessive valid axes for palletizing 3-point teaching data	There are too many valid axes in the point data for palletizing 3-point teaching. Axes to comprise the palletizing PX/PY planes cannot be specified.
CB0	Mismatched valid axes for palletizing 3-point teaching data	The valid axis pattern in the point data for palletizing 3-point teaching does not match.
CB1	Offset setting error at palletizing 3-point teaching	Zigzag offset (not zero) cannot be set in palletizing 3-point teaching, if the reference point is the same as the end point of the PX-axis.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
CB2	BGPA/EDPA pair-end mismatch error	The BGPA/EDPA syntax is invalid. EDPA was declared before BGPA, or another BGPA was declared after BGPA without first declaring EDPA.
CB4	Arch-motion Z-axis non-declaration error	Z-axis has not been declared by PCHZ or ACHZ.
CB5	BGPA non-declaration error during palletizing setting	Palletizing setting cannot be performed without first declaring BGPA. Declare BGPA.
CB6	Palletizing point error	The palletizing points are invalid (non-Z-axis components are absent, etc.).
CB7	Arch-trigger non-declaration error	Declare arch triggers using PTRG or ATRG.
CB8	No 3-point teaching setting error at palletizing angle acquisition	The palletizing angle cannot be acquired until setting by palletizing 3-point teaching is complete.
CB9	PX/PY-axis indeterminable error at palletizing angle acquisition	Angle cannot be calculated because there are too many valid axes in the 3-point teaching data and thus PX/PY-axes cannot be specified.
CBA	Reference-axis/PY/PY-axis mismatch error at palletizing angle acquisition	Angle cannot be calculated because the reference axis for angle calculation is neither of the axes comprising the PX/PY-axes as set by 3-point teaching.
CBB	Reference-point/PX-axis end-point duplication error at palletizing angle acquisition	Angle cannot be calculated because the reference point of 3-point teaching is the same as the PX-axis end-point data other than the PZ-axis component and thus arc tangent cannot be calculated.
CBC	Palletizing motion calculation error	Trapezoid control calculation error for palletizing motion
CBD	MOD command divisor 0 error	"0" was specified as the divisor in the MOD command.
CBE	Target-locus boundary over error	The target position or movement locus exceeded the positioning boundary in the infinite-stroke mode.
CBF	Positioning distance overflow error	The positioning distance is too large.
CC0	Axis mode error	The axis mode is invalid.
CC1	Speed change condition error	An attempt was made to change the speed of an axis whose speed cannot be changed (axis operating in S-motion, etc.).
CC2	Driver parameter list number error	The driver parameter list number is invalid.
CC3	Angle error	The angle is invalid.
CC4	SEL data error	The SEL data is invalid.
CC5	Positioning boundary pull-out error	An attempt was made to execute a command not permitted outside the positioning boundary.
CC6	Driver error primary detection	A driver error was found by primary detection.
CC7	Palletizing movement PZ-axis pattern non-detection error	PZ-axis component is not found in the axis pattern during palletizing movement.
CC8	Arch top Z-axis pattern non-detection error	Z-axis component relating to the highest point of arch motion is not found in the axis pattern during arch motion operation.
CC9	Arch trigger Z-axis pattern non-detection error	Z-axis component relating to arch motion is not found in the axis pattern of the arch-trigger declaration point data.
CCA	Arch top/end-point reversing error	The coordinates of highest point and end point are reversed during arch motion operation.
CCB	Arch start-point/trigger reversing error	The coordinates of start point and start-point arch trigger are reversed during arch motion operation.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
CCC	Arch end-point/trigger reversing error	The coordinates of end point and end-point arch trigger are reversed during arch motion operation.
CCD	Drive-source cutoff axis use error	An attempt was made to use an axis whose drive source is cut off.
CCE	Error axis use error	An attempt was made to use an axis currently generating an error.
CCF	Palletizing reference-point/valid-axis mismatch error	The PX/PY/PZ-axes set by PASE/PCHZ are not valid in the axis pattern of the reference-point data set by PAST.
D01	Encoder EEPROM-write timeout error	The encoder is faulty or failure occurred in the encoder communication.
D02	Encoder EEPROM-read timeout error	The encoder is faulty or failure occurred in the encoder communication.
D03	Encoder count error	Faulty encoder or defective encoder assembly condition is suspected.
D04	Encoder one-revolution reset error	The encoder is faulty or has turned.
D05	Encoder-EEPROM write acceptance error	The encoder is faulty or failure occurred in the encoder communication.
D06	Encoder received-data error	The encoder is faulty or failure occurred in the encoder communication.
D07	Driver logic error	The driver CPU board is in a condition where it cannot operate normally.
D08	Encoder CRC error	The encoder is faulty or failure occurred in the encoder communication.
D09	Driver overspeed error	The motor speed exceeded the upper limit.
D0A	Driver overload error	The power input to the motor exceeded the upper limit.
D0B	Driver EEPROM data error	Failure during write or EEPROM failure
D0C	Encoder EEPROM data error	Failure during write or EEPROM failure
D0E	Axis sensor error	An error occurred in the axis sensor.
D0F	Power stage temperature error	The power stage board exceeded the upper temperature limit.
D10	IPM error	A failure occurred in the motor drive circuit.
D11	Driver abnormal interruption error	The driver CPU board is in a condition where it cannot operate normally.
D12	Encoder disconnection error	The encoder cable is disconnected.
D13	FPGA watchdog timer error	Failure in the interface with the main CPU
D14	Current loop underrun error	Failure in the interface with the main CPU
D15	Driver-CPU down status error	An error occurred in the driver CPU board.
D17	Main-CPU alarm status error	Failure in the interface with the main CPU
D18	Speed loop underrun error	Failure in the interface with the main CPU
D19	Encoder receive timeout error	The encoder is faulty or failure occurred in the encoder communication.
D1A	Driver command error	An error occurred in the CPU bus command.
D1B	Serial bus receive error	Failure in the interface with the main CPU
D1C	Encoder overspeed error	The motor speed exceeded the upper limit.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
D1D	Encoder full-absolute status error	The motor speed exceeded the upper limit.
D1E	Encoder counter overflow error	The encoder rotation counter exceeded the upper limit.
D1F	Encoder rotation error	Faulty encoder or defective encoder assembly condition is suspected.
D20	Driver error	(Refer to error No. CA1.)
D22	Encoder rotation reset error	The encoder is faulty or has turned.
D23	Encoder alarm reset error	Faulty encoder
D24	Encoder ID error	The encoder is faulty or failure occurred in the encoder communication.
D25	Encoder configuration mismatch error	The encoder configuration information is outside the function information range.
D26	Motor configuration mismatch error	The motor configuration information is outside the function information range.
D29	Excitation detection error	An error was detected during excitation communication.
D2A	Driver control power overvoltage error	An overvoltage error was detected in the driver control power.
D2B	Driver control power voltage drop error	A voltage drop was detected in the driver control power.
D2C	Drive-power overvoltage error	An overvoltage error was detected in the motor drive power.
D2D	Drive-power voltage drop error	A voltage drop was detected in the motor drive power.
D2E	Synchronous communication error	A communication failure occurred between the driver board and FPGA (main).
D50	Fieldbus error (FBMIRQ timeout)	A FBMIRQ timeout was detected.
D51	Fieldbus error (FBMIRQ reset)	A FBMIRQ reset error was detected.
D52	Fieldbus error (FBMBSY)	A FBMBSY was detected.
D53	Fieldbus error (BSYERR)	A BSYERR was detected.
D54	Window lock error (LERR)	A LERR was detected.
D55	Fieldbus error (Min busy)	A Min busy error was detected.
D56	Fieldbus error (MinACK timeout)	A Min ACK timeout was detected.
D57	Fieldbus error (MoutSTB timeout)	A Mout STB timeout was detected.
D58	Fieldbus error (INIT timeout)	An INIT timeout was detected.
D59	Fieldbus error (DPRAM write/read)	A DPRAM write/read error was detected.
D5A	Fieldbus error (TOGGLE timeout)	A TOGGLE timeout was detected.
D5B	Fieldbus error (Access-privilege retry over)	An access-privilege retry over error was detected.
D5C	Fieldbus error (Access-privilege open error)	An access-privilege open error was detected.
D5D	Fieldbus error (FBRS link error)	A FBRS link error was detected.
D5E	Fieldbus error (Mailbox response)	A mailbox response error was detected.
D60	Expanded-SIO 2/4 CH isolation power error	An Expanded-SIO isolation power error was detected.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
D61	Expanded-SIO 1/3 CH isolation power error	An Expanded-SIO isolation power error was detected.
D62	Expanded-SIO baud-rate-generator clock oscillation error	An Expanded-SIO clock oscillation error was detected.
D63	Expanded-SIO UART paging error	An Expanded-SIO paging error was detected.
D64	Expanded-SIO assignment error	The "board channel assignment number" or "expanded-I/O slot assignment number" in I/O parameter Nos. 100, 102, 104, 106, 108 or 110 may be outside the input range or duplicated, a serial communication expansion board may not be installed in the specified slot, or a "communication mode" other than RS232C may have been selected when the "board channel assignment number" is other than "1" or "2," among other reasons.
D67	Motor/encoder configuration information mismatch error	Driver parameter No. 25 "Motor/encoder configuration information" (motor identification number, encoder identification number) does not match encoder parameter No. 11 "Motor/encoder configuration information" (motor identification number, encoder identification number). Check the parameter values, connection of the encoder cable, etc.
D68	No remote-mode control support board error	Hardware supporting remote-mode control is not installed, although remote-mode control (AUTOMANU) is specified in I/O parameter No. 79.
D69	External terminal block overcurrent or power-supply error	Overcurrent or power-supply error in the external terminal block
D6A	Hardware unsupported function error	An attempt was made to use a function not supported by the hardware.
D6B	Overrun error	The overrun sensor was actuated.
D6C	Actual-position soft limit over error	The actual position exceeded a soft limit by the "soft limit/actual position margin" or more.
D6D	Logic error	A logic error occurred.
D6E	Motor drive-source OFF error (MPONSTR-OFF)	An OFF status of the drive source (MPONSTR-OFF) was detected in a non-shutdown (SHDWNSTR-OFF) state.
D70	Option use permission error	Check, among others, if an option is specified with a system program that does not permit use of options.
E01	DMA address error	DMA transfer error
E02	SCIF send-buffer overflow error	The SCIF send buffer overflowed.
E03	SCI send-buffer overflow error	The SCI send buffer overflowed.
E04	SCIF receive-buffer overflow error	The SCIF receive buffer overflowed. Excessive data was received from outside.
E05	SCI receive-buffer overflow error	The SCI receive buffer overflowed. Excessive data was received from the slave.
E06	Receive timeout error (Slave communication)	Response from the slave cannot be recognized.
E07	SCI overrun error (Slave communication)	Communication failure. Check for noise, circuit failure and slave card.
E08	SCI framing error (Slave communication)	Communication failure. Check for noise, shorting, circuit failure and slave card.
E09	SCI parity error (Slave communication)	Communication failure. Check for noise, shorting, circuit failure and slave card.
E0A	SCI CRC error (Slave communication)	The CRC in the message is invalid.
E10	SCIF communication mode error	The communication mode is invalid.
E11	SCI communication mode error	The communication mode is invalid.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E12	SIO-bridge SCIF send-queue overflow error	The send queue overflowed.
E13	SIO-bridge SCI send-queue overflow error	The send queue overflowed.
E14	SCI receive-data-register full wait timeout error	Communication failure. Check for noise, shorting, circuit failure and slave card.
E15	SCI overrun error	Communication failure. Check for noise, shorting, circuit failure and slave card.
E16	Program end confirmation timeout error	The program cannot be ended.
E17	I/O-processing-program start logic error	The I/O-processing-program start logic is invalid.
E18	Task ID error	The task ID is invalid.
E19	WAIT factor error	The WAIT factor is invalid.
E1A	WAIT logic error	The WAIT logic is invalid.
E1B	Point-data valid address error	Point-data valid address is not set.
E1C	Source data error	The source data is invalid.
E1D	Unaffected output number error	The unaffected output number is invalid. A value other than an output port number ("0" is acceptable) may be input in I/O parameter Nos. 70 to 73.
E1E	Zone parameter error	A value other than an output port/global flag number ("0" is acceptable) or duplicate numbers may be input in axis-specific parameter Nos. 88, 91, 94 and 97, or the output number specified as system output in the I/O parameter for output function selection may be duplicated, among other reasons.
E1F	I/O assignment parameter error	A value other than an I/O port number ("-1" is acceptable) or other than an I/O head port number + [multiple of 8] may be input in I/O parameter Nos. 2 to 9, or a value other than a [multiple of 8] may be input in I/O parameter Nos. 14 to 17.
E20	I/O assignment duplication error	I/O assignments are duplicated. Check I/O parameter Nos. 2 to 9 and 14 to 17 and the I/O slot card type (number of I/Os), etc.
E21	I/O assignment count over error	The I/O assignments exceed the specified range. Check I/O parameter Nos. 2 to 9 and 14 to 17 and the I/O slot card type (number of I/Os).
E22	Header error (Slave communication)	The header in the message received from the slave card is invalid.
E23	Card ID error (Slave communication)	The card ID in the message received from the slave card is invalid.
E24	Response type error (Slave communication)	The response type in the message received from the slave card is invalid.
E25	Command type error (Slave communication)	The command type of the transmitting command is invalid.
E26	Target type error	The target type is invalid.
E27	No target error	Target (driver card, I/O card, encoder or other slave card) is not installed.
E29	EEPROM error (EWEN/EWDS not permitted)	EEPROM access error (when writing)



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E2A	Read compare mismatch error during EEPROM write	EEPROM access error (when writing)
E2B	Abnormal response error when sending EEPROM information acquisition command	An abnormal response was received when a slave-EEPROM information acquisition command was sent.
E2C	Maximum receive size over error when sending EEPROM information acquisition command	The maximum receive size exceeds the limit value when a slave-EEPROM information acquisition command is sent.
E2D	Receive-data checksum error when sending EEPROM information acquisition command	The checksum of receive data is invalid when a slave-EEPROM information acquisition command is sent.
E2E	No required power stage error	The required power stage is not installed for the valid axes.
E2F	No required regenerative resistance error	The required regenerative resistance is not installed for the valid axes.
E30	No required motor-drive power error	The required motor-drive power is not installed for the valid axes.
E31	No standard I/O slot error	Standard I/O unit is not installed.
E32	No control power error	Control power unit is not installed.
E33	Slave response logic error	The slave response logic is invalid.
E34	Slave block number out of range	The slave block number is out of range.
E37	Slave data setting prohibited	Setting of slave data is prohibited.
E38	Faulty slave EEPROM	The slave EEPROM is faulty.
E39	No encoder EEPROM error	The encoder is not equipped with EEPROM.
E3A	Absolute encoder error	Absolute encoder is specified illegally. (Check axis-specific parameter No. 38.)
E3C	Undefined slave-command error code detected	An undefined slave-command error code was detected.
E3D	SEL program/point/parameter flash ROM status error	Data is not written to the flash ROM correctly or written in an old, incompatible application version.
E3E	Parameter checksum error	The flash ROM data has been destroyed.
E3F	Gain parameter error	The setting of "Axis-specific parameter No. 60, Position gain," etc., is invalid.
E40	Rotational-movement axis parameter error	Check axis-specific parameter Nos. 67, 66, 38, 37, 1, etc.
E41	Servo-motion data packet shortage error	There are not enough servo-motion data packets.
E42	Servo job error	The servo job is invalid.
E45	Servo undefined command detection error	An undefined command was detected during servo processing.
E46	Maximum receive size over error at absolute-data acquisition	The receive size is too large when acquiring absolute data.
E47	No normal response error at absolute-data acquisition	Normal response is not received when acquiring absolute data.
E49	Encoder rotation error	An encoder rotation error was detected.
E4A	Encoder rotation counter overflow error	An encoder rotation counter overflow error was detected.
E4B	Encoder count error	An encoder count error was detected.
E4C	Encoder overspeed error	An encoder overspeed error was detected.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E4D	Driver phase-Z detection logic error	A phase-Z detection completion status was notified from the driver in a mode other than the phase-Z detection operation mode.
E4E	Phase-Z count parameter error	Check axis-specific parameter Nos. 23, 38, 37, etc.
E4F	Synchro parameter error	Check axis-specific parameter Nos. 65, 39, all-axis parameter No. 1, etc.
E50	Driver special command ACK-timeout error	ACK cannot be detected for the driver special command.
E51	Drive unit error (DRVESR)	Error notification from the driver
E52	Encoder error (DRVESR)	Error notification from the driver
E53	Driver CPU error (DRVESR)	Error notification from the driver
E54	Servo control error (DRVESR)	Error notification from the driver
E55	Command error (DRVESR)	Error notification from the driver
E56	Motor temperature error (DRVESR)	Error notification from the driver
E58	Servo ON/OFF timeout error	Servo ON/OFF cannot be confirmed.
E59	Brake ON/OFF timeout error	Brake ON/OFF cannot be confirmed.
E5A	Pole sense non-detection error	Motor magnetic pole cannot be detected.
E5B	Detection OFF error upon pole sense completion	The motor-magnetic-pole detection status bit (Psenex) is turned OFF after completion of pole sense.
E5C	Hold-at-stop servo job error	The servo job is invalid.
E5D	Servo packet error	The servo packets are invalid.
E5E	Servo-control-right management array number error	The servo-control-right management array number is invalid.
E5F	Length conversion parameter error	Check axis-specific parameter Nos. 47, 50, 51, 42, 1, etc.
E60	Slave maximum receive size over error	The slave receive size is too large.
E61	Slave no normal response reception error	Normal response cannot be received from the slave.
E62	Sending-slave CPU type error	The CPU type of the sending slave is invalid.
E63	Message-buffer information type error	The message-buffer information type is invalid.
E64	Abnormal standby power detection error	Abnormal standby power was detected.
E65	Regenerative resistance temperature error	A regenerative resistance temperature error was detected.
E66	AC-power overvoltage error	An AC-power overvoltage error was detected.
E67	Motor-power overvoltage error	A motor-power overvoltage error was detected.
E68	Emergency-stop status requiring reset recovery (not error)	Reset the emergency stop and then reconnect the power.
E69	Abnormal 24-V I/O power source	The 24-V I/O power source is abnormal.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E6A	Safety-gate open status requiring reset recovery (not error)	Close the safety gate and then reconnect the power.
E6B	Shutdown factor indeterminable error	Shutdown factor cannot be determined.
E6C	DO output current error	The DO output current is abnormal.
E6D	Drive-source cutoff relay error	The drive-source cutoff relay may have been melted.
E6E	Power-stage rating (W) mismatch error	A power stage with inappropriate rated capacity (W) is installed.
E6F	Power-stage rating (V) mismatch error	A power stage with inappropriate rated voltage (V) is installed.
E70	Motor-drive power rating (V) mismatch error	A motor-drive power source with inappropriate rated voltage (V) is installed.
E71	Encoder configuration information outside supported function information range	An encoder whose configuration information is outside the range supported by the driver unit is installed.
E72	Motor configuration information outside supported function information range	A motor whose configuration information is outside the range supported by the driver unit is installed.
E73	Encoder resolution mismatch error	The encoder resolution in the system's axis-specific parameter and that of the installed encoder do not match.
E74	Encoder division ratio mismatch error	The encoder division ratio in the system's axis-specific parameter and that of the installed encoder do not match.
E75	Encoder linear/rotary type mismatch error	The encoder linear/rotary type in the system's axis-specific parameter and that of the installed encoder do not match.
E76	Encoder ABS/INC type mismatch error	The encoder ABS/INC type in the system's axis-specific parameter and that of the installed encoder do not match.
E77	Magnetic-pole sensor installation specification mismatch error	The magnetic-sensor installation specification in the system's axis-specific parameter and that of the installed encoder do not match.
E78	Brake installation specification mismatch error	The brake installation specification in the system's axis-specific parameter and that of the installed encoder do not match.
E79	Abnormal response error when sending EEPROM-data setting slave command	An abnormal response was received when an EEPROM-data setting slave command was sent.
E7A	Maximum receive size over error when sending EEPROM-data setting slave command	The receive size exceeded the limit value when an EEPROM-data setting slave command was sent.
E7B	Motor-drive power ON timeout error	Abnormal current flow from the motor-drive power source
E7C	Register read/write test error	Error reading/writing the register
E7D	Linear-movement axis parameter error	Check axis-specific parameter Nos. 38, 68, 1, etc.
E7E	Parameter error	The parameter is invalid.
E7F	Stroke parameter error	Check axis-specific parameter Nos. 7, 8, 1, etc.
E80	Unsupported card error	An unsupported card is installed in an I/O slot.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E81	Priority auto-assignment card non-detection error	Priority auto-assignment card cannot be detected.
E82	Card mismatch error	The combination or positioning of I/O slot cards has a problem.
E83	I/O slot card error	The I/O slot card is invalid.
E84	Resolution parameter error	Check axis-specific parameter Nos. 47, 50, 51, 44, 42, 43, 1, 37, etc.
E85	Driver ready OFF factor indeterminable error	Driver ready OFF factor cannot be determined.
E86	Fieldbus error (FBVCCER)	A fieldbus error (FBVCCER) was detected.
E87	Fieldbus error (FBPOWER)	A fieldbus error (FBPOWER) was detected.
E88	Power error (Other)	A power error (Other) was detected. This error also generates when the power OFF → ON interval is short. After the power has been turned off, be sure to wait for at least 5 seconds before turning it back on. Abnormal regenerative resistance temperature is also suspected.
E89	SCIF open error in non-AUTO mode (Servo in use)	In a mode other than AUTO, opening of the serial 1 channel (also used by the PC software/TP port) from a SEL program is prohibited while the servo is in use (to ensure safety).
E8A	SEL program flash-ROM status error	Data is not written to the flash ROM correctly or written in an old, incompatible application version.
E8B	Symbol definition table flash-ROM status error	Data is not written to the flash ROM correctly or written in an old, incompatible application version.
E8C	Point data flash-ROM status error	Data is not written to the flash ROM correctly or written in an old, incompatible application version.
E8D	Parameter flash-ROM status error	Data is not written to the flash ROM correctly or written in an old, incompatible application version.
FF0 to F00	Shutdown error (hi_sysdwn () definition)	A shutdown error (hi_sysdwn () definition) was detected.
F03 to F58	Shutdown error (OS call error)	A shutdown error (OS call error) was detected.
F60	System-down level error-call procedure error	A system-down level error-call procedure error was detected.
F61	Interpreter-task end task ID error	An interpreter-task end task ID error was detected.
F62	Abnormal standby power detection error	Abnormal standby power was detected.
F63	Regenerative resistance temperature error	A regenerative resistance temperature error was detected.
F64	AC-power overvoltage error	An AC-power overvoltage error was detected.
F65	Motor-power overvoltage error	A motor-power overvoltage error was detected.
F66	Servo control underrun error	A servo control underrun error was detected.
F67	FROM-write bus width error	A write operation other than 32-bit long word access was detected while writing the flash ROM.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
F68	FROM write protect error	Write operation to a write-protected flash ROM area (FRMWE bit in DEVCTR = 1) was detected.
F69	Boot watchdog error	A FPGA boot watchdog was detected. The core program may not be running properly.
F6A to FA0	Undefined exception/interruption error	An undefined exception/interruption occurred.
FB0	TMU0 interruption error	A TMU0 interruption error was detected.
FB1	Application code SDRAM copy error (Checksum)	The sum of 4 bytes does not match between the corresponding sections after FROM → SDRAM program copy.
FB2	Installed flash ROM type mismatch (Application)	The flash ROM type anticipated in the software does not match the flash ROM type actually installed. Check the combination of software and hardware.



◎ Error List (MAIN core) (In the panel window, the three digits after “E” indicate an error number.)

Error No.	Error name	Description, action, etc.
A70	SCIF overrun error	Communication error. Check for noise, connected equipment and communication setting. (When updating the application, connect to a PC and use IAI's update tool.)
A71	SCIF framing error	Communication error. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting. (When updating the application, connect to a PC and use IAI's update tool.)
A72	SCIF parity error	Communication error. Check for noise, shorted/disconnected communication cable, connected equipment and communication setting. (When updating the application, connect to a PC and use IAI's update tool.)
A73	IAI protocol header error	Communication protocol error. Check for noise and connected equipment. (When updating the application, connect to a PC and use IAI's update tool.)
A74	IAI protocol terminal ID error	Communication protocol error. Check for noise and connected equipment. (When updating the application, connect to a PC and use IAI's update tool.)
A75	IAI protocol command ID error	Communication protocol error. Check for noise and connected equipment. (When updating the application, connect to a PC and use IAI's update tool.)
A76	IAI protocol checksum error	Communication protocol error. Check for noise and connected equipment. (When updating the application, connect to a PC and use IAI's update tool.)
A77	Motorola S record type error	The update program file is invalid. Check the file.
A78	Motorola S checksum error	The update program file is invalid. Check the file.
A79	Motorola S load address error	The update program file is invalid. Check the file.
A7A	Motorola S write address over error	The update program file is invalid. Check the file.
A7B	Flash timing limit over error (Write)	Error writing the flash ROM (When updating)
A7C	Flash timing limit over error (Erase)	Error erasing the flash ROM (When updating)
A7D	Flash verify error	Error erasing/writing the flash ROM (When updating)
A7E	Flash ACK timeout	Error erasing/writing the flash ROM (When updating)
A7F	Head sector number specification error	Error erasing the flash ROM (When updating)
A80	Sector count specification error	Error erasing the flash ROM (When updating)
A81	Write-destination offset address error (Odd-numbered address)	The address written during flash ROM write (when updating) is invalid. Check the update program file.
A82	Write-source data buffer address error (Odd-numbered address)	Error writing the flash ROM (When updating)
A83	Invalid code sector block ID error	The flash ROM is new, or the program currently written to the flash ROM is invalid because the last update was aborted. The ROM can be updated without problem.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
A84	Code sector block ID erase count over	The number of times the flash ROM was erased exceeded the allowable count.
A85	FROM write request error before erase is complete	When updating, a flash-ROM write command was received before a flash-ROM erase command. Confirm that the update program file is valid and then perform update again.
A86	Absolute-encoder backup battery voltage-low warning (Driver detection)	The voltage of the absolute-data backup battery is low. Check the battery connection or replace the battery.
A87	Motorola S byte count error (Detected by the core)	The update program file is invalid. Check the file.
A88	Message conversion error (Detected by the core)	The received message does not match the message format or contains invalid data. Check the message sent from the host communication device.
A89	Update target non-specification error (Detected by the core)	An update command was received before the update target was correctly specified during update processing. Check if an appropriate update PC tool is used and if the target specification and other settings of the update PC tool are correct.
A8A	Update system code error (Detected by the core)	The system code in the message of the received update target specification command does not match the controller system. Check the target specification and other settings of the update PC tool.
A8B	Update unit code error (Detected by the core)	The unit code in the message of the received update target specification command does not match the controller unit that can be updated. Check the target specification and other settings of the update PC tool.
A8C	Update device number error (Detected by the core)	The device number specified in the message of the received update target specification command is not appropriate. Check the target specification, device number and other settings of the update PC tool.
A8D	Flash busy reset timeout (Detected by the core)	Error erasing/writing the flash ROM
A8E	Unit type error (Detected by the core)	The unit type in the received command message is invalid or not supported.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
CD0	Drive unit error (Driver detection)	Error notification from the driver
CD1	Encoder error (Driver detection)	Error notification from the driver
CD2	Driver CPU error (Driver detection)	Error notification from the driver
CD3	Servo control error (Driver detection)	Error notification from the driver
CD4	Command error (Driver detection)	Error notification from the driver
CD5	Motor temperature error (Driver detection)	Error notification from the driver



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
E90	Core code flash-ROM status error	The core program is invalid. Contact the manufacturer.
E91	Application code flash-ROM status error	The application program is invalid. Contact the manufacturer.
E92	Core code sum error	The core program is invalid. Contact the manufacturer.
E93	Application code sum error	The application program is invalid. Contact the manufacturer.
E94	Timing limit over error (Flash erase)	Error erasing the flash ROM
E95	Flash verify error (Flash erase)	Error erasing the flash ROM
E96	Flash ACK timeout (Flash erase)	Error erasing the flash ROM
E97	Head sector number specification error (Flash erase)	Error erasing the flash ROM
E98	Sector count specification error (Flash erase)	Error erasing the flash ROM
E99	Timing limit over error (Flash write)	Error writing the flash ROM
E9A	Flash verify error (Flash write)	Error writing the flash ROM
E9B	Flash ACK timeout (Flash write)	Error writing the flash ROM
E9C	Write-destination offset address error (Flash write)	Error writing the flash ROM
E9D	Write-source data buffer address error (Flash write)	Error writing the flash ROM
E9E	Watchdog reset occurrence error	A WDT (watchdog timer) was manually reset (error detection).
E9F	Exception occurrence error while BL = 1 (NMI)	An exception occurred while the block bit in the CPU status register was "1." (NMI)
EA0	Exception occurrence error while BL = 1 (Other than NMI)	An exception occurred while the block bit in the CPU status register was "1." (Other than NMI)
EA1	Bit exception reset due to command/data TLB duplication	This reset occurs when there are multiple TLB entries corresponding to the virtual address.
EA2	Undefined exception/interruption error	An undefined exception/interruption occurred.
EA3	AC-power cutoff detection error	An AC-power cutoff was detected.
EA4	Abnormal standby power detection error	Abnormal standby power was detected.
EA5	Regenerative resistance temperature error	A regenerative resistance temperature error was detected.
EA6	AC-power overvoltage error	An AC-power overvoltage error was detected.
EA7	Motor-power overvoltage error	A motor-power overvoltage error was detected.
EA8	FROM-write bus width error	A write operation other than 32-bit long word access was detected while writing the flash ROM.
EA9	FROM write protect error	Write operation to a write-protected flash ROM area (FRMWE bit in DEVCTR = 1) was detected.
EAA	SDRAM write/read test error	The SDRAM is faulty. Contact the manufacturer.
EAB	Application-update SCIF send-queue overflow error	An overflow occurred in the send queue.



(In the panel window, the three digits after "E" indicate an error number.)

Error No.	Error name	Description, action, etc.
EAC	Servo control underrun error	A servo control underrun error was detected.
EAD	Boot error	A FPGA boot watchdog was detected. The core program may not be running properly.
EAE	Application-update SCIF receive-queue overflow error	Excessive data is received from outside. (Confirm that a PC and IAI's update tool are used to update the application.)
EAF	Installed flash ROM type mismatch (Core)	The flash ROM type anticipated in the software does not match the flash ROM type actually installed. Check the combination of software and hardware.
EB2	Flash busy reset timeout (Detected by the core)	Malfunction of the flash ROM. The flash ROM is not reset from the busy mode.



☉ Troubleshooting of X-SEL Controller

A panel window is provided in the front panel of the Tabletop Robot.

Error numbers will be displayed in this panel window.

When the power is turned on, normally “rdy” or “Ardy” will be displayed. “P01” or other code will be displayed while a program is running.

When an error generates, the panel window will show “EA1D” or other code starting with “E.” (Some errors do not begin with “E.”)

Status	Panel window display
After turning on the power	rdy, Ardy
Program is running	P01, P64, etc.
Error has generated	EA1D, ED03, etc.

* Among the alphabets, B and D are shown in lower case.

Depending on the error number, it may be possible to reset the error after removing the cause of the error, or the power must be reconnected to reset the error.

Also, some error numbers are output to the LED display in the panel window, while others are not.

For details, see “☉ Error Level Control.”



Troubleshooting (Causes and Countermeasures for Key Errors)

Error No.	Error name	Cause	Countermeasure
ACF	AC power cutoff	Momentary power failure has occurred or the voltage has dropped. 100 V is input while the controller's voltage specification is 200 V.	Check the power-source voltage. If the last digit of the controller's model number is "1," the power specification is 100 V. If the last digit is "2," the power specification is 200 V.
ErG	Emergency stop (This is not an error.)	Emergency-stop signal is input.	Emergency-stop signal is input in the following condition: 1. The emergency-stop button on the teaching pendant is pressed. 2. The applicable input terminal in the system connector is turned ON. 3. The port switch on the front panel is set to the manual side. (The teaching-pendant/PC-software connector is not connected.) 4. The actuator is of sensor specification and the slider is stopped on either end of the slider.
dSF	Deadman switch OFF	The switch is set to the manual side even when the teaching-pendant connector or other connector is not connected.	Set the switch to the auto side when the teaching-pendant connector or other connector is not connected.
CA5	Stop deviation overflow error	Operation is mechanically disabled. If there is no problem in the mechanical function, the power stage board is faulty.	Check to see if the actuator mounting bolts are contacting inside the axes, or if the slider attachment is contacting any surrounding mechanical parts. Replace the board.
C6b	Deviation overflow error	Operation is mechanically disabled.	Check to see if the actuator mounting bolts are contacting inside the axes, or if the slider attachment is contacting any surrounding mechanical parts.
d03	Encoder count error	The encoder is faulty or dust is attached.	Remove the motor cover and apply cleaning air spray for OA equipment, etc., over the cord wheel. If the problem persists, replace/readjust the encoder.



Error No.	Error name	Cause	Countermeasure
d10	IPM error	The motor coil is damaged.	Measure resistances among phases U/V/W. If the resistance values are different, the coil has been burned. Replace the motor. If the resistance values are almost the same, the coil has not been burned. Replace the board.
807	Shutdown relay ER status	If the motor coil is not damaged, the power stage board (to which the motor power cable is connected) is faulty. The transistor on the power-supply board (to which the power cable is connected) is damaged.	Replace the board.



Trouble Report Sheet			Date:				
Company name		Department		Reported by			
TEL	(Ext)	FAX					
Purchased from		Purchase date					
Serial number		Manufacture date					
[1] Number of axes <input type="checkbox"/> axis(es) Type							
[2] Type of problem 1. Disabled operation 2. Position deviation 3. Runaway machine 4. Error Error code = <table border="1"><tr><td></td><td></td><td></td></tr></table> 5. Other ()							
[3] Problem frequency and condition Frequency = Condition							
[4] When did the problem occur? 1. Right after the system was set up 2. After operating for a while (Operating hours: _____ year(s) and _____ month(s))							
[5] Operating direction 1. Horizontal 2. Horizontal + Vertical							
[6] Load condition 1. Load transfer 2. Push-motion operation 3. Load: Approx. _____ kg 4. Speed: Approx. _____ mm/sec							
[7] Special specification (option, etc.)							



Change History

Revision Date	Description of Revision
	First edition
	Second edition
	Third edition
December 2009	Fourth edition <ul style="list-style-type: none">• Corrected clerical errors, etc.• P. 282 to 287: Added input/output function selections.
May 2010	Fifth edition <ul style="list-style-type: none">• Added "Before Using This Product" on the first page after the cover.• Added "Safety Guide" at the beginning of the main text after the table of contents.• Added "Change History" on the last page.• Updated the back cover. (Changed the addresses of the head office and sales offices, and indicated that the customer service center Eight is open 24 hours, among others.)
October 2010	Sixth edition <ul style="list-style-type: none">• Warning notes for "Position during servo-on" are added below the servo-on descriptions in pages 140 and 141.
April 2011	Seventh edition Swapped over the page for CE Marking
March 2012	Eighth edition <ul style="list-style-type: none">• Contents added and changed in Safety Guide in pages 1 to 7• Caution in Handling added in pages 8• Contents changed in 13. Warranty in pages 12 to 13• Weight added to external dimensions on pages 36 to 43• Warning notes added such as in case the grease got into your eye, immediately go to see the doctor for an appropriate care in pages 248 and 249



IAI Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan
TEL +81-54-364-5105 FAX +81-54-364-2589
website: www.iai-robot.co.jp/

Technical Support available in USA, Europe and China

IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505
TEL (310) 891-6015 FAX (310) 891-0815
Chicago Office: 1261 Hamilton Parkway, Itasca, IL 60143
TEL (630) 467-9900 FAX (630) 467-9912
Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066
TEL (678) 354-9470 FAX (678) 354-9471
website: www.intelligentactuator.com

IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany
TEL 06196-88950 FAX 06196-889524

IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China
TEL 021-6448-4753 FAX 021-6448-3992
website: www.iai-robot.com