

Table Top Type Robot TT

First Step Guide

Second Edition

Thank you for purchasing our product.
Make sure to read the Safety Guide and detailed Instruction Manual (CD) included with the product in addition to this First Step Guide to ensure correct use.
This Instruction Manual is original.

Warning : Operation of this equipment requires detailed installation and operation instructions which are provided on the CD included in the box this device was packaged in. It should be retained with this device at all times.
A copy of the CD Manual can be requested by contacting your nearest IAI Sales Office listed at the back cover of the Instruction Manual or on the First Step Guide.

- Using or copying all or part of this Instruction Manual without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.

Product Check

This product is comprised of the following parts if it is of standard configuration.
If you find any fault in the contained model or any missing parts, contact us or our distributor.

1. Parts (The option is excluded.)

No.	Part Name	Model
1	Robot Main Body (with a built-in controller)	Refer to "How to read the model plate" and "How to read the model of the controller."
Accessories		
2	Power Supply Plug	AP-400-C (Manufacturer: Yamate Electric Co., Ltd.)
3	I/O Flat Cable	CB-DS-PIO020
4	First Step Guide	
5	Operation Manual (CD)	
6	Safety Guide	

2. Optional Components

No.	Part Name	Model
1	Main Body Mounting Bracket (with set bolts and nuts)	TT-FT

3. Teaching Tool (Option)

The personal computer application software or teaching pendant is required for the operations including program creation and setup such as position setting and parameter setting with teaching. Use either of them.


No.	Part Name	Model	Remarks
1	PC Software (with RS232C Cable + Emergency Stop Box)	IA-101-X-MW	RS232C→RS232C*1
2	PC Software (USB conversion adapter + RS232C cable + Cable and Emergency Stop Box)	IA-101-X-USB MW	USB→RS232C*1
3	PC Software (with USB Cable + Dummy Plug)	IA-101-TT-USB	USB→USB*1
4	Teaching pendant	SEL-T	—
5	Teaching pendant (with deadman switch)	SEL-TD	—
6	Teaching pendant	IA-T-X	—
7	Teaching pendant (with deadman switch)	IA-T-XD	—

*1 The communication port on the left is for the personal computer and on the right is for the TT.

4. Operation manuals related to this product, which are contained in the CD.

No.	Name	Manual No.
1	Table Top Type Robot TT Operation Manual	ME0149
2	PC software IA-101-X-MW Operation Manual	ME0154
3	Teaching pendant SEL-T/TD Operation Manual	ME0183
4	Teaching pendant IA-T-X/XD Operation Manual	ME0160
5	DeviceNet Operation Manual	ME0124
6	CC-Link Operation Manual	ME0123
7	PROFIBUS-DP Operation Manual	ME0153
8	X-SEL Ethernet Operation Manual	ME0140

5. How to read the model plate



6. How to read the Model No.

Model No. Example **TT - A3 - I - 2020 - 05B - DV**
 ① ② ③ ④ ⑤ ⑥

①Series	②Type	③Encoder type	④XY Stroke	⑤Z Stroke	⑥Option
TT (Normal)	A2:Gate Type with 2-axis C2:Cantilever Type with 2-axis A3:Gate Type with 3-axis C3:Cantilever Type with 2-axis	I: Incremental	2020 200×200mm 4040 400×400mm	- 50mm 10B 100mm	DV:DeviceNet Specifications CC:CC-Link Specifications PR:PROFIBUS Specifications ET :Ethernet Specifications FT :Main Body Mounting Bracket included P :I/O PNP Specifications

Basic Specifications

[Common Specifications]

Item	Specifications
Surrounding air temperature・humidity	0 to 40°C, Room Humidity 20% to 85% or less
Motor Type	Pulse Motor (Servo Control)
Position detection method	Incremental Encoder
Driving System	Ball Screw (φ10mm, Rolled C10), Ball Screw Lead 6mm
Positioning Repeatability	± 0.02mm
Backlash	0.1mm or less
Guide	Direct Driven Infinite Circulation Type
Allowable Load Moment*1	Ma:6.5N・m Mb:9.3N・m Mc:16.4N・m

*1 Value found on the assumption of the life of 5000 km run

[Individual Mechanism Specifications]

Type		Stroke (mm)			Max. Speed for each axes (mm/sec)			Acceleration/ Deceleration (G)	Max. Load Capacity (kg)*2			Weight (kg)	Model
		X Axis	Y Axis	Z Axis	X Axis	Y Axis	Z Axis		X Axis	Y Axis	Z Axis		
Gate Type with	2-axis	200	200	-	300			0.3	10	5	-	14.8	TT-A2-I-2020
		400	400	-								33	TT-A2-I-4040
	3-axis	200	200	50	300	280	0.3	10	-	2	16.5	TT-A3-I-2020-05B	
				100	300							TT-A3-I-2020-10B	
		400	400	50	300	280					35	TT-A3-I-4040-05B	
				100	300							TT-A3-I-4040-10B	
Cantilever Type with	2-axis	200	200	-	300			0.2	-	4	-	16.3	TT-C2-I-2020
		400	400	-								35	TT-C2-I-4040
	3-axis	200	200	50	300	280	0.2	-	-	2	18	TT-C3-I-2020-05B	
				100	300							TT-C3-I-2020-10B	
		400	400	50	300	280					37	TT-C3-I-4040-05B	
				100	300							TT-C3-I-4040-10B	

*2 The load capacity in the case of rated acceleration is shown (Gate Type: 0.3G, Cantilever Type: 0.2G)

[Controller Specifications]

Item	Specifications
Number of axes	2-axis 3-axis
Supply voltage	Single-phase 100 to 115VAC, 200 to 230VAC ± 10%
Power frequency	50Hz/60Hz
Power-source capacity	100VAC 150VA 210VA 200VAC 155VA 215VA
Maximum Current*3	3A (100VAC), 1.6A (200VAC) 4.2A (100VAC), 2.2A (200VAC)
Rush Current*4	15A (100VAC), 30A (200VAC)
Leakage Current	0.75mA
Insulation Strength	2000VAC for 1 min.
Momentary Power Interruption Tolerance	500μs or more
Speed Setting	1 to 300mm/sec
Acceleration Setting	0.01G to 0.3G
Program language	Super SEL language
Number of programs (Number of multitask programs)	64 programs (16 programs)
Number of program steps	6000 steps (Total)
Number of positions	3000 positions (Total)
Program Startup	Special Digital Switch + Special Start Switch
Data storage device	Flash ROM + SRAM*5
Standard I/O Board	16 Input Points / 16 Output Points
Applicable Field Bus	DeviceNet / CC-Link / PROFIBUS / Ethernet
Protective functions	Over-voltage, motor over current, motor overload, driver temperature abnormality, encoder abnormality, etc.


*3 The current reaches its maximum level when the servo-motor exciting phase is detected which is to be performed in the first servo-motor turning ON processing after the power injection. (Normal: Approx. 1 to 2 sec, Max.: 10 sec)

*4 Rush current at the power connection continues for about 20 msec. Consider the safety rate at the time when rush current passes. The rush current value varies depending on the impedance of the power line.

*5 The SRAM data is not battery backed up. Accordingly, when the power is turned off, the data of flags and variables used in the program, are not saved. Take the greatest care. The same procedure is applied when the program or position data is not written on the Flash ROM.

External Dimensions


[Gate Type with 2-axis TT-A2]



*1 Fine slider adjustment (for manual tweaking of position).

Model	A	B	C	D	E	F	G	Xst	Yst
TT-A2-I-2020	369.7	330	338.5	133.3	185	240	88.2	200	200
TT-A2-I-4040	569.7	530	538.5	333.3	385	440	188.2	400	400

[Gate Type with 3-axis TT-A3]



*1 Fine slider adjustment (for manual tweaking of position).

Model	A	B	C	D	E	F	Xst	Yst	Zst
TT-A3-I-2020-05B	369.7	330	338.5	83.3	135	240	200	200	50
TT-A3-I-2020-10B	369.7	330	338.5	83.3	135	240	200	200	100
TT-A3-I-4040-05B	569.7	530	538.5	283.3	335	440	400	400	50
TT-A3-I-4040-10B	569.7	530	538.5	283.3	335	440	400	400	100

[illegible]

								(Unit mm)	
Model	A	B	C	D	E	F	Xst	Yst	
TT-C2-I-2020	405	320	135	120	310	42	200	200	
TT-C2-I-4040	605	520	335	213.6	510	142	400	400	

The technical drawings include:


- T-Groove Section:** A cross-sectional view of the T-groove with dimensions: 7.3, 4.3, 1.8, and 4.3.
- Z-Slider Set Hole Section:** A cross-sectional view of the Z-slider set hole with dimensions: 4-M5 Depth 10, 37.4, 30, 2-φ 4H7 Depth 5, 30, 42, 50, and 4-M4 Depth 8.
- Z-Slider Position Adjusting Volume:** A detailed view of the Z-slider position adjusting volume with dimensions: 26, 2.5, ME, SE, Home, 40, 60, 4-M4 Depth 8, 4-M5 Depth 10, 2-φ 4H7 Depth 5, 84, 2.5, ME, Home, and Yst.
- Y Axis:** A side view of the Y-axis with dimensions: 317, 156, 10.58, 124.5, 1.5, 85, 10.6, 8, 22, 50, 60, 49, 10, 42, and 1.2.
- Z Axis:** A side view of the Z-axis with dimensions: 317, 40, 50, 60, 49, 10, 42, and 1.2.
- X Axis:** A side view of the X-axis with dimensions: 41.8, 30, 148.8, 45, 45, 1.2, and A.
- T-Groove (Four Locations):** A detail view of the T-groove with dimensions: 46, 2.5, ME, SE, Home, 40, 60, 4-M4 Depth 8, 4-M5 Depth 10, 2-φ 4H7 Depth 5, 84, 2.5, ME, Home, and Yst.

(Unit mm)									
Model	A	B	C	D	E	F	Xst	Yst	Zst
TT-C3-I-2020-05B	405	330.6	135	120	310	71	200	200	50
TT-C3-I-2020-10B	405	330.6	135	120	310	71	200	200	100
TT-C3-I-4040-05B	605	530.6	335	213.6	510	171	400	400	50
TT-C3-I-4040-10B	605	530.6	335	213.6	510	171	400	400	100

- Location where the surrounding air temperature exceeds the range of 0 to 40°C
- Location where condensation occurs due to abrupt temperature changes
- Relative humidity less than 20%RM or greater than 85%RM
- Location exposed to corrosive gases or combustible gases
- Location exposed to significant amount of dust, salt or iron powder
- Location subject to direct vibration or impact
- Location exposed to direct sunlight
- Location where the product may come in contact with water, oil or chemical droplets

- Location subject to electrostatic noise
- Location where high electrical or magnetic field is present
- Location with the mains or power lines passing nearby

1. There is a cooling vent hole on the main body's rear panel section. Do not close the vent hole when the main body is installed.
2. When it required to fix the main body, fix it as follows using the optional mounting brackets (Model TT-FT: 4 sets with secure bolts and nuts)
User supplied bolts to secure the brackets to the mounting surface or table.



Connect it using a soft copper wire with the diameter of 1.6 mm or more.

Rear Panel Section
Power Connector

Frame Ground

Class D grounding
(Formerly Class-3 grounding:
Grounding resistance at 100Ω or less)


Connect it using a soft copper wire with the diameter of 1.6 mm or more to the frame ground on the main body (Refer to the above figure).

Carry out noise elimination measures for power devices on the same power path and in the same equipment. The following are examples of measures to eliminate noise sources:


-

Connection Diagram

Front Panel Section



Rear Panel Section



- ^{*1} For the selection of the circuit breaker, perform it according to the following items.
- Breaker Teaching pendant Value > Power Capacity + AC Input Voltage (Refer to the item for the controller specifications for the power capacity).
- The current reaches the maximum level when the servo-motor is turned on and the servo-motor exciting phase is detected. Select the circuit breaker rated current that does not trip the maximum current.
 - Select the circuit breaker that does no trip with the rush current described in the controller specifications.
 - (Refer to the operating characteristic curve described in the manufacturer's catalog.)
 - For the rated breaking current for the circuit breaker, select the breaking current value with which the current can be securely broken down even when short-circuit current passes.
 - Rated Breaking Current > Short-circuit Current = Primary Power Supply Capacity/Power Voltage.
 - Select the breaking current value for the circuit breaker leaving some margin.

- ^{*2} When the leakage breaker is to be installed, it is required to select it with the purpose clarified such as protection from fire or human body protection.
- Measure the leakage current at the location where the leakage breaker has been installed.
- Use the “applicable to higher harmonics type” leakage breaker.

I/O Signals

Input

Pin No.	Electric wire color	Port No.	Function in Standard Setting (in Delivery)	Remarks
1	BR 1	—	I/O Power Source +24V	It is set to the universal input when it is delivered. However, the change of the input function is available with the I/O parameter setting.
2	RD 1	016	Universal Input	Parameter ^{*1} No. 30 Input function select 000 ^{*2} 1: Program Start
3	OR 1	017	Universal Input	31 Input function select 001 0: Universal Input 1: Software Reset
4	YW 1	018	Universal Input	32 Input function select 002 0: Universal Input 1: Servo ON signal
5	GN 1	019	Universal Input	33 Input function select 003 0: Universal Input 1: Program automatically started when the power ON is reset in AUTO mode and software is reset 2: Automatic Starting Program Signal
6	BL 1	020	Universal Input	34 Input function select 004 0: Universal Input 1: All servo-axes soft interlock (OFF level)
7	PL 1	021	Universal Input	35 Input function select 005 0: Universal Input 1: Pause Release (ON edge)
8	GY 1	022	Universal Input	36 Input function select 006 0: Universal Input 1: Pause Signal (OFF level)
9	WT 1	023	Universal Input	37 Input function select 007 ^{*3} 0: Universal Input 1: Program No. appointment (LSB)
10	BK 1	024	Universal Input	38 Input function select 008 ^{*3} 0: Universal Input 1: Program No. appointment(The second bit)
11	BR 2	025	Universal Input	39 Input function select 009 ^{*3} 0: Universal Input 1: Program No. appointment(The third bit)
12	RD 2	026	Universal Input	40 Input function select 010 ^{*3} 0: Universal Input 1: Program No. appointment(The fourth bit)
13	OR 2	027	Universal Input	41 Input function select 011 ^{*3} 0: Universal Input 1: Program No. appointment(The fifth bit)
14	YW 2	028	Universal Input	42 Input function select 012 ^{*3} 0: Universal Input 1: Program No. appointment(The sixth bit)
15	GN 2	029	Universal Input	43 Input function select 013 ^{*3} 0: Universal Input 1: Program No. appointment(MSB : The seventh bit) 2: Error Reset (ON edge)
16	BL 2	030	Universal Input	44 Input function select 014 0: Universal Input 1: Driving Power Interruption Cancellation Input (ON Edge)
17	PL 2	031	Universal Input	45 Input function select 015 0: Universal Input 1: All Effective Axes Homing (ON Edge) 2: All Increment Effective Axes Homing (ON Edge)


- ^{*1} Set the input functions using the I/O parameter Nos. 30 to 45 (Input Function Selection 000 to 015) and set the port Nos. that assign the each of the set functions, using the I/O parameter Nos. 282 to 298.
- ^{*2} If the input function selection 000 (program start) is assigned to any port except for the Port No. 000, the start switch on the front panel is disabled.
- ^{*3} When the input function selection 007 to 013 (program No. designating digital switch) are assigned to any port except for the port Nos. 007 to 013, the program change digital switch on the front panel is disabled.

Output

Pin No.	Electric wire color	Port No.	Function in Standard Setting (in Delivery)	Remarks
18	GY 2	316	Universal Output	Parameter ^{*4} No. 46 Output function select 300 ^{*5} Output function select 300 (Area 2) 0: Universal Output 1: Error Output at the operation cancellation level or more (ON) 2: Error Output at the operation cancellation level or more (OFF) 3: Error Output at the operation cancellation level or more + emergency stop output (ON) 4: Error Output at the operation cancellation level or more + emergency stop output (OFF)
19	WT 2	317	Universal Output	47 Output function select 301 ^{*5} Output function select 301 (Area 2) 0: Universal Output 1: READY Output (PIO Trigger Program Operation Available) and without occurrence of any error at the operation cancellation level or more 2: READY Output (PIO Trigger Program Operation Available) and READY Output (PIO Trigger Program Operation Available, and without occurrence of any error at the cold start level or more or more level or more
20	BK 2	318	Universal Output	48 Output function select 302 ^{*5} Output function select 302 (Area 2) 0: Universal Output 1: Emergency-stop output(ON) 2: Emergency-stop output(OFF)
21	BR 3	319	Universal Output	49 Output function select 303 ^{*5} Output function select 303 (Area 2) 0: Universal Output 1: AUTO Mode Output 2: Output during the Automatic Operation (In addition, when the parameter No. 12 is set to “1”)
22	RD 3	320	Universal Output	50 Output function select 304 ^{*5} Output function select 304 (Area 2) 0: Universal Output 1: Output at the time of “All Effective Axes Homing (=0)” 2: Output when all the effective axes homing is completed 3: Output when all the effective axes home preset coordinates are set
23	OR 3	321	Universal Output	51 Output function select 305 Output function select 305 (Area 2) 0: Universal Output 2: Output during the first axis servo ON
24	YW 3	322	Universal Output	52 Output function select 306 Output function select 306 (Area 2) 0: Universal Output 2: Output during the second axis servo ON
25	GN 3	323	Universal Output	53 Output function select 307 Output function select 307 (Area 2) 0: Universal Output 2: Output during the third axis servo ON
26	BL 3	324	Universal Output	54 Output function select 308 Output function select 308 (Area 2) 0: Universal Output
27	PL 3	325	Universal Output	55 Output function select 309 Output function select 309 (Area 2) 0: Universal Output
28	GY 3	326	Universal Output	56 Output function select 310 Output function select 310 (Area 2) 0: Universal Output
29	WT 3	327	Universal Output	57 Output function select 311 Output function select 311 (Area 2) 0: Universal Output
30	BK 3	328	Universal Output	58 Output function select 312 Output function select 312 (Area 2) 0: Universal Output
31	BR 4	329	Universal Output	59 Output function select 313 Output function select 313 (Area 2) 0: Universal Output
32	RD 4	330	Universal Output	60 Output function select 314 Output function select 314 (Area 2) 0: Universal Output
33	OR 4	331	Universal Output	61 Output function select 315 Output function select 315 (Area 2) 0: Universal Output
34	YW 4	—	I/O Power Source 0V	

- ^{*4} Set the output functions using the I/O parameter Nos. 46 to 61 (Output Function Selection 300 to 315) and set the port Nos. that assign the each of the set functions, using the I/O parameter Nos. 299 to 314. Also, setting the output functions using the I/O parameter Nos. 331 to 346 (Output Function Selection 300 Area 2 to 315 Area 2) and setting the Port Nos. that assign the each of the set functions, using the I/O parameter Nos. 315 to 330, are available.
- When the system output signal is output to the I/Os on the above table, use the Output Function Selection Area 2.
- ^{*5} Because the output function selections 300 to 304 are allocated to the LEDs on the panel window, when the parameters of 46 to 50 are set to universal output, or the Port No. allocation is changed using the parameter 299 to 303 settings, the LEDs are disabled.

I/O Flat Cable (Accessories) CB-DS-PIO020




I/O Specifications

Specifications	Input section		Output section	
	Item	Specifications	Item	Specifications
NPN	Input voltage	24VDC ± 10%	Load voltage	24VDC
	Input current	7mA 1 circuit	Peak load electric current	100mA/1 point 400mA/8 ports*6
	ON/OFF Voltage	NPN ON Voltage : MIN. 16VDC OFF Voltage : MAX. 5VDC	Leak current	MAX. 0.1mA/1 point
		PNP ON Voltage : MIN. 8VDC OFF Voltage : MAX. 19VDC		*6 The total of load current reaches max. 400mA every 8 ports from output port No. 300.
PNP	Controller		Controller	
	Controller		Controller	


For the input and output, an equivalent circuit expressing the logic is used.

I/O Circuit Diagrams

NPN Specifications




PNP Specifications



Starting Procedures

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below.



Set-up for operation is completed.

Troubleshooting

The following alarm displays are frequently generated at the start-up operation.
Deal with each of them referring to the following table.

Status display	Status contents	Cause and Remedy
	During Emergency-stop	It is not an alarm. <ul style="list-style-type: none">• It is caused when the emergency stop button is not cleared on the front panel. Clear it.• It is generated when the emergency stop switch in the teaching pendant or the personal computer application software is not cancelled. In such case, cancel it.• It is generated when the personal computer cable is not connected to the emergency stop box.
	Deadman switch OFF	It is not an alarm. <ul style="list-style-type: none">• It generated when the AUTO/MANU switch has been set to "MANU" and the personal computer or the teaching pendant is not connected. Connect the personal computer or the teaching pendant or set the AUTO/MANU switch to "AUTO".• When the actuator is to be started up, hold the deadman switch on the teaching pendant to turn it on.
	AC Power Interruption Momentary Power Failure Power Voltage Drop	It is generated when the power voltage is not supplied. Check the power supply.
	24V I/O Error	It is generated when the +24V power for I/O is not supplied. Check the power supply. (Procedure for starting up I/O 24V power unit without connection) Set both the I/O parameter No. 10 and No. 12 to "0". In this case, the I/O connection is invalid.
	Field Bus Error	It is generated when the field bus link connection is not established. Check the link cable connection, I/O parameter and PLC parameter settings. (How to start up the controller without connecting the field bus) Set both the I/O parameter No. 10 and No. 12 to "0".



Quality and Innovation

IAI Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan
TEL +81-54-364-5105 FAX +81-54-364-2589
website: www.iai-robot.co.jp/

Technical Support available in USA, Europe and China

IAI America, Inc.

Head Office: 2690 W, 237th Street Torrance, CA 90505
TEL (310) 891-6015 FAX (310) 891-0815
Chicago Office: 1261 Hamilton Parkway Itasca, IL 60143
TEL (630) 467-9900 FAX (630) 467-9912
Atlanta Office: 1220 Kennestone Circle Suite 108 Marietta, GA 30066
TEL (678) 354-9470 FAX (678) 354-9471
website: www.intelligentactuator.com

IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany
TEL 06196-88950 FAX 06196-889524

IAI (Shanghai) Co.,Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China
TEL 021-6448-4753 FAX 021-6448-3992
website: www.iai-robot.com